

# SERVICE MANUAL

SERVICE MANUAL

 **DAELIM MOTOR CO.,LTD.**

- HEAD OFFICE (FACTORY)  
#58, SUNG SAN-DONG, CHANGWON, KYUNGNAM, KOREA  
TEL : (82-55) 239-7000 / FAX : (82-55) 239-7524
- OVERSEAS SALES OFFICE  
#13-5, SUNG SOO 1DONG 1GA, SUNG DONG GU, SEOUL, KOREA  
TEL : (82-2) 498-6465 / FAX : (82-2) 467-9997



 **DAELIM MOTOR**

## HOW TO USE THIS MANUAL

This manual describes effective maintenance procedure for the Cordi manufactured by DAELIM Motor Co., Ltd. To ensure safety and optimal operating conditions of the vehicle, carry out regular inspections according to the maintenance schedule (Section 2).


Sections 1 through 2 provide information on overall vehicle; section 3, assembly and disassembly procedures for external components, and section 4 describes maintenance procedure for the engine, frame and electrical systems.

To facilitate use of this manual, each page starts with disassembly and system diagrams, service information, and troubleshooting guide. If you cannot find the cause of trouble, refer to Section 18: Troubleshooting.

- Contents of this manual and specifications are subject to change without prior notice for improvement of vehicle quality.
- No part of this publication may be reproduced without written permission of DAELIM Motor Co., Ltd.,

## CONTENTS

<b>GENERAL</b>	<b>SERVICE INFORMATION</b>	<b>1</b>
	<b>INSPECTIONS/ADJUSTMENTS</b>	
	<b>EXTERNAL PARTS</b>	
<b>ENGINE</b>	<b>LUBRICATION SYSTEM</b>	<b>4</b>
	<b>FUEL SYSTEM</b>	
	<b>ENGINE REMOVAL/INSTALLATION</b>	<b>6</b>
	<b>KICK STARTER/ CONTINUOUSLY VARIABLE TRANSMISSION</b>	
	<b>CYLINDER HEAD/CYLINDER/PISTON</b>	
	<b>TRANSMISSION/CRANKSHAFT/CRANK CASE</b>	<b>9</b>
<b>FRAME</b>	<b>FRONT WHEEL/FRONT FORK/STEERING</b>	<b>10</b>
	<b>REAR WHEEL/BRAKE/SUSPENSION</b>	<b>11</b>
	<b>BRAKE SYSTEM</b>	<b>1</b>
<b>ELECTRICAL SYSTEM</b>	<b>BATTERY/CHARGING SYSTEM</b>	<b>1</b>
	<b>IGNITION SYSTEM</b>	<b>14</b>
	<b>STARTING SYSTEM</b>	<b>1</b>
	<b>LIGHTS/METER/SWITCHES</b>	<b>16</b>
	<b>WIRING DIAGRAM</b>	<b>1</b>
	<b>TROUBLESHOOTING</b>	<b>1</b>



Cordi

---

# 1. SERVICE INFORMATION

<b>GENERAL SAFETY . . . . .</b>	<b>1-1</b>	<b>TWIST TORQUE . . . . .</b>	<b>1-14</b>
<b>SERVICE RULES . . . . .</b>	<b>1-1</b>	<b>SPECIALIZED TOOLS . . . . .</b>	<b>1-16</b>
<b>CAUTION WHEN WIRING . . . . .</b>	<b>1-5</b>	<b>LUBRICATION OIL . . . . .</b>	<b>1-17</b>
<b>SERIAL NUMBER LOCATION . . . . .</b>	<b>1-9</b>	<b>SYMBOLS . . . . .</b>	<b>1-18</b>
<b>MAINTENANCE INFORMATION . . . . .</b>	<b>1-10</b>	<b>WIRING DIAGRAM . . . . .</b>	<b>1-19</b>



## GENERAL SAFETY

### ⚠ WARNING

1. Do not run the engine for a long time in closed or not well-ventilated area because the exhaust gas contains toxic substances such as carbon monoxide, hydrocarbon, nitric oxide.
2. The battery fluid(lean sulfuric acid) is extremely toxic. It is dangerous if skin is exposed to it or if it enters into the eye. Be careful in handling. When exposed to the battery fluid, wash it with water and get a medical check up.(store the battery fluid in a safe place to avoid touching by the children)
3. Pay attention not to be burned and always put on the protection gears because the engine or the muffler is hot right after engine stops.
4. Gasoline is extremely flammable. Maintenance must performed in the place free of the open fire or electric spark.
5. When more than two person are working, always pay attention to other worker's action and always have safety in mind.
6. The skin exposed to used engine oil can be a major reason of the skin cancer. Pay attention not to exposed and wash carefully with soap and water after handling.
7. If compressed air is used to clean the brake, dust scattered in the air can be breathed in by workers. Please take action not to scatter dust in the brake cleaner, etc.
8. Flammable nitrogen gas is generated during charging the battery so charging must be performed in well-ventilated area and free of the open fire and spark.


## SERVICE RULES

1. Parts and lubrication oil must be DAELIM genuine or recommended parts.
2. Before maintenance, remove deposit or dust from the chasis.



# SERVICE INFORMATION


3. Store the parts of each system discriminatively to install each part in the right place.



4. After removing gasket, O-ring, piston pin clip and cotter pin, always replace them with the new one. When removing the snap ring, it can be easily missed after transformation or installation.




5. Clean the parts after the overhaul and before the test and remove the cleaning oil with compressed air. Apply oil to seal face during installation.




6. Check necessary place and measure necessary data during installation. When installing, return to the state before removing.



7. Align the bolts to uniform the tightening points before tightening them when you don't know the bolt length.



8. Bolts, nuts and pieces must be tightened from the bigger diameter to the smaller one, from inside to outside and diagonally with the specified torque.




9. Check to see if the rubber part is worn out when removing it and replace it if necessary. Some rubber part is weak to gasoline and kerosene, so pay attention not to soak with gasoline or oils.




10. Recommended grease must be applied to or filled in the specified place.



11. Maintenance needed to use the specialized tools must be performed with the right tool.




12. Never reuse the ball bearing removed with the ball applied pressure when removing press-fitted the bearing.




13. Check the smooth rotation of inner or outer race of the ball bearing by rotating it manually.

- Replace the ball bearing having excessive axial/longitudinal hanging.
- Wipe the ball bearing likely to have hanging with cleaning oil.(except double-sided sealed type ball bearing)
- Replace the ball bearing of which press-fitted part is slacked at the case or shaft.




14. Pay attention to installation direction in case of the single-sided sealed ball bearing. Install the open-direction or double-sided sealed bearing in the way that the face marked with manufacturer and size should direct to the outer axle.



15. When blowing the ball bearing with compressed air after cleaning, keep the race from rotating. High speed rotation of the race may damage the bearing. Prior to installation, apply oil or grease to the bearing.




16. Install the snap ring so that chamfered side directs to the load-applied side. After installation, check the proper installation by rotating the snap ring.



17. Check each part for proper tightening and operation after installation.




18. The brake fluid and coolant can damage the painted plastic or rubber parts. Keep these parts from contacting with them and wash these parts with water in case of contact.




# SERVICE INFORMATION


19. Install the oil seal so that the manufacturer marked surface directs outer surface.(direction not covered with oil)
- Pay attention not to bend or damage the lip.
  - Apply the grease to the lip.




20. Connect the tube until the tube fully inserted in the joint. Install the clip if it is supplied. Replace the tube having slacked end.




21. Keep the pneumatic system interior or the engine interior from the infiltration of dust.




22. Install the gasket mounted in the contact surface of each case of the engine while removing gasket material completely. Remove damaged contact surface by wiping with the oil stone equally.



23. Pay attention not to bend the cable excessively. Transformed or damaged cable may cause malfunction or damage.




24. Install the boots with the installing groove by inserting the boots into the groove.




# CAUTION WHEN WIRING


- Each cord must be connected depending on its color. When connecting different cord, attach color tube around the connector. Connect the coupler to the connector with same color and same pin number.
- Identify the two-colored cord by main color first and then striped color .




- When measuring voltage or resistance of the cord terminal using tester, contact the tester plug behind of the coupler. Pay attention not to open the cord terminal and contact the tester plug from the front of the coupler in case of water-proof coupler.




- Recheck the condition of contact, securing and continuity of each part after maintenance.
- When connecting the battery, the plus terminal must be connected first.
- After connecting the terminal, apply the grease to the terminal.




- When disconnecting the battery, the minus terminal must be disconnected first.
- Make sure that the tool such as spanner do not contact with the frame.



- Connect covers to the terminal after maintenance.



- If the fuse is short-circuited, find out the cause and repair. Replace with the fuse having the specified capacity.




- If there is rust in the terminal, remove the rust with sand paper prior to connecting.






# SERVICE INFORMATION


- Turn off the main switch before connecting/disconnecting.
- Release the lock to disconnect the lock of the coupler.
- The lock of the coupler has two types according to releasing method (press type and pull type) so release it properly according to the shape.
- Typical releasing method of the coupler is illustrated in the following.




- Release the lock by inserting the coupler slightly and then narrowing connection to remove the coupler.




- Check to see if there is bended terminal and secure it to avoid disconnecting.




- When disconnecting the coupler, disconnect it while holding the coupler body. Pull while holding the wire harness cord and do not remove the coupler connection.




- Insert the lock of the coupler until the lock is fully secured.




- Pay attention not to damage the vinyl cover of the coupler.




- If the wire harness coating is damaged, repair by winding vinyl tape or replace it.
- Prior to connecting the connector, make sure that the cover is not damaged and the mess terminal is not opened.



- Insert the connector until the vinyl cover is fully inserted into the terminal.
- The opening of the vinyl cover must face at the ground direction but in case of the plain connector, the draining opening must face at the sky direction.




- Wire band must be secured firmly in the specified location of the frame. In case of aluminium band, secure the wire harness to the coated part.




- In case of the weld clamp, do not clamp in the welded part.




- When clamping the wire, pay attention not to contact with hot part.




- When removing T-start, broaden the groove of T-start using the wiring driver and release the torque.
- Connect the harness and the hose to T-start and then insert until the groove is locked.
- When removing T-start from the frame, replace it with the new one.




- Secure the wire harness firmly using the clamp.



- When clamping the wire harness, make sure that the harness is not contacted with the shaft or rotating part.




- The wire harness must be routed without contacting with the end of the lamp or any sharp edge.
- The wire harness must be routed without contacting with the end of the bolt or the piece.




# SERVICE INFORMATION

- In case that the wire harness is contacted with the end or the sharp edge, protect both parts with tube or tape.





- The wire must not hang down or be pulled excessively.





- If necessary, lock the wire harness properly.

- When mounting parts, make sure that the wire harness is not pressed by the parts.




- Do not twist the wire harness.

- Wire the wire harness not to be pulled or expanded when the handle is turned to the right or the left completely. Avoid excessive bending or chewing and interference with the engine.




- Prior to using the tester, please read the manual carefully and understand the contents.
- When testing the resistance of the tester, the zero adjustment must be performed before testing.

- Do not drop or throw the parts especially semiconductor contained parts because these parts may be damaged by the impact of the drop.



# SERIAL NUMBER LOCATION



## ENGINE SERIAL NUMBER LOCATION




## FRAME SERIAL NUMBER LOCATION



## SPECIFICATIONS

ITEM		SPECIFICATIONS	ITEM	SPECIFICATIONS
TYPE OF VEHICLE		Cordi	BRAKING DISTANCE	8.0m(30km/h )
OVERALL LENGTH		1,715mm	MIN. REVOLUTION RADIUS	1,800mm
OVERALL WIDTH		665mm	COOLING TYPE	AIR-COOLED
OVERALL HEIGHT		1,053mm	STARTING	STARTER MOTOR, KICK
WHEEL BASE		1,227mm	MOTOR TYPE	2-CYCLE
MOTOR TYPE		SE50E	NO. OF CYLINDERS, MOUNTING	1 CYLINDER, TRANSVERSE
DISPLACEMENT		49.5cc	VALVE APPARATUS	READ VALVE PISTON VALVE COMBINATION
FUEL TYPE		UNLEADED GASOLINE	BORE & STROKE	40X39.4mm
DRY WEIGHT	FRONT AXLE	28.8kg	COMPRESSION RATIO	7.3:1
	REAR AXLE	47.7kg	MAX. OUTPUT	5.7PS/7,000rpm (2.95PS/6,000rpm)
	TOTAL	76.5kg	MAX. TORQUE	0.63kgf · m/6,500rpm (0.35kgf · m/5,500rpm)
PASSENGERS		1(65kg)	PRIMARY SPEED REDUCTION RATIO	3.077
GROUND CLEARANCE		105mm	SECONDARY SPEED REDUCTION RATIO	3.461
CASTER		27°	TRANSMISSION	NON STAGE TRANSMISSION
TRAIL		69mm	TRANSMISSION RATIO 1ST GEAR	2.41~0.76
FRAME TYPE		UNDER BONE		


※ “( )” MARKED CONTENTS APPLY TO EUROPE ONLY.



ITEM		STANDARD	USE LIMITS
<b>LUBRICATION SYSTEM</b>	ENGINE OIL TANK CAPACITY FULL CAPACITY	1.2 liters	
	RECOMMENDED ENGINE OIL	Motix, 2-Cycle Oil	
<b>LUBRICATION TYPE</b>	TRANSMISSION OIL CAPACITY FULL CAPACITY	0.09 liters	
	RECOMMENDED TRANSMISSION OIL	DMC Pure Mission Oil or SAE 80W/90	
<b>LUBRICATION TYPE</b>	OIL FILTER TYPE	Separation Lubrication	
	OIL PUMP TYPE	Current Filtration, Plunger Type	
<b>COOLING TYPE</b>	COOLING TYPE	Air-Cooled	
<b>FUEL SYSTEM</b>	FUEL TANK CAPACITY FULL CAPACITY	4.8 l	
	AIR CLEANER TYPE	Urethane Foam	
	CARBURETOR	PA 35	
	SETTING MARK	14mm	
	VENTURI DIAMETER	1 1/2 Rotation(1 1/8 Rotation)	
	AIR SCREW OPENING	12.2	
	FLOAT LEVEL	2,000rpm	
	IDLING RPMS	2	
	NO. OF JET NEEDLES	#77(#65)	
	MAIN JET	#38(#35)	
SLOW JET	2-6mm		
THROTTLE GRIP CLEARANCE			
<b>CYLINDER HEAD, CYLINDER, PISTON</b>	PORT OPEN/CLOSE PERIODS INHALATION	OPEN	Auto Control
		CLOSE	Auto Control
	EXHAUST	OPEN	80.5° BBDC
		CLOSE	80.5° ABDC
	SCAVENGING	OPEN	55° BBDC
		CLOSE	55° ABDC
	CYLINDER HEAD COMPRESSION PRESSURE		12.0kgf/cm <sup>2</sup> -600rpm
	CYLINDER ID MARK LOCATION		Top of Cylinder
	INSIDE DIAMETER ID MARK(A)		φ40.005 ~ φ40.010mm
	NO ID MARK		φ40.010 ~ φ40.015mm
	CYLINDRICAL DEGREE		-
	OUT OF ROUNDNESS		-
	PISTON OUTSIDE DIAMETER		
	ID MARK(A)		φ39.955 ~ φ39.960mm
	ID MARK(B)		φ39.965 ~ φ39.970mm
	NO ID MARK		φ39.960 ~ φ39.965mm
	CYLINDER AND PISTON CLEARANCE		0.040 ~0.055mm
	PISTON PIN HOLE INSIDE DIAMETER		φ12.002 ~ φ12.008mm
	PISTON PIN OUTSIDE DIAMETER		φ11.994 ~ φ12.000mm
	PISTON AND PISTON PIN CLEARANCE		0.002 ~ 0.014mm
PISTON RING GAP TOP		0.15 ~ 0.3mm	
	SECOND	0.15 ~ 0.3mm	
RING MARK		Turning up	
CONNECTING ROD SMALL END PORTION DIAMETER		φ17.005 ~ φ17.017mm	
			0.10mm
			0.10mm
			17.03mm

※“( )” MARKED CONTENTS APPLY TO EUROPE ONLY.

# SERVICE INFORMATION

ITEM		STANDARD	USE LIMITS		
CLUTCH	CLUTCH	AUTOMATIC TYPE	Automatic Centrifugal Continuously Variable Transmission		
		CLUTCH OUTER DIAMETER	$\phi$ 107.0~ $\phi$ 107.2mm		
		CLUTCH LINING THICKNESS	4.0mm		
	DRIVE BELT	WIDTH	15mm		
	MOVABLE DRIVE FACE	BUSH INSIDE DIAMETER	$\phi$ 20.035~ $\phi$ 20.085mm		
		BOSS OUTSIDE DIAMETER	$\phi$ 20.011~ $\phi$ 20.025mm		
		WEIGHT ROLLER OUTSIDE DIAMETER	$\phi$ 15.92~ $\phi$ 16.08mm		
CRANK SHAFT	DRIVEN PULLEY	FACE SPRING FREE LENGTH	$\phi$ 98.1mm		
		FACE OUTSIDE DIAMETER	$\phi$ 33.965~ $\phi$ 33.985mm		
		MOVABLE FACE INSIDE DIAMETER	$\phi$ 34.000~ $\phi$ 34.025mm		
	CRANK SHAFT	LARGE END SIDE CLEARANCE	0.15~0.55mm	0.60mm	
		CONNECTING ROD LARGE END RIGHT ANGLE DIRECTION CLEARANCE	0.010~0.02mm	0.04mm	
		CRANK SHAFT SHAKING A	0.05mm(70mm from center)	0.15mm	
	B	0.03mm(37mm from center)	0.10mm		
					
FRONT, REAR WHEELS	WHEELS	RIM RUNOUT	RADICAL	-	2.0mm
			AXIAL	-	2.0mm
		AXLE DEFLECTION		-	0.2mm
	TIRES	TYPE		TUBELESS	-
		TIRE PRESSURE	FRONT	1.25 kgf/cm <sup>2</sup>	-
			REAR	2.00 kgf/cm <sup>2</sup>	-
		TIRE SIZE	FRONT	90/90-10-50J	-
			REAR	90/90-10-50J	-

		ITEM	STANDARD	USE LIMITS
<b>BRAKES</b>	FRONT BRAKE	LEVER FREE PLAY	10~20mm	-
		BRAKE FLUID	DOT3 or DOT4	-
		BRAKE PAD THICKNESS	-	to wear line
		DISK THICKNESS	3.0mm	2.5mm
		DISK SHAKING	-	0.3mm
		DISK WEAR LINE	2.5mm	
	REAR BRAKE	MASTER CYLINDER INSIDE DIAMETER	11.000-11.043mm	11.05mm
		MASTER PISTON OUTSIDE DIAMETER	10.957-10.984mm	10.91mm
		CALIPER CYLINDER INSIDE DIAMETER	30.230-30.280mm	30.29mm
		CALIPER PISTON OUTSIDE DIAMETER	30.148-30.198mm	30.14mm
		LEVER FREE PLAY	10~20mm	-
		DRUM INSIDE DIAMETER	95mm	95.5mm
	LINING THICKNESS	4.0mm	2.0mm	
<b>IGNITION SYSTEM</b>	SPARK PLUG	STANDARD	BP6HS(BPR6HS)	
		OP (at low speed)	B4HSA(BR4HSA)	
		OP (at high speed)	BP7HS(BPR7HS)	
		PLUG GAP	0.6~0.7mm	
	IGNITION TIMING	F MARK	BTDC 15° /2,000rpm	
	PEAK VOLTAGE	IGNITION COIL(PRIMARY VOLTAGE)	300V ± 25V	
		EXCITE COIL	over 100V	
		PULSE GENERATOR	over 2.8V	
	IGNITION COIL RESISTANCE VALUES(20°C)	PRIMARY COIL	0.1~0.5 Ω	
		SECONDARY COIL(PLUG CAP CONNECTION)	6.3~10.3 kΩ	
SECONDARY COIL(PLUG CAP DISCONNECTION)		2.8~3.8 kΩ		
EXCITE COIL RESISTANCE VALUE(20°C)		50~200 Ω		
PLUSE GENERATOR RESISTANCE VALUE(20°C)		400~800 Ω		
<b>CHARGING SYSTEM, AC GENERATOR</b>	AC GENERATOR	TYPE	AC	
		OUTPUT	12V-11A/5,000rpm	
		CHARGING COIL RESISTANCE VALUE(20°C)	0.4~1.0 Ω	
		LIGHTING COIL RESISTANCE VALUE(20°C)	0.2~0.8 Ω	
	REGULATOR/RECTIFIER	TYPE	Semi-conductor	
		CONTROL VOLTAGE	LAMP SIDE CHARGING SIDE	12.0~14.0V/5,000rpm 13.0~15.0V/5,000rpm
	REGISTER RESISTANCE VALUE	REGISTER(6.7 Ω 5W)	6.3-7.1 Ω	

※ “( )” MARKED CONTENTS APPLY TO EUROPE ONLY.



## SERVICE INFORMATION

ITEM		STANDARD	USE LIMITS
LIGHTS, METER, SWITCHES	LIGHTS, BULBS	HEADLIGHT	12V-35/35W
		TAIL/STOP LIGHT	12V-5/21W
		WINKER LIGHTS	12V-10W × 2
		FRONT	12V-10W × 2
		REAR	12V-3W × 1
		HIGH BEAM LAMP	12V-3W × 1
		OIL LEVEL INDICATOR LAMP	12V-3.0W
		WINKER PILOTS	7A
		FUSE	12V-1.7W × 2
		METER LIGHTS	12V-4W × 1
	LICENCE LAMP		
BATTERY		TYPE	MF BATTERY
		CAPACITY	12V-3AH
		TERMINAL VOLTAGE(20°C)	13.0~13.2V
		CHARGING CURRENT/STANDARD	0.4A/5h
		CHARGING CURRENT/RAPID	4A/0.5h

## TWIST TORQUE

### ENGINE

TWIST PART	NUMBER	SCREW DIAMETER (mm)	TWIST TORQUE	REFERENCE
FLY WHEEL NUT	1	10	4.0kgf·m	
DRIVE FACE NUT	1	12	5.5kgf·m	
CYLINDER HEAD BOLT	4	6	1.0kgf·m	
SPARK PLUG	1	14	1.4kgf·m	
DRIVEN FACE NUT	1	28	5.5kgf·m	
CLUTCH OUTER NUT	1	10	4.0kgf·m	
OIL LEVEL CHECK BOLT	1	8	1.3kgf·m	
EXHAUST PIPE JOINT NUT	2	6	1.2kgf·m	
MUFFLER BRACKET BOLT	2	8	3.3kgf·m	
CRANK CASE BOLT	6	6	1.0kgf·m	

**FRAME PARTS**

TWIST PART	NUMBER	SCREW DIAMETER	TWIST TORQUE	REFERENCE
STEERING STEM LOCK NUT	1	-	7.0kgf · m	
HANDLE POST TWIST NUT	1	10	5.0kgf · m	
FRONT BRAKE LEVER PIVOT BOLT	1	6	1.0kgf · m	
FRONT BRAKE LEVER PIVOT NUT	1	6	1.0kgf · m	
REAR BRAKE LEVER PIVOT SCREW	1	5	0.3kgf · m	
REAR BRAKE LEVER PIVOT NUT	1	5	0.4kgf · m	
MASTER CYLINDER HOLDER BOLT	2	6	1.2kgf · m	
MASTER CYLINDER COVER SCREW	2	4	0.2kgf · m	
BRAKE HOSE BOLT	2	10	3.5kgf · m	
CALIPER MOUNT BOLT	2	8	2.7kgf · m	
CALIPER BREATHER VALVE	1	8	0.6kgf · m	
CALIPER PAD PIN	2	10	1.8kgf · m	
CALIPER SLIDE PIN BOLT	1	8	2.3kgf · m	
BRAKE SWITCH SCREW	1	4	0.12kgf · m	
STEERING STEM BOLT(FRONT FORK SIDE)	4	10	3.5~4.5kgf · m	
FRONT AXLE NUT	1	12	6kgf · m	
REAR AXLE NUT	1	14	11.0kgf · m	
SPEEDOMETER CABLE SETTING SCREW	1	4	0.2kgf · m	
REAR BRAKE ARM BOLT	1	6	0.6kgf · m	
FRONT BRAKE DISK BOLT	3	8	3.9kgf · m	
REAR CUSHION UPPER BOLT	1	10	4.0kgf · m	
REAR CUSHION LOWER BOLT	1	10	4.0kgf · m	
ENGINE HANGER BRACKET NUT (FRAME SIDE)	2	10	5.0kgf · m (7.3kgf · m)	
EXHAUST PIPE JOINT NUT	3	6	1.2kgf · m	
MUFFLER BRACKET BOLT	2	8	3.3kgf · m	
EXHAUST PIPE PROTECTOR SCREW	4	6	0.5kgf · m	

**STANDARD TWIST TORQUE**

TYPE	TWIST TORQUE			TYPE	TWIST TORQUE		
	N-m	kgf-m	ft-lb		N-m	kgf-m	ft-lb
5mm BOLT, NUT	5	0.5	4	5mm SCREW	4	0.4	3
6mm BOLT, NUT	10	1.0	7	6mm SCREW	9	0.9	7
8mm BOLT, NUT	21	2.1	15	6mm SCREW FLANGE BOLT, NUT	9	0.9	7
10mm BOLT, NUT	35	3.5	25	8mm SCREW FLANGE BOLT, NUT	27	2.7	20
12mm BOLT, NUT	55	5.5	40	10mm SCREW FLANGE BOLT, NUT	40	4.0	29

Bolts not appearing in the following table are tightened using standard torque.

## SERVICE INFORMATION

### SPECIALIZED TOOLS

TOOL NAME	TOOL NO.	USAGE	CHAPTER
FLOAT LEVEL GAUGE	07401-001000	Carburetor Oil Level Measurement	5
BEARING DRIVER	07945-GC80000	Change of Driven Face Outer Bearing	7
BEARING REMOVER	07936-3710300	Disassembly of Driven Face Needle Bearing	
REMOVER HANDLE	07936-3710100		
REMOVER WEIGHT	07741-0010201		
DRIVER HANDLE A	07749-0010000	Assembly of Driven Face Needle Bearing	
OUTER DRIVER 24 × 26mm	07746-0010700	Disassembly/Assembly of Clutch/Driven Face	
CLUTCH SPRING COMPRESSOR	07960-KM10000		
SOCKET WRENCH 39mm	0723-03900		
CLUTCH CENTER HOLDER	07724-0050001	Disassembly/Assembly of Driven Pulley/Driven Face	
UNIVERSAL HOLDER	07725-0030000	Disassembly/Assembly of Clutch/Driven Pulley	
CRANK ASSEMBLY	0740-00001	Assembly of Drive Shaft	9
DRIVER HANDLE A	0749-0010000	Assembly of Drive Shaft Bearing	
OUTER DRIVER 37 × 40mm	07746-0010200		
DRIVER PILOT, 17mm	07746-0040400		
UNIVERSAL BEARING PULLER	0755-00001	Disassembly of Crank Shaft Bearing	
CRANK CASE PULLER	0751-00003	Disassembly of R/L Crank Case, Crank Shaft	
CRANK ASSEMBLY	0740-00001	Disassembly of R.Crank Case, Crank Shaft	
OUTER DRIVER 52 × 55mm	07746-0010400	Assembly of Crank Shaft Bearing	
DRIVER PILOT 20mm	07746-0040500		
DRIVER HANDLE A	07749-0010000		
CRANK ASSEMBLY	0740-00001	Assembly of R/L Crank Shaft Oil Seal	
LOCK NUT WRENCH A	07916-1870101	Disassembly of Top Cone Race	10
LOCK NUT WRENCH B	07916-KM10000		
BALL RACE REMOVER	07946-GA70000	Assembly of Ball Race	
OUTER DRIVER, 42 × 47mm	07746-0010300		
DRIVER HANDLE A	07749-0010000		
SHOCK ABSORBER COMPRESSOR	07GM-0010000	Disassembly/Assembly of Rear Cushion	11
COMPRESSOR SCREW ASS' Y	079GME-0010100		
SPRING COMPRESSOR ATTACHMENT	07967-GA70102		
SPRING COMPRESSOR ATTACHMENT	07JME-GW20100		
UNIVERSAL HOLDER	07725-0030000	Disassembly/Assembly of Fly Wheel	13
A.G.G ROTOR PULLER	0750-00006	Disassembly of Fly Wheel	

# LUBRICATION OIL

## ENGINE PARTS

APPLICATION AREAS	CAUTIONARY SUGGESTIONS	OIL TYPE
CRANK CASE JOINING FACE CRANK CASE REVOLUTION PART CYLINDER BIG REVOLUTION PART, FRICTION PART		Gasket Fluid(TB 1215) Ultra-2 Super, 2-Cycle Oil (Separation Lubrication Use)
TRANSMISSION(FINAL REDUCTION)	Capacity : 0.09 l	SAE 80W/90
KICK SPINDLE BUSH STARTER PINION STARTER DRIVE GEAR OPERATION PART MOVEABLE DRIVEN FACE (DRIVEN FACE OPERATION PART)	Capacity : 5.0~5.6g	Multi-Purpose Grease
OIL PUMP DRIVE GEAR		Molybdenum Grease




## FRAME PARTS

APPLICATION AREAS	CAUTIONARY SUGGESTIONS	OIL TYPE
FRONT WHEEL DUST SEAL EDGES FRONT PIVOT ARM BUSH FRICTION FACE FRONT PIVOT ARM SEAL EDGES REAR BRAKE CAM AXLE PART, CAM PART WHOLE AREA OF REAR BRAKE CAM DUST SEAL REAR BRAKE ANCHOR PIN AXLE PART FRONT BRAKE OIL SEAL EDGES FRONT BRAKE CAM AXLE PART, CAM PART WHOLE AREA OF FRONT BRAKE CAM DUST SEAL SPEEDOMETER GEAR/PINION INSIDE DIAMETER PART, AXLE PART, GEAR TEETH PART BALL RACE, BEARING REVOLUTION PART		Multi-Purpose Grease
HANDLE GRIP INSIDE AXLE PART		Adhesives ROYAL BOND 1300














## SERVICE INFORMATION

# SYMBOLS / ABBREVIATIONS

The following symbols are used in this manual to represent job-related warnings or cautions.



SYMBOL	MEANING	SYMBOL	MEANING
 WARNING	Indicates dangerous area. Serious accident may result if instructions are not followed.	 CAUTION	Indicates important work. Minor injury or vehicle part damage may result if instructions are not followed.
		 NOTE	Indicates general safety matters. Provides safety and appropriate handling procedures.

The following symbols indicate needed lubrication steps, the changing of parts, and required specialized tools, etc. when performing maintenance.


SYMBOL	CAUTION
	Use recommended engine oil, unless otherwise specified.
	Use molybdenum oil solution (mixture of the engine oil and molybdenum grease with the ratio 1:1)
	Use multi-purpose grease (Lithium based multi-purpose grease NLG #2 or equivalent)
	Use molybdenum disulfide grease (containing more than 3% molybdenum disulfide, NLGI #2 or equivalent)
	Use molybdenum disulfide paste containing more than 40% molybdenum disulfide, NLGI #2 or equivalent)
	Use silicone grease
	Apply a locking agent. Use the agent of the middle strength, unless otherwise specified
	Apply sealant
	Replace the parts with new ones before assembly
	Use brake fluid, DOT3 or DOT4. Use the recommended brake fluid, unless otherwise specified
	Use Fork or Suspension Fluid
	Use special tool
	Use option tool. These tools are obtained as you order parts.
(⇒3-1)	Indicates reference page. (Example : Refer to page 3-1)


Special grease, etc. that do not correspond to the above are indicated without using symbols.

# WIRING DIAGRAM



# SERVICE INFORMATION







---

# MEMO

---

## 2. INSPECTIONS/ADJUSTMENTS

<b>SERVICE INFORMATION . . . . .</b>	<b>2-1</b>	<b>BRAKE FLUID . . . . .</b>	<b>2-7</b>
<b>REGULAR INSPECTION SCHEDULE . . . . .</b>	<b>2-2</b>	<b>BRAKE PAD/SHOE . . . . .</b>	<b>2-7</b>
<b>FUEL LINE (FUEL TUBE) . . . . .</b>	<b>2-3</b>	<b>BRAKE SYSTEM . . . . .</b>	<b>2-8</b>
<b>FUEL LINE FOR CLOGGING . . . . .</b>	<b>2-3</b>	<b>HEADLIGHT ADJUSTMENT . . . . .</b>	<b>2-8</b>
<b>THROTTLE GRIP OPERATION . . . . .</b>	<b>2-4</b>	<b>SIDE STAND . . . . .</b>	<b>2-9</b>
<b>AIR CLEANER . . . . .</b>	<b>2-4</b>	<b>SUSPENSION . . . . .</b>	<b>2-9</b>
<b>SPARK PLUG . . . . .</b>	<b>2-5</b>	<b>BOLTS, NUTS, FASTENERS . . . . .</b>	<b>2-9</b>
<b>CYLINDER COMPRESSION PRESSURE . . . . .</b>	<b>2-6</b>	<b>WHEELS/TIRES . . . . .</b>	<b>2-9</b>
<b>CARBURETOR IDLING . . . . .</b>	<b>2-6</b>	<b>STEERING HEAD BEARING . . . . .</b>	<b>2-10</b>
<b>AIR SCREW ADJUSTMENT . . . . .</b>	<b>2-6</b>	<b>BATTERY . . . . .</b>	<b>2-10</b>

### SERVICE INFORMATION

#### WARNING

- The exhaust gas contains poisonous substance. Do not keep engine idling in a closed or poorly ventilated place for a long period of time.

#### NOTE

- Stand the main stand prior to beginning work.

### SPECIFICATIONS

ITEM	STANDARD VALUE	REFERANCE
THROTTLE GRIP FREE PLAY	2-6mm	
SPARK PLUG	BPR6HS	
SPARK PLUG GAP	0.6 0.7mm	
CARBURETOR IDLE SPEED	2,000rpm	
CYLINDER COMPRESSION PRESSURE	12kgf/cm <sup>2</sup> (600rpm)	

### TORQUE VALUES

SPARK PLUG	1.4kgf · m
CYLINDER HEAD COVER BOLTS	1.0kgf · m

# INSPECTIONS / ADJUSTMENTS

## REGULAR INSPECTION SCHEDULE

Carry out pre-operation check at each scheduled maintenance period based on the information described in the owner's manual.

I : INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY.

R : REPLACE L : LUBRICATE C : CLEAN

ITEM	FREQUENCY	ODOMETER READING(NOTE 1)					REMARK
		x 1000Km	1	4	8	12	
		MONTH		6	12	18	
FUEL LINE(FUEL TUBE)				I	I	I	
THROTTLE GRIP OPERATION			I	I	I	I	
OIL PUMP, OIL LINE				I	I	I	
AIR CLEANER				C	C	C	NOTE 2
SPARK PLUG				I	I	I	
CARBON REMOVAL			Every 8,000 : C				
CARBURETOR IDLE SPEED			I	I	I	I	
TRANSMISSION OIL						R	
BRAKE SHOE/PAD WEAR			I	I	I	I	NOTE 3
BRAKE SYSTEM			I	I	I	I	
BRAKE STOP SWITCH			I	I	I	I	
HEADLIGHT ADJUSTMENT				I	I	I	
CLUTCH SHOE WEAR				I	I	I	
SUSPENSION				I	I	I	
BOLTS, NUTS, FASTENERS			I		I		
WHEELS/TIRES			I	I	I	I	
STEERING HEAD BEARING			I		I		
DRIVE BELT				I	I	I	
WEIGHT ROLLER				I	I	I	
SLIDE PIECE				I	I	I	
DRIVEN FACE					I		
MOVEABLE DRIVE FACE				I	I	I	

If there are no appropriate type of tools and maintenance data available, or if you do not have mechanical technology contact authorized maintenance shops, dealers or other designated repair shops for maintenance and inspections.

To ensure safety, inspections and maintenance of these parts must be carried out by authorized maintenance shops, dealers or other designated repair shops.


### NOTE

1. After the odometer reading exceeds 12,000km, repeat maintenance service at intervals indicated in the table.
2. After riding in areas with high humidity or pollution, carry out maintenance service more frequently.
3. Replace every 2 years. Proper technology is required for this job.

## FUEL LINE(FUEL TUBE)

Remove the luggage box. (⇒3-3)

Check the fuel tube of the fuel auto cock connected to the fuel tank and carburetor. If the fuel tube is cranked, damaged or leaks, replace it.




## FUEL LINE FOR CLOGGING

Check the fuel tank cap and/or fuel tank breather tube for clogging.

Visually inspect the fuel strainer for contamination.

Check the fuel flow with the fuel strainer installed and with the strainer removed.



Replace the fuel strainer if it is excessively contaminated or if the fuel flow is not smooth.



### ⚠ CAUTION

- Note the installation direction of the fuel strainer. Be sure to install it as shown in the drawing, i.e., with the cup facing down. Fuel flows even though the strainer is installed upside down, but it contaminates the inner wall of the strainer and prevents visual inspection of the strainer.

Remove the fuel valve lock nut and check the fuel strainer screen for contamination. Tighten the lock nut to the specified torque.



## THROTTLE GRIP OPERATION

Check if the throttle grip operates smoothly in any steering position

If the throttle grip does not operate properly, lubricate the throttle cable.

If the throttle grip does not operate properly, check the throttle cable for aging, damage or kinking.

Check the throttle grip free play.

**FREE PLAY : 2~6mm**

If the throttle grip doesn't move smoothly, adjust the free play.

Take off the rubber boots, loosen the lock nut, and turn the adjuster to control the free play.

After adjusting, tighten the lock nut, check the operation of grip, and then put on the rubber boots.

## AIR CLEANER

Loosen the 5 setting screw assembled to the air cleaner case cover, and then remove the air cleaner case cover.

Remove the air cleaner element.


Wash away any accumulated dust or dirt, by gently squeezing it in non flammable or high flash point solvent.

### ⚠ WARNING

- Using gasoline or low flash point solvents for cleaning parts may result in a fire or explosion.

### ⚠ CAUTION

- Cleaning the element with gasoline or any acid, alkaline, or organic, volatile type oil may cause improper ignition, deterioration of the element, or a loosening of the element adhesive.



Be sure to allow the element to dry thoroughly before applying oil. Otherwise, the oil will be diluted by the water and the filtering ability of the filter will be much less effective. Spread clean #80~90 gear oil on the element, rubbing in thoroughly over the surface with both hands, and then squeeze out any excess oil.

**CAUTION**

- Using air filter oil when riding in extremely dusty conditions prevents premature engine wear due to dust/dirt drawn into the engine. Apply air filter oil to the entire surface of the element and rub it with both hands to saturate the element with oil. Squeeze out excess oil.




## SPARK PLUG

Remove the plug maintenance cover. Remove the spark plug cap and disassemble the plug.


Check the plug for damage, contamination or deposits. If the spark plugs are severely contaminated or damaged, replace with new ones. If the plugs can be reused after removing only the carbon, use plug cleaner and wire brush to clean the plugs. Always use a feeler gauge to check the gap.

**SPARK PLUG GAP : 0.6~0.7mm**



**CAUTION**



- Make sure there is no dirt or debris on the seat of the spark plug hole before inserting the spark plug.
- To prevent damage to the cylinder head, hand-tighten the spark plug before using a wrench to tighten to the specified torque. (torque : 14kgf · m)
- Do not over-tighten the spark plug.



Spark plug specification change

HIGH SPEED	STANDARD	LOW SPEED
BPR7HS	BPR6HS	BR4HSA

The specification changes according to the speed.



## CYLINDER COMPRESSION PRESSURE

Start and warm up the engine.  
Remove the plug maintenance cover.  
Stop engine, and remove the spark plug cap and spark plug.  
Install a compression gauge.  
Open the throttle completely, and crank the engine with the starter motor until the gauge reading rising.

### ⚠ CAUTION

- Fix the vehicle securely.
- Cut off the engine, and lock the high pressure cable.
- While the engine is hot, pay attention not to get burned.

### ⚠ NOTE

- The maximum reading is usually reached within 4~7 seconds

**COMPRESSION PRESSURE : 10.0kg/cm<sup>2</sup> (600rpm)**

If the pressure is low, check the following:

- Leakage from the cylinder head gasket
- Piston/cylinder worn

If pressure is high, check the following:

- Carbon deposits on the piston head, and cylinder head.

**TOOL : COMPRESSION GAUGE**

## CARBURETOR IDLING


Stand the vehicle on the main stand.  
Heat the engine to make accurate idling inspection and adjustment.  
Verify all engine adjustments satisfy specifications.  
Make adjustments, if necessary.  
Turn the throttle stop screw and make adjustments to prescribed idling speed.

**STANDARD RPM: 2,000rpm**

## AIR SCREW ADJUSTMENT


### ⚠ NOTE

- The air screw is factory pre-set. Adjustment is not necessary unless the carburetor is overhauled or a new air screw is installed.
- Tightening the air screw against its seat will damage the seat.



Turn the air screw clockwise until it seats lightly then back it out to the specification given. This is an initial setting prior to the final air screw adjustment.

Rev the engine up slightly from the idle speed and make sure that engine speed rises and returns smoothly. Adjust by turning the air screw in or out within a 1/4 turn if necessary. If the engine cannot be adjusted by turning the air screw within a 1/4 turn, check for other engine problems.



## BRAKE FLUID


Remove the brake fluid cover.

Check the oil level inside the front brake reservoir. If the oil level is near the lower limit line, remove the reservoir diaphragm and fill DOT 3 and DOT 4 brake fluid to the top limit line.

If the brake fluid reaches the lower limit line, check the entire brake system for leaks.

### ⚠ CAUTION

- Brake fluid will damage painted, plastic or rubber parts.
- Mixing incompatible fluids can impair braking efficiency.
- Foreign materials can clog the system, causing a reduction or complete loss of braking ability.
- A leak in the brake system can lead to reduced braking efficiency and possible loss of braking ability.



## BRAKE PAD/SHOE


### BRAKE PAD REPLACEMENT

Check the brake pads for wear.

If the red mark on the pad reaches the brake disc, replace the pads.

### ⚠ NOTE


- Replace the brake pads in sets.



### BRAKE SHOE REPLACEMENT


If the arrow mark of the wear limit aligns with the ‘ ’ mark when the rear brake lever is fully pressed, it indicates the brake lining has reached the service limit. Replace the brake shoes.





## BRAKE SYSTEM

Check the front brake hose for cracks or damage. If any leaks are found, replace immediately.  
Check the brake rod for looseness or damage, and replace it if necessary.



## BRAKE LEVER FREE PLAY


Check the free play after pulling the lever.

**FRONT : 10~20mm**  
**REAR : 10~20mm**



## REAR BRAKE FREE PLAY ADJUSTMENT

Turn the adjuster nut to adjust the free play.  
After initial adjustment, check the operation of the rear brake light switch. Make additional adjustments, if necessary.




## HEADLIGHT ADJUSTMENT

Adjust the headlight beam level by operating the adjusting screw located on the upper side of the front fender.

### ⚠ NOTE

- Adjust the beam level according to local laws and regulations.
- Improper beam level adjustment may blind oncoming drivers, or may incorrectly light the road ahead.



## SIDE STAND

- Erect the main stand.
- Pull the lower end of the side stand, and see if it moves freely.
- If the side stand does not move smoothly, apply grease to the pivot area.
- If the side stand moves too freely, check the side stand spring.
- Check the axial movement of the side stand.




## SUSPENSION

### ⚠ NOTE

- Do not ride motor cycle with an unsatisfactory suspension. Loose or worn suspension parts will lead to deterioration in the vehicle's safety and operation efficiency.

### FRONT WHEEL

- Hold the brake lever, and compress the front cushion up and down several times to check the operating conditions.
- Check the front fork for oil leakage, parts damage or looseness.




### REAR WHEEL

- Compress the rear cushion up and down several times to check the operating conditions.
- Check the rear fork for oil leakage, parts damage or looseness.

## BOLTS, NUTS, FASTENERS

- Check all nuts and bolts of the frame during the regular maintenance to check if they meet the prescribed torque value.
- Check all pins, clips, hose clamps and cable stays.



## WHEELS/TIRES


### ⚠ NOTE

- Check the tire pressure when the tires have been cooled off. Check the tread (the part making contact with the road surface) and side for wear, cracks or damage. Replace damaged tires.

### STANDARD PRESSURE

kgf/cm<sup>2</sup>

ITEM	FRONT WHEEL	REAR WHEEL
DRIVER ONLY	1.25	2.00
DRIVER AND A PASSENGER	1.25	2.00



Check the tread depth at the tire center.  
If the tread depth has reached the service limit, replace the tire.




## STEERING HEAD BEARING

### ⚠ NOTE

- Check the cable if it interferes with the handle operation.


Lift the front wheel and check if the handle moves right and left smoothly. If the handles move heavily, check if the cable or electric cord interferes with the handle. If the handle moves satisfactorily, adjust the steering head bearing.



## BATTERY

Remove a special screw securing the battery cover from the floor panel.  
Check if the terminal is loose.  
If the terminal is loose, check and clean the contacting surface and then tighten it.  
Apply grease thinly after tightening.  
If the terminal is rusted, remove the battery, pour warm water and clean with the wire brush.

- FULL CHARGING VOLTAGE : 13.0~13.2V
- LOW CHARGING VOLTAGE : LESS THAN 12.3V



### ⚠ NOTE

- Check the charging condition using the voltmeter.
- Pay attention not to transform the battery terminal.
- Never remove the filler cap.

---

## 3. EXTERNAL PARTS

<b>SERVICE INFORMATION . . . . .</b>	<b>3-1</b>	<b>FLOOR PANEL . . . . .</b>	<b>3-4</b>
<b>MAINTENANCE PRECEDURE . . . . .</b>	<b>3-2</b>	<b>FRONT COVER . . . . .</b>	<b>3-5</b>
<b>LUGGAGE BOX . . . . .</b>	<b>3-3</b>	<b>FRONT FENDER . . . . .</b>	<b>3-5</b>
<b>BATTERY MAINTENCE LID . . . . .</b>	<b>3-3</b>	<b>INNER COVER . . . . .</b>	<b>3-5</b>
<b>CENTER COVER . . . . .</b>	<b>3-3</b>	<b>FRONT UNDER COVER . . . . .</b>	<b>3-6</b>
<b>REAR CARRIER . . . . .</b>	<b>3-3</b>	<b>FRONT HANDLE COVER . . . . .</b>	<b>3-6</b>
<b>BODY COVER . . . . .</b>	<b>3-3</b>	<b>REAR HANDLE COVER . . . . .</b>	<b>3-6</b>
<b>REAR FENDER . . . . .</b>	<b>3-3</b>	<b>MUFFLER SEPARATION . . . . .</b>	<b>3-7</b>
<b>FLOOR SIDE COVER . . . . .</b>	<b>3-4</b>		

## SERVICE INFORMATION


 **NOTE**

This section describes external parts removal/installation.  
Do not apply unreasonable force when disassembling covers, to prevent possible damage.  
A muffler is hot. Do not service it immediately after the engine is stopped.


# EXTERNAL PARTS

## MAINTENANCE PROCEDURE

### NAMES OF FRAME COVERS



This chart shows arrows connected in the order of disassembling covers.



## LUGGAGE BOX

Loosen 3 washer bolts and 2 flange bolts.  
Remove the oil tank cap and the fuel tank cap.

**NOTE**

- Luggage box can be removed with the seat.

Remove the luggage box.  
Install in the reverse order of removal.

**CAUTION**

- Install the oil tank cap and the fuel tank cap temporarily to prevent the foreign material from entering after removing the luggage box.

## BATTERY MAINTENANCE LID

Loosen 1 special screw and remove maintenance cover.

## CENTER COVER

Loosen 2 tapping screw securing the floor panel.  
Loosen 2 special screw (R/L) securing the body cover.  
Remove the center cover.

**CAUTION**

- If removal is difficult, recheck each connection and then try removing again.





Install in the reverse order of removal.

## REAR CARRIER

Open the seat  
Loosen 2 washer bolts securing luggage box and 2  
Flange bolts securing body cover.  
Remove the rear carrier.  
Install in the reverse order of removal.

**CAUTION**

- Pay attention not to break or damage the rear carrier when installing or removing.



## EXTERNAL PARTS



### BODY COVER

- Remove the luggage box. (⇒3-3)
- Remove the center cover. (⇒3-3)
- Remove the rear carrier. (⇒3-3)
- Loosen 2 special screw (R/L) securing the frame body.
- Loosen 2 special screw securing rear fender.
- Remove seat lock cable.
- Remove tail light, coupler of winker.
- Remove the body cover.
- Install in the reverse order of removal.




### REAR FENDER

- Luggage box. (⇒3-3)
- Center cover. (⇒3-3)
- Rear carrier. (⇒3-3)
- Body cover. (⇒3-4)
- Remove the 2 washer bolts securing frame body.
- Draw the rear part of the rear fender from the bracket in the frame.
- Loosen the rear cushion under bolt, remove the rear fender.

#### ⚠ CAUTION


- If removal is difficult, recheck each connection and try removing again.

Install in the reverse order of removal.



### FLOOR SIDE COVER

- Loosen the 2 washer screw located in the side of the R,L floor side cover.
- Pull the front part of the floor side cover to remove the floor panel.
- Remove the floor side cover.
- Install in the reverse order of removal.



### FLOOR PANEL

- Remove the plug maintenance cover. (⇒3-3 )
- Remove the center cover. (⇒3-3)
- Loosen the tapping screw securing the battery cover to remove the battery cover.
- Disconnect the battery wire to remove the battery and loosen 1 washer bolt.
- Remove the CDI, winker relay coupler, fuse.
- Loosen the 2 washer bolts securing the floor panel.



Remove the floor panel from the connecting groove of the inner box by lifting the rear part of the panel slightly.

Draw the floor panel moving it to the right and left to remove it.

Install in the reverse order of removal.

## FRONT COVER

Loosen the upper cover set screws (R/L) securing the inner box.


Loosen the upper cover set screws (R/L) securing the front under cover.

Loosen the special bolt securing the front of the front cover.

Draw the upper part of the front cover to remove it.

Disconnect the head light wiring and remove the front cover.

Install in the reverse order of removal.



### NOTE

- Check for proper alignment of the connection (hook) before performing installation.

## FRONT FENDER

Loosen the special screw (R/L) securing the front fork.

Remove the front fender.

Install in the reverse order of removal.



## INNER COVER

Remove the center cover. (⇒3-3)

Remove the floor side cover. (⇒3-4)


Remove the floor panel. (⇒3-4)

Remove the front cover. (⇒3-5)



Loosen the tapping screws (R/L) securing the front under cover.

Loosen the 1 set screw securing bag holder.

Install in the reverse order of removal.







## FRONT UNDER COVER

- Remove the front cover. (⇒3-5)
- Remove the inner box. (⇒3-5)
- Remove the front fender. (⇒3-5)
- Remove the front wheel. (⇒10-5)
- Loosen the flange bolts securing the lower end of the inner cover.
- Remove the front under cover.
- Install in the reverse order of removal.

### NOTE

- Pay attention not to turn over the vehicle.

## FRONT HANDLE COVER




- Remove the back mirror.
- Remove the master cylinder seal.
- Loosen the 2 tapping screws securing the rear handle cover.
- Remove the front handle cover while pull the cover to the front slightly.
- Install in the reverse order of removal.

## REAR HANDLE COVER

- Remove the back mirror.
- Remove the front handle cover. (⇒3-6)
- Remove the speedometer cable from the meter.
- Loosen the 2 tapping screws securing the steering handle comp.
- Disconnect the right and left switch wiring.
- Remove the speedometer and rear handle cover from the steering handle.
- Disconnect the right and left switch.
- Loosen the 3 tapping screws securing the speedometer and the rear handle cover.
- Remove the rear handle cover.
- Install in the reverse order of removal.

### NOTE

- Check each switch for proper operation after installation.
- Wires and cables must be connected properly.



## MUFFLER

### EX. PIPE REMOVAL

Loosen the 2 flange bolts securing the SAI reed valve ass'y.

Loosen 1 flange nut and 1 special nut securing the cylinder comp.

Loosen 2 flange bolts securing the RH. crank case.

Remove the EX. pipe by drawing it to the ground.

Install in the reverse order of removal.

#### ⚠ WARNING

- Never perform the maintenance of the muffler right after stopping the vehicle because the muffler is extremely hot

### MUFFLER COMP

Loosen the 3 flange nuts securing the exhaust pipe comp.

Loosen 2 flange bolts securing the RH. crank case.

Install in the reverse order of removal.

**TIGHTENING TORQUE OF THE RH. CRANKCASE**  
: 3.3kgf · m

#### ⚠ CAUTION

- When installing the gasket, replace it with the new one.
- Check to see if there is any evacuation after installing the muffler.

### S.A.I PIPE

Remove 2 flange bolts securing the exhaust muffler ass'y.


Remove the upper flange bolt securing the muffler comp.

Remove the hose clip and tube.

Install in the reverse order of removal.

## EXTERNAL PARTS

---



### AIR FILTER ASS'Y SECONDARY

Remove the seat.  
Remove the luggage box.  
Remove the hose clip and the hose.  
Install in the reverse order of removal.


---

# MEMO

---

# LUBRICATION SYSTEM

---



---

## 4. LUBRICATION SYSTEM

<b>SERVICE INFORMATION . . . .</b>	<b>4-1</b>	<b>OIL PUMP BLEEDING . . . . .</b>	<b>4-4</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>4-1</b>	<b>OIL PUMP, TUBE INSPECTION . .</b>	<b>4-5</b>
<b>OIL SYSTEM DRAWING . . . .</b>	<b>4-2</b>	<b>OIL PASS, TUBE INSPECTION . .</b>	<b>4-5</b>
<b>OIL PUMP DISASSEMBLY/ ASSEMBLY . . . . .</b>	<b>4-3</b>	<b>ENGINE OIL LEVEL INSPECTION .</b>	<b>4-6</b>
<b>OIL PUMP INSPECTION . . . .</b>	<b>4-3</b>	<b>TRANSMISSION OIL INSPECTION .</b>	<b>4-7</b>
<b>OIL PUMP ADJUSTMENT . . .</b>	<b>4-4</b>	<b>OIL TANK DISASSEMBLY . . .</b>	<b>4-7</b>

### SERVICE INFORMATION



- Remove air from oil tube and oil pump if the oil tube is taken off or if air enters the oil tube.

If the oil tube is disassembled, remove the air in the oil pass tube.  
Maintenance on the oil pump is done without the engine being removed from the vehicle.  
When disassembling the oil pump, do not allow foreign substances from entering the engine or oil pump.  
Do not disassemble the oil pump assembly.  
If the oil tube is disassembled, place a tube clip or band on the oil tube to prevent oil from leaking out.

### TROUBLESHOOTING


#### Overheating or engine clogging

- Faulty adjustment of oil pump(insufficient amount pumped).
- Bad quality of engine oil.
- Engine oil not being injected or blocked, bent strainer screen or oil tube.
- Entering of air in oil tube system.
- Faulty oil pump.
- Engine oil not being supplied from oil tank.
  - Blocked oil tank cap air hole
  - Blocked oil strainer screen


#### Excess exhaust smoke, accumulation of carbon on spark plug

- Faulty adjustment of oil pump(over-pumped amount).
- Bad quality of engine oil.

# OIL SYSTEM DRAWING






## OIL PUMP DISASSEMBLY/ASSEMBLY



- Remove the luggage box.
- Remove the air cleaner.
- Remove the 2 bolts of oil pump cable stay.
- Remove oil tube on the side of oil pump.
- Remove oil pass tube.
- Remove setting plate of oil pump.
- Remove oil pump.
- Install in the reverse order of removal.

### ⚠ CAUTION

- When assembling/disassembling the oil pump, do not allow foreign substances from entering the engine and oil tube by cleaning around the oil pump.
- If the air enters into the oil line, it may cause faulty lubrication or engine sticking. Always remove the air in the oil line after maintenance.
- Pay attention not to damage the O-ring when assembling the oil pump.






## OIL PUMP INSPECTION/ADJUSTMENT

- Remove the oil pump.
- Rotate the shaft and check for proper rotation.
- Check the gear for wear, damage and leak of each seal.
- If the oil comes out from the outlet of the oil pump after connecting the oil tube (which is connecting between the tank and the oil pump) to the inlet and rotating the shaft in the driving direction, consider the oil pump is in good condition.



# LUBRICATION SYSTEM



## ADJUSTMENT

### ⚠ CAUTION

- Perform after inspection and adjustment of throttle cable.

Check to see if the matching mark of the oil pump body and control lever are aligned in a state where the throttle grip is completely rotated.

Adjustment is performed by loosening the oil pump control cable lock nut and turning the control nut.

While the engine is running, slightly open the throttle and check to see if the control lever operates together with the increase in engine rpms.

### ⚠ CAUTION

- Do not adjust the control lever matching mark to the closed side of the oil pump body matching mark. If this is done, the amount of pumped oil is reduced, negatively affecting the engine.
- Make sure that the open axis stays within an 1mm sphere.

The following occurs when the oil pump is adjusted incorrectly.

- When the oil pump lever is excessively opened :  
Emitting of white exhaust gas or starting problems.
- When the oil pump lever is insufficiently opened :  
Clogging of engine.


### ⚠ NOTE

- If the oil pump cable stay bolt is removed, apply the screw locking compound to the bolt thread.

## OIL PUMP BLEEDING


### ⚠ CAUTION

- Air infiltration in the oil pass may cause the engine sticking. Always remove the air in the oil pass after maintenance.
- When disassembling the oil tube, air can be enter into the oil tube and the oil pump because of the oil leaking in the oil tube. Remove the air completely.
- Do not allow foreign substances from entering the oil pass.




## OIL PUMP/OIL TUBE


Fill the oil tank with engine oil.  
Cap around the oil pump and the carburetor with dry cloth.  
Locate the end of the oil tube in the level lower than the oil tank and drain the oil to bleed the air.  
Install the oil tube in the oil pump.



Incline the oil pump to locate the oil pump shaft at the angle of 45° from the “ ” mark with oil tube connected.




In this state, locate the oil pump in the level lower than the oil tank and drain the oil to bleed the air.  
Install the oil pump shaft in the oil pump after completing the bleeding.  
Install the oil pump in the crankcase.



## OIL PASS TUBE

Bend the oil pass tube in the “U” shape, keep the two ends parallel with each other and fill the oil pass tube with the oil.

# LUBRICATION SYSTEM



Connect the oil pump and then the carburetor quickly with the both ends of the tube pressed to avoid the air from entering.

**NOTE**

- Make sure that the tubes are arranged correctly.

Start the engine.

**NOTE**

- Do not start the engine in the poorly-ventilated area.

Open the oil pump control level fully and idle for 2minutes to bleed the air remained in the oil pass tube with the oil drained from the oil pump.


**NOTE**

- Do not increase the engine RPM more than required.

Connect the oil control cable.

**NOTE**


- Adjust the oil pump if the adjustment nut of the oil control lever is loose.



## ENGINE OIL LEVEL INSPECTION

Check the engine oil level if the pilot lamp blinks when the main switch is turned on.

**LOW OIL WARNING LIGHT BLINKING LEVEL : 0.15 l**



Remove the oil tank cap and fill the oil tank with oil to the level of the projected portion

**RECOMMENDED OIL : ULTRA 2 SUPER OIL**


Reinstall the oil tank cap and check to see if the pilot lamp turns off when the main switch is turned on.

## TRANSMISSION OIL INSPECTION

Check the body and the connection of each engine component for any leak.

Remove the oil check bolt and check to see if the oil overflows from the oil check hole.

If only the small amount of oil overflows, fill the recommended transmission oil through the oil filler hole gradually.



### ⚠ NOTE

- Oil level inspection must be performed in the flat ground with the vehicle being straight by raising the main stand.

### RECOMMENDED OIL : SAE 80W / 90

Tighten the oil level check bolt.

### TIGHTENING TORQUE : 1.3kgf · m

Start the engine and check for leak.

## OIL TANK DISASSEMBLY

Remove the luggage box.

Remove the body cover.

Loosen 2 flange bolts securing fuel tank and seatcatch.  
Loosen 2 washer bolts of setting stay securing luggage carrier.

Remove the switch connector of oil tank and the tube on the side of oil pump.

Remove the oil level switch connector.

Remove the tube on the side of oil pump.




Install the tube clip or the valve in the oil tube to avoid the oil from leaking.

Remove the flange bolt securing the oil tank and press the left and lower rear fender to remove the oil tank.

Drain the oil from the oil tank.

Remove the oil level switch.

Remove the oil strainer.



## INSPECTION

Check the oil level switch and the oil tube for proper installation.


Install in the reverse order of removal.

### ⚠ CAUTION

- If the oil enters into the oil pass, it may cause abnormal lubrication or engine sticking. Always remove the air in the oil pass after maintenance.
- Make sure that the oil tube is connected properly.
- Drain the oil in the clean container.
- Install the oil strainer after cleaning it.

# FUEL SYSTEM

---



# 5. FUEL SYSTEM

<b>SERVICE INFORMATION . . . . .</b>	<b>5-1</b>	<b>CARBURETOR CLEANING . . . . .</b>	<b>5-6</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>5-2</b>	<b>CARBURETOR INSPECTION . . . . .</b>	<b>5-6</b>
<b>IDLING ADJUSTMENT . . . . .</b>	<b>5-2</b>	<b>THROTTLE VALVE</b>	
<b>FUEL TANK . . . . .</b>	<b>5-3</b>	<b>REMOVAL/INSTALLATION . . . . .</b>	<b>5-7</b>
<b>AIR CLEANER DISASSEMBLE . . . . .</b>	<b>5-4</b>	<b>FUEL AUTOCOCK</b>	
<b>AIR CLEANER ELEMENT</b>		<b>REMOVAL/INSTALLATION . . . . .</b>	<b>5-8</b>
<b>DISASSEMBLY . . . . .</b>	<b>5-4</b>	<b>INLET PIPE REED VALVE</b>	
<b>CARBURETOR REMOVAL/</b>		<b>REMOVAL/INSTALLATION . . . . .</b>	<b>5-9</b>
<b>INSTALLATION . . . . .</b>	<b>5-5</b>	<b>REED VALVE INSPECTION . . . . .</b>	<b>5-9</b>
<b>FLOOT CAAMBER/FLOOT JET</b>			
<b>REMOVAL/INSTALLATION . . . . .</b>	<b>5-5</b>		

## SERVICE INFORMATION

### GENERAL SAFETY

**⚠ WARNING**

Gasoline is extremely flammable. Avoid fire in the work place, also paying particular attention to sparks. Furthermore, the evaporated (gasified) gasoline is highly explosive. Work in a well-ventilated areas.  
 Exhaust gas contains poisonous substance. Do not keep engine running for a long period of time in a closed, or poorly ventilated area.

**⚠ CAUTION**

Do not excessively bend or twist cable. Distorted or damaged cable may lead to mechanical malfunctions.  
 Pay particular attention to the position of O-ring. Replace with new ones when disassembled.  
 If it is desired to store a vehicle for a period longer than 3 weeks, drain gasoline out of the carburetor float chamber. Gasoline left in the float chamber will be deteriorated causing the slow jet to be clogged with deposits, and idling may become unstable.

### SPECIFICATIONS

FUEL TANK CAPACITY : 4.8 l

### CARBURETOR

ITEM	STANDARD	ITEM	STANDARD
TYPE/THROTTLE BORE	PA35	PILOT SCREW OPENING	1 1/2(1 1/8)
VENTURI DIAMETER	14mm	FLOAT LEVEL	12.2
MAIN JET No.	#77(#65)	IDLING SPEED	2,000rpm
SLOW JET No.	#38(#35)	THROTTLE GRIP FREE PLAY	2-6mm

※“( )” MARKED CONTENTS APPLY TO EUROPE ONLY.

### TOOL

FLOAT LEVEL GAUGE

## TROUBLESHOOTING

### The vehicle does not start.

- No gasoline in fuel tank.
- Fuel is not coming out of carburetor.
- Too much fuel is flowing into cylinder.
- No spark emitted from spark plug.
- Air cleaner is blocked.
- Suction system is experiencing secondary intake of air.
- Using low quality gasoline.
- Starter is damaged.
- Throttle cable is working improperly.
- Fuel tank is functioning improperly.

### Idle is unstable and engine turns off after starting.

- Starter is damaged.
- Ignition system is damaged.
- Using low quality gasoline.
- Suction system is experiencing secondary intake of air.
- Idle is adjusted improperly.
- Air screw is adjusted improperly.
- Compression pressure is low.
- Air/Fuel mixture is either too lean or rich.
- Carburetor is blocked.

### Mis-firing occurs when driving at high speeds.

- Ignition system is damaged.
- Mixture is too lean.

### Back firing

- Ignition system is damaged.
- Mixture is too lean.

### Insufficient power and high fuel consumption.

- Air cleaner is blocked.
- Ignition system is damaged.
- Mixture is too rich.

### Air/Fuel mixture is extremely lean

- Fuel jet is blocked.
- Float valve is damaged.
- Oil level is low.
- Bad ventilation of air in tank cap.
- Fuel strainer screen is blocked.
- Fuel tube is bent, creased or blocked.
- Suction system is receiving secondary suction of air.

### Air/Fuel mixture is extremely rich.

- Air jet is blocked.
- Float valve is damaged.
- Oil level is too high.
- Starter is damaged.
- Air cleaner is blocked.

## IDLING ADJUSTMENT

Travel the vehicle 2~3km under the speed of 50km/h to stabilize the combustion on normal temperature.

Set the main stand on an even place to secure the safety.

Turn the stop screw to adjust the idling speed to 2,000rpm.

Turn the air screw as 1/4 turn to find the highest engine rpm and adjust it to 2,000rpm.





※Turning the air screw right-hand, the fuel will get thicker, and turning left-side, it will be thinner.

As engine speed is set to 2,000rpm by use of air screw, lower the idling speed 20~50rpm.

(Standard air screw: 1 1/2 turn back)

Slightly snap 2~3 times, and set to 2,000rpm by use of the stop screw.

Slightly snap 2~3 times again to increase the stability and smooth the restarting, and complete the adjustment as 1,800~2,000rpm.



## FUEL TANK REMOVAL

### ⚠ WARNING

- Gasoline is extremely flammable. Avoid fire during work, and pay particular attention to electric sparks. Furthermore, the evaporated (gasified) gasoline is highly explosive. Work in a well-ventilated areas.

Remove the following parts.

Luggage box. (⇒3-3)

Plug maintenance lid.(⇒3-3)

Center cover. (⇒3-3)

Rear carrier. (⇒3-3)

Body cover. (⇒3-3)


Remove the fuel tube from the fuel auto cock.

### ⚠ NOTE

- Use the tube clip or the cap to prevent the gasoline from leaking.



## FUEL SYSTEM



- Remove the fuel unit wire coupler.
- Remove the rear fender. (⇒3-7)
- Loosen the 2 flange bolts and remove the seat catch.
- Loosen the 2 flange bolts and remove the fuel tank support stay.
- Loosen the 2 flange bolts and remove the fuel tank.

### INSTALLATION

Install in the reverse order of removal.

#### ⚠ NOTE

- Check for gasoline leakage.
- Gasoline mark is on the fuel tank cap.
- Check this mark when filling gasoline.



WASHER BOLT

### AIR CLEANER ELEMENT DISASSEMBLY


- Loosen the 5 air cleaner cover washer screws.
- Remove the air cleaner cover.
- Remove the air cleaner element.
- Install in the reverse order of disassembly.



AIR CLEANER ELEMENT

### AIR CLEANER REMOVAL

- Loosen the air cleaner connecting bend screw pin.
- Loosen the 2 bottom air cleaner washer bolts.
- Loosen the top rear fender flange bolt.
- Remove the air cleaner from the carburetor.
- Install in the reverse order of removal.




CARBURETOR

### CARBURETOR REMOVAL/INSTALLATION

#### ⚠ NOTE

- Keep the fire away.
- Open the drain screw to drain the gasoline in the carburetor chamber.



- Remove the luggage box. (⇒3-3)
- Remove the plug maintenance cover. (⇒3-3)
- Remove the center cover. (⇒3-3)
- Remove the air cleaner. (⇒5-4)
- Remove the wiring coupler of the auto by starter.
- Remove the oil pass tube.
- Remove the throttle valve set.
- Remove the 2 flange bolts securing the inlet pipe.
- Remove the carburetor insulator.
- Remove the carburetor.
- Install in the reverse order of removal.

**NOTE**



- Install the carburetor after aligning the throttle valve cutaway and the throttle stop screw.
- Tighten the top set correctly so that it is not released.

## CARBURETOR DISASSEMBLY/ASSEMBLY

- Remove the auto by starter cover.
- Loosen the 2 washer screws
- Remove the auto by starter set plate.
- Remove the auto by starter.
- Remove the auto by starter O-ring.
- Assemble in the reverse order of disassembly.


**NOTE**

- Install the auto by starter in the carburetor body after applying grease to the starter O-ring and then tighten firmly with set plate piece.



## FLOAT CHAMBER/FLOAT/JET DISASSEMBLY/ASSEMBLY

- Loosen the 2 float chamber screws.




## INSPECTION

Check the float valves and seats for cracks or damage.  
 Check the float valve operation.  
 Check the float valve level.

**FLOAT LEVEL : 8mm**

Remove the main jet, needle jet holder, and needle jet, and remove the slow jet.  
 Remove the air screw, spring, washer, O-ring.  
 Remove the throttle stop screw, spring, O-ring.



## CARBURETOR CLEANING

After removing all parts, blow open air and fuel passages in the carburetor body with compressed air.


**CAUTION**

- Cleaning the air and fuel passages with a piece of wire will damage the carburetor body or fuel pump.

Assemble in the reverse order of disassembly.


**CAUTION**

- Tightening air screw against its seat will damage the seat.



**NOTE**

- Be sure to install the needle jet with the smaller hole toward the float chamber.
- Install the air screw and its O-ring and washer in the order as shown in the drawing. If the air screw and carburetor body are replaced with the new ones, adjustment is necessary.




## CARBURETOR INSPECTION


Connect an ohmmeter to the auto bystarter wire connector terminals and measure the resistance. If the resistance is greatly out of specification, it indicates a faulty PTC in the auto bystarter. Replace the auto bystarter.

**NOTE**


- The auto by starter might be normal if the resistance is only slightly out of specification. However, be sure to check all related parts for trouble.
- Refer to the Model Specific manual for specified resistance.




Remove the carburetor and let it cool down for 30 minutes. Insert a vinyl tube into the fuel enriching circuit and blow into the tube. Air should flow into the circuit. If air does not flow into the circuit, replace the auto bystarter.



Connect the battery to the auto bystarter terminals and wait for 5 minutes. Insert a vinyl tube into the fuel enriching circuit and blow into the tube. Air should not flow into the circuit. If air flows into the circuit, replace the auto bystarter.







Check the resistor if the auto bystarter is normal but engine is still hard to start. If there is a broken wire in the resistor, current will not flow to the PTC and the auto bystarter will not operate. If there is a shorted wire in the resistor, current of a higher voltage than specified will reach the PTC. This will cause the fuel enriching circuit to close too soon, and starting will be difficult.



## THROTTLE VALVE DISASSEMBLY

Remove the throttle valve.  
Remove the throttle cable.  
Remove the throttle valve spring.  
Remove the needle clip.  
Remove the seal cap.  
Remove the clip.  
Remove the jet needle.



## ASSEMBLY

Install the jet needle into the throttle valve and secure with the retainer.

Route the throttle cable through the spring and compress the spring fully.

Attach the throttle cable end to the bottom of the throttle valve and thread the throttle cable through the slot in the valve.

Align the cutout in the throttle valve with the throttle stop screw on the carburetor body and install the valve on the carburetor.

### NOTE

- Be sure that the throttle valve cutaway is toward the air cleaner case side as it determines the volume of air for fuel mixture.

Operate the valve after installing the throttle valve.

## FUEL AUTO COCK

### REMOVAL/INSTALLATION

Remove the luggage box. (⇨3-3)

Remove the plug maintenance cover. (⇨3-3)

Remove the center cover. (⇨3-3)

Remove the rear carrier. (⇨3-3)

Remove the body cover. (⇨3-3)

Remove the fuel tube A, B connected to the carburetor.

Remove the inlet pipe negative pressure tube.

Remove the fuel tube A, B connected to the fuel tank.

Remove the flange bolt securing the fuel auto cock and the frame.

Remove the fuel auto cock.

Install in the reverse order of removal.

### CAUTION

- Be sure to remove the diaphragms from the fuel auto valve before using compressed air to blow out the air passages. Compressed air will damage the diaphragms or may force them off the aluminum


Disconnect the fuel line and place it in a clean container as shown.

### NOTE

- Place a clean container under the fuel tube.
- Refer to the Model Specific manual for replacement.

Connect the fuel auto valve vacuum tube to the vacuum pump and apply vacuum. Be sure that the fuel flows out smoothly. If the vacuum does not remain steady, it indicates the diaphragm is incorrectly installed or damaged. If the vacuum remains steady, but the fuel flow is not smooth, it indicates a clogged filter or incorrectly installed diaphragm.

If the fuel flows without the vacuum applied, the diaphragm is incorrectly installed.



## INLET PIPE REED VALVE

### REMOVAL/INSTALLATION

- Remove the luggage box. (⇨3-3)
- Remove the air cleaner. (⇨5-4)
- Remove the carburetor. (⇨5-4)
- Remove the negative pressure tube connected to the inlet pipe.
- Remove the oil pump cable. (⇨4-3)
- Remove the fan cover and shroud.
- Remove the inlet pipe securing 4 flange bolts connected to the L crank case.
- Remove the inlet pipe.
- Remove the reed valve.
- Install in the reverse order of removal.



### INSPECTION


- Check the reed valve for fatigue or damage and replace the reed valve assembly if necessary.
- Check the reed valve seat for cracks, damage and clearance from the reed and replace the reed valve assembly if necessary.

#### ⚠ NOTE

- Be sure to replace the reed valve as an assembly. Disassembling or bending the reed stopper will cause engine trouble.

# ENGINE REMOVAL/INSTALLATION

---



---

# 6. ENGINE REMOVAL/INSTALLATION

SERVICE INFORMATION . . . . .	6-1
ENGINE REMOVAL/INSTALLATION . . . . .	6-2

## SERVICE INFORMATION

### GENERAL SAFETY

 NOTE

- Use a jack to remove or install the engine. Support the motorcycle with a jack firmly, taking precautions not to damage the frame, engine, cable or harness.
- Attach tape to the frame to protect it during the engine removal or installation.

The following works can be carried out without removing the engine from the vehicle body.

- TRANSMISSION (⇒SECTION 9)
- A.C. GENERATOR (⇒SECTION 13)
- KICK STARTER/ CONTINUOUSLY VARIABLE TRANSMISSION (⇒SECTION 7)
- CYLINDER HEAD/ CYLINDER/ PISTON (⇒SECTION 8)
- CARBURETOR (⇒SECTION 5)
- OIL PUMP (⇒SECTION 4)




Items to be worked after removing engine

- CRANKSHAFT, CRANKSHAFT BEARING, CRANK CASE BEARING.

### TORQUE VALUES :

ENGINE HANGER BOLT (ENGINE) : 5.0kgf · m  
(FRAME) : 7.3kgf · m





## ENGINE REMOVAL/INSTALLATION

- Remove the luggage box. (⇒3-3)
- Remove the plug maintenance cover. (⇒3-3)
- Remove the center cover. (⇒3-3)
- Disconnect the AC generator coupler. (⇒13-7)
- Disconnect the carburetor auto bystarter coupler.
- Remove the spark plug cap.
- Remove the oil pump cable.
- Remove the oil tube connected to the oil pump.
- Remove the negative pressure tube connected to the inlet pipe.
- Remove the fuel tube connected to the carburetor and the auto cock.

Loosen the carburetor cap top, remove the throttle valve.

Loosen the rear brake adjust nut, remove the brake arm joint B and rear brake cable.

Loosen the under bolt at the end of rear cushion.

- Loosen the engine hanger U-nut.
- Loosen the engine hanger flange bolt.
- Remove the engine. (with the muffler and rear wheel attached)

### ⚠ NOTE

- Take action to prevent oil from leaking (Install the clip in the oil tube)
- Take precautions not to damage the engine when removing the engine from the chasis.

- Remove the muffler. (⇒3-7)
- Remove the rear wheel. (⇒11-3)
- Install in the reverse order of removal.

### ⚠ NOTE


- Take precautions not to damage wiring and cable.
- Take precautions not to damage the threaded part of bolts.
- Arrange the cable, tubes and wiring in the right positions.

## ENGINE REMOVAL/INSTALLATION



- Check the following after the engine is assembled.
- Electric systems.
  - Adjust of the rear brake free play.
  - Inspection of the throttle cable operation.
  - Inspection of the oil pump cable operation.

# KICK STARTER/CONTINUOUSLY VARIABLE TRANSMISSION



# 7. KICK STARTER/CONTINUOUSLY VARIABLE TRANSMISSION

<b>SERVICE INFORMATION . . . . .</b>	<b>7-1</b>	<b>DRIVE FACE REMOVAL . . . . .</b>	<b>7-5</b>
<b>SERVICE STANDARD . . . . .</b>	<b>7-1</b>	<b>MOVABLE DRIVE FACE REMOVAL . . . . .</b>	<b>7-6</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>7-1</b>	<b>MOVABLE DRIVE FACE INSPECTION . . . . .</b>	<b>7-6</b>
<b>LH. SIDE COVER REMOVAL . . . . .</b>	<b>7-2</b>	<b>MOVABLE DRIVE FACE ASSEMBLY . . . . .</b>	<b>7-6</b>
<b>KICK STARTER REMOVAL . . . . .</b>	<b>7-2</b>	<b>DRIVE FACE ASSEMBLY . . . . .</b>	<b>7-7</b>
<b>KICK STARTER INSPECTION . . . . .</b>	<b>7-3</b>	<b>DRIVEN PULLY REMOVAL/INSPECTION . . . . .</b>	<b>7-8</b>
<b>KICK STARTER INSTALLATION . . . . .</b>	<b>7-3</b>	<b>DRIVE FACE INSPECTION . . . . .</b>	<b>7-10</b>
<b>DRIVE BELT REMOVAL . . . . .</b>	<b>7-4</b>	<b>DRIVE FACE BEARING INSPECTION . . . . .</b>	<b>7-10</b>
<b>DRIVE BELT INSPECTION . . . . .</b>	<b>7-5</b>	<b>CLUTCH/DRIVEN PULLY ASSEMBLY . . . . .</b>	<b>7-12</b>
<b>DRIVE BELT ASSEMBLY . . . . .</b>	<b>7-5</b>	<b>DRIVEN PULLY ASSEMBLY . . . . .</b>	<b>7-13</b>

## SERVICE INFORMATION

### GENERAL SAFETY

Do not allow oil to contact the drive belt or the pulley face. The transmission rate of driving force is reduced with oil contact.  
Do not operate starter motor while the L. crank case front cover is removed.

 **NOTE**

• Take precautions not to apply the grease oil to the movable drive face or weight roller.

### SPECIFICATIONS

ITEM	STANDARD	SERVICE LIMIT
MOVABLE DRIVE FACE BUSHING INNER DIAMETER	20.035-20.085mm	20.60mm
DRIVE FACE BOSS OUTER DIAMETER	20.011-20.025mm	19.97mm
DRIVE BELT WIDTH	17.5mm	16.50mm
WEIGHT ROLLER OUTER DIAMETER	15.920-16.080mm	15.40mm
CLUTCH OUTER AND INNER DIAMETER	107.0-107.2mm	107.50mm
DRIVEN FACE SPRING PLAY	98.1mm	32.80mm
DRIVEN FACE OUTER DIAMETER	33.965-33.985mm	33.94mm
DRIVEN FACE INNER DIAMETER	34.000-34.025mm	34.06mm

## TROUBLESHOOTING

### Engine starts but motorcycle does not work.

- Drive belt worn.
- Ramp plate damaged.
- Clutch shoe worn or damaged.
- Movable driven face spring cut.

### Engine stops, or the vehicle runs suddenly, after starting.


- Clutch shoe spring cut.

### Vehicle unable to run at the maximum speed, or lack of output



- Drive belt worn.
- Defective movable driven face spring.
- Weight roller worn.
- Pulley face contaminated.

## L. SIDE COVER REMOVAL

- Remove the rear brake cable.
- Remove the 9 flange bolts securing LH. side cover.
- Remove the LH. side cover.



Remove the gasket and the dowel pin.




### NOTE


- Install the new gasket and dowel pin after removing the gasket of the crankcase surface.
- Align the bolts to uniform the tightening location before tightening then when you don't know the bolt length.
- Tighten the bolts diagonally with specified tightening torque.

**TORQUE : 1.0kgf · m**

## KICK STARTER REMOVAL


- Remove the L. side cover.
- Remove the kick starter ratchet and the thrust washer while rotating the kick starter arm.
- Loosen the flange bolt securing the kick starter arm, remove the kick starter arm.
- Remove the 14mm external circlip.
- Remove the kick spindle washer.
- Remove the kick starter spindle.
- Remove the kick spindle spring, bush.





## INSPECTION

- Inspect wear and damage of the kick starter spindle and gear portion.
- Inspect damage to return spring.
- Inspect defects and damage of the kick starter spindle bushing.
- Inspect wear and damage of the kick starter ratchet.
- Inspect damage to friction spring.




## KICK STARTER INSTALLATION

- Install the kick spindle bush, spring in the L. side cover.
- Install the kick starter spindle in the L. side cover.
- Install the kick starter spindle washer.
- Install the 14mm external circlip in the L. side cover.
- Install the kick starter arm.
- Install the kick spindle spring in the groove of the L. side cover.
- Install the thrust washer.



### NOTE

- When installing the 14mm external circlip, keep holding the spindle manually and install the circlip in the groove correctly.
- Apply the grease to the kick starter ratchet groove and gear.
- Check the kick starter ratchet and the kick starter spindle for smooth operation after installation.





Rotate the kick starter spindle using the kick starter arm, draw the spindle to the L. side cover and assemble the kick starter ratchet.

## **DRIVE BELT REMOVAL**

Remove the LH. side cover.  
Remove the 2 dowel pins and gasket.  
Remove the start pinion ass.y.


**⚠ CAUTION**

- Use the special tool when loosening the lock nut. Holding the rear wheel or rear brake will damage the final reduction system.




Hold the clutch outer using the universal holder and remove the nut.  
Remove the clutch outer.

**TOOL: UNIVERSAL HOLDER**



Loosen the drive face setting nut 12mm with the clutch center holder.  
Remove the drive face.

**TOOL: CLUTCH CENTER HOLDER**



Remove the driven pulley/ clutch with the drive belt in place.  
Remove the drive belt from the driven pulley groove and drive pulley groove.


## DRIVE BELT INSPECTION

Check the drive belt for cracks, pry separation and wear; replace as necessary.  
Measure the width of the drive belt as shown.  
Replace the belt if the service limit is exceeded.

**SERVICE LIMIT : 15.5mm**

### ⚠ NOTE

- Use only a genuine DAELIM replacement drive belt.
- Do not get oil or grease on the drive belt or pulley faces. Clean off any grease or oil before reinstalling.





## DRIVE BELT INSTALLATION

Temporarily install the driven pulley/clutch assembly on the drive shaft.  
Turn the pulley clockwise and spread the faces apart while installing the drive belt.  
Remove the pulley assembly once with the drive belt installed.

### ⚠ NOTE

- Hold the pulley faces apart preventing them from closing.



## DRIVE FACE


### REMOVAL

Remove the L. side cover. (⇒7-2)  
Hold the drive face using the clutch center holder and remove the nut and washer.

**TOOL : CLUTCH CENTER HOLDER**


Remove the drive face.  
Remove the flange nut, washer drive face from crank shaft.





**MOVABLE DRIVE FACE DISASSEMBLY**


Remove the dirve face. (⇒7-6 )  
 Remove the movable drive face.



**MOVABLE DRIVE FACE INSPECTION**

The weight rollers push on the movable drive pulley face (by centrifugal force); worn or damaged weight rollers will interfere with this force. Check the rollers for wear or damage and replace as necessary. Measure the O.D. of each roller, replace if the service limit is exceeded.

**SERVICE LIMIT : 15.4mm**




Check the drive face boss for wear or damage and replace as necessary. Measure the O.D of the drive face boss. Replace the boss if the service limit is exceeded. Measure the I.D. of the drive face. Replace it if the service limit is exceeded. Movable drive face boss outer diameter

**SERVICE LIMIT : 19.97mm**

Movable drive face inner diameter

**SERVICE LIMIT : 20.6mm**



**MOVABLE DRIVE FACE ASSEMBLY/INSTALLATION**

Install the weight roller on the movable drive face. Install the ramp plate. Pack the inside of the movable drive face with the specified amount of grease. Install the movable drive face boss.



## ⚠ NOTE

- Do not get the grease on the pulley face. Remove any misplaced grease with a degreasing agent.



Install the movable face assembly on the crankshaft.

## DRIVE FACE INSTALLATION


Squeeze the drive belt into the pulley groove and pull the drive belt over the drive face shaft.

Refer to drive belt assembly method.


Install drive face, washer, drive pulley nut on the crank shaft.



Install the drive belt on the movable drive face.



Install the drive face on the crank shaft serration.  
Install the washer and install flange nut.



Tighten the drive pulley nut to the specified torque.


**TORQUE VALUE : 5.5kgf · m**  
**TOOL : CLUTCH CENTER HOLDER**

**⚠ NOTE**

- Correctly match the drive pulley face and crank shaft serration when assembling.
- If the universal holder cannot be used, remove the cooling fan and hold the flywheel with the universal holder.



Install the driven pulley outer.  
Tighten the driven pulley outer to the specified torque with universal holder.



## CLUTCH/DRIVEN PULLEY

### DISASSEMBLY

- Remove the L.side cover. (⇒7-2)
- Remove the drive face. (⇒7-9)



Hold the clutch outer using the universal holder and remove the flange nut, then remove the clutch outer.  
Remove the drive belt.  
Remove the driven pulley.  
Install in the reverse order of removal.

## DRIVEN PULLEY SUB ASS'Y

### DISASSEMBLY

The clutch/driven face are assembled toward the clutch spring compressor.

#### ⚠ CAUTION

- Make sure that the boss portions of the clutch/driven face are matched with the clutch spring compressor hole.

#### TOOL : CLUTCH SPRING COMPRESSOR

Fix the clutch spring compressor with a vice, etc. Disassemble the 28mm special nut with a socket wrench. Disassemble the clutch driven face from the clutch spring compressor.

#### TOOL : CLUTCH SPRING COMPRESSOR SOCKET WRENCH 39 × 41mm

Assembly is done in the reverse order of disassembly.

Remove the seal collar from the driven pulley. Remove the guide pins and guide pin rollers and the movable driven pulley face.

#### ⚠ NOTE

- Some guide pin can be separated to the roller and the pin.





Remove the O-ring and oil seals from the movable driven face.


### INSPECTION

#### Clutch outer

Measure the I.D. at shoe contact surface of the clutch outer. Replace the outer if the service limit is exceeded.

**SERVICE LIMIT : 107.5mm**






**Clutch Shoe Inspection**

Measure the thickness of each shoe ; replace if the service limit is exceeded.


**SERVICE LIMIT : 2.0mm**



**Movable Driven Face Spring Inspection**

Measure the free length of the driven pulley spring and replace if the service limit is exceeded.


**SERVICE LIMIT : 92.8mm**



**Driven Face Inspection**

Check the following;  
 -Both faces for damage or excessive wear.  
 -Guide pin groove for damage or deformation.  
 Replace damaged or worn parts an necessary.  
 Measure the O.D. of the driven face and the I.D. of the movable driven face. Replace either part if the service limit is exceeded.

**Driven face outer diameter service limit : 33.94mm**  
**Movable driven face inner diameter service limit : 34.06mm**



**Driven Face Bearing Inspection**

Check the inner bearing oil seal (if installed) for damage; replace as necessary.  
 Check the needle bearing for damage or excessive play and replace as necessary.  
 Turn the inner race of the outer bearing with your finger. Check that the bearing turns smoothly and quietly, and that the bearing outer race fits securely.  
 Replace the bearing if necessary.

## CLUTCH SHOE REPLACEMENT

Remove the E-clip and washers, then remove the clutch shoes and shoe springs from the drive plate.

**NOTE**

- Some models use one retainer plate instead of three washers.

Check the shoe springs for damage or loss of tension.

Check the damper rubbers and shoe springs for damage or deformation; replace as necessary. Apply a small amount of grease on the pivot pins.

Install new clutch shoes on the pivot pins and push them into place. Use a small amount of grease on the pivot pin and keep grease off of the brake shoes. Replace the brake shoes if there is any grease on them.





**CAUTION**

- Grease or oil damages clutch shoes and can lead to a loss of engaging ability.

Use pliers to hook the springs to the shoes. Install the E-clip and washers or retainer plate into the pivot pins.

**NOTE**

- Apply only to the belt type gearless transmission.
- Wipe the grease came out from the pivot pin thoroughly.



## **CLUTCH/DRIVEN PULLEY ASSEMBLY**

Install new oil seals and O-rings on the movable driven pulley face.

Lubricate the inside of the movable face with the specified amount of grease.

**GREASE APPLICATION : 5.0~5.5g**

Install the movable face on the driven pulley face.  
Install the guide pins, or guide pins and guide pin rollers.

Install the seal collar.





Assemble the driven pulley, spring and clutch in the clutch spring compressor. Compress the assembly by turning the tool handle until the lock nut can be installed.

Clamp the clutch spring compressor in a vise and tighten the lock nut to the specified torque using the lock nut wrench.

**TORQUE VALUE : 4.0kgf · m**

Remove the spring compressor.  
Install the clutch/driven pulley and drive belt onto the drive shaft.

**TOOL : CLUTCH SPRING COMPRESSOR  
SOCKET WRENCH 39mm**




## DRIVEN PULLEY ASSEMBLY

### INSTALLMENT

Rotate the driven pulley ass'y to the right side and enlarge the belt groove.

Install the drive belt on the driven pully subass'y and mount on to the drive shaft.



Install the drive belt on the assembling area of the movable drive face.



After assembling the drive face in serration area of the L.H. crank shaft.

Install the drive pully nut temporarily.



Tighten the starter driven gear with standard torque.

**STANDARD TORQUE : 5.5kgf · m**





## KICK STARTER/CONTINUOUSLY VARIABLE TRANSMISSION

---



After assembling the clutch outer, install the flange nut temporarily.  
Fix the clutch outer with the universal holder, tighten the flange nut with standard torque.

**STANDARD TORQUE : 4.0kgf · m**




Install the LH. crank case cover and tighten the bolts.

---

# MEMO

---

# CYLINDER HEAD / CYLINDER / PISTON



## 8. CYLINDER HEAD/CYLINDER/PISTON

<b>SERVICES INFORMATION . . . . .</b>	<b>8-1</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>8-1</b>
<b>FAN COVER, SHROUD REMOVAL . . . . .</b>	<b>8-2</b>
<b>CYLINDER HEAD/ CYLINDER/ PISTON . . . . .</b>	<b>8-2</b>

### SERVICE INFORMATION

#### GENERAL SAFETY

Take precautions not to damage the joint part with a driver when removing the cylinder, or not to damage the cooling pin by striking the cylinder too hard.

Take precautions not to damage the inside of the cylinder or the exterior part of the piston.

Check parts after disassembling, and clean and dry with an air hose prior to taking measurements.

#### SPECIFICATIONS

Unit : mm(in)

ITEM		STANDARD VALUE	SERVICE LIMIT
CYLINDER	Inner diameter	$\phi$ 40.005~40.010mm	40.05mm
	Cylindricity	-	0.10mm
	Out of roundness	-	0.10mm
PISTON,	Piston skirt outer diameter	39.955~39.970mm	39.90mm
PISTON PIN,	Piston pin hole inner diameter	12.002~12.008mm	12.03mm
PISTON RING	Piston pin outer diameter	11.994~12.000mm	11.98mm
CYLINDER TO PISTON CLEARANCE		0.040~0.055mm	0.13mm

### TROUBLESHOOTING

#### Comperssion low

Worn cylinder or piston rings

Leaking valve seats

#### Excessive smoke

Worn cylinder or piston

Improper installation of piston rings

Scored or scratched piston or cylinder wall

#### Overheating

Excessive carbon build-up on the piston combustion

Incorrect spark plug

#### Knocking or abnormal noise


Worn piston and cylinder

Excessive carbon build-up


Low octane fuel

## FAN COVER, SHROUD REMOVAL

- Remove the luggage box. (⇒3-3)
- Remove the plug maintenance cover. (⇒3-3)




- Loosen the 2 fan cover flange bolts.
- Loosen the 2 left shroud flange bolts.
- Remove the left shroud.



### NOTE

- Pay attention not to damage certain part when removing
- Remove according to the working procedure.


Install in the reverse order of removal.



## CYLINDER HEAD/ CYLINDER/ PISTON

### REMOVAL

- Remove the luggage box. (⇒3-3)
- Remove the the battery maintenance lid. (⇒3-3)
- Remove the center cover. (⇒3-3)
- Remove the floor side cover. (⇒3-4)
- Remove the floor panel. (⇒3-4)
- Remove the exhaust muffler assembly. (⇒3-7)
- Remove the fan cover shroud.




## Cylinder Head

Loosen the 4 cylinder head bolts.

### ⚠ NOTE

- Bolts are loosened by rotating 2~3 times and alternating to a diagonal bolt.

Remove the cylinder head.  
Remove the cylinder head gasket.



## Cylinder

Remove the cylinder.




## Piston/Piston Ring

Remove the piston pin clip.  
Remove the piston pin.


### ⚠ NOTE

- Be careful not to bend pins.
- Be careful not to damage the cylinder and crankcase gasket face when cleaning.




Remove the piston.  
Remove the needle bearing from the small end of the connecting rod.

# CYLINDER HEAD / CYLINDER / PISTON




## NOTE

- Do not damage or scratch the piston.
- Do not apply side force to the connecting rod.
- Do not let the clip fall into the crankcase.
- Mark and store the pistons and piston pins so that they can be reinstalled in their original positions.



## INSPECTION


There is more carbon deposit within the engine in case of 2 cycle engine than 4 cycle engine because the engine oil is burnt in the 2 cycle engine. Excessive carbon deposit may cause self-ignition by the overheating of the carbon in the combustion chamber and the piston head and may damage the engine. Carbon deposit in the exhaust gas port disturbs exhaust gas flow and causes decrease of the output. Remove the carbon deposit periodically.



## CAUTION

- Pay attention not to damage the combustion chamber, the piston and the cylinder when removing the carbon.


Remove the cylinder head and remove the carbon with the piston being in the top dead center. Dismount the cylinder, remove the carbon deposited in the exhaust gas port and clean the remaining carbon in the cylinder.



## Cylinder Wear Inspection

Inspect the cylinder wall for scratches and wear. Inspect the area near T.D.C (Top Dead Center) carefully. This area is especially subject to wear due to the possibility of borderline lubrication from heat and top ring compression.

# CYLINDER HEAD / CYLINDER / PISTON



Measure and record the cylinder I.D. at the three levels in both an X and Y axis.  
Take the maximum reading to determine the cylinder wear.

**NOTE**

- Avoid the intake and exhaust ports when measuring.

Measure the piston O.D.

**SERVICE LIMIT : 40.05mm**


Calculate the piston-to-cylinder clearance. Take the maximum reading to determine the clearance.

## Piston Outer Diameter Inspection


Measure and record the piston O.D. 90° to the piston pin bore and at the point specified in the Model Specific manual, near the bottom of the piston skirt.  
Replace the piston if the service limit is exceeded.

**SERVICE LIMIT : 39.90mm**

Calculate the piston-to-cylinder clearance




Install the needle bearing and piston pin in the connecting rod small end and check for excessive play.



## Piston Pin Inspection

Measure the piston pin O.D. at three points.  
Replace the piston pin if the service limit is exceeded.

**SERVICE LIMIT : 11.98mm**






## Piston Pin Bore Inspection

Measure the piston pin bore I.D. in an X and Y axis. Take the maximum reading to determine the I.D. Replace the piston if the I.D. is over the service limit.

**SERVICE LIMIT : 12.03mm**



## PISTON/PISTON RING INSTALLATION


Clean the piston ring grooves.

Lubricate the piston rings and ring grooves with clean 2-stroke oil.

Install the piston rings on the piston with the marks facing up.

### NOTE

- Do not confuse the top and second rings. Be sure to install them in the proper grooves.
- Some 2-stroke engines use an expander ring behind the second ring.




In 2-stroke engines, the piston has stopper pins that hold the piston rings away from the intake and exhaust ports.

Align the piston ring end gaps with the stopper pins.

Check the fit of each ring in the groove by pressing the ring into the groove. Make sure that it is flush with the piston at several points around the ring.


If the ring rides on the stopper pin, it is damaged during assembly.





Coat the needle bearing (2-stroke engine only) and piston pin with the recommended oil. Lubricate the piston pin

Install the needle bearing into the connecting rod.

Install the piston and insert the piston pin.





## NOTE

- The mark that is stamped on the piston head should be facing the correct direction.
  - “●” MARK : TO INTAKE SIDE
  - “EX” MARK : TO EXHAUST SIDE
  - “ ” MARK : TO ONGOING SIDE
  - “↓” MARK : TO INTAKE SIDE

Install the new piston pin clips.

## CAUTION



- Take care not to drop the piston pin clip into the crankcase.
- Make sure to set the piston pin clip in the groove properly.
- Do not align the clip's end gap with the piston cutout.

## CYLINDER/ CYLINDER HEAD INSTALLATION

Apply the engine oil inside of cylinder piston ring and install them.

Install the new piston pin clip.

# TRANSMISSION/CRANKSHAFT/CRANKCASE



# 9. TRANSMISSION/CRANKSHAFT/CRANKCASE

<b>SERVICE INFORMATION . . . . . 9-1</b>	<b>CRANKSHAFT REMOVAL . . . . . 9-5</b>
<b>SERVICE STANDARD . . . . . 9-1</b>	<b>CRANKSHAFT BEARING REMOVAL . 9-5</b>
<b>TRANSMISSION/CRANKSHAFT/ CRANKCASE . . . . . 9-2</b>	<b>CRANKCASE BEARING REMOVAL . 9-6</b>
	<b>CRANKSHAFT INSTALLATION . . 9-7</b>

## SERVICE INFORMATION

### GENERAL SAFETY

This section describes how to remove the crank case and to maintain the transmission and the crankshaft.

Always use special tools to change the drive shaft. Fix the bearing inner race, andn install the shaft.

The following parts must be removed prior to removing the crank case. Follow the removal procedure specified in each section.

- OIL PUMP (⇒SECTION 4)
- CARBURETOR (⇒SECTION 5)
- ENGINE (⇒SECTION 6)
- CYLINDER HEAD/ CYLINDER/ PISTON (⇒SECTION 8)
- AC GENERATOR (⇒SECTION 13)
- DRIVE PULLEY (⇒SECTION 7)
- CLUTCH/DRIVEN PULLEY (⇒SECTION 7)
- REED VALVE (⇒SECTION 5)





The following parts must be removed prior to changing the L. crank case. Follow the removal procedure specified in each section.

- TRANSMISSION (⇒SECTION 9)
- REAR BRAKE (⇒SECTION 12)

To assemble the crank case and crankshaft, set the special tool to the inner race of the crankshaft bearing, and push and assemble. Remove the bearing from the crankshaft during disassembling work, and insert a new bearing in the case. Install the oil seal after the case is assembled.

## SERVICE STANDARD

ITEM		STANDARD VALUE	SERVICE LIMIT	
CRANK SHAFT	Large end side clearance	0.15~0.55mm	0.60mm	
	Connecting rod large end right angle direction clearance	0.010~0.02mm	0.04mm	
	Crank shaft shaking	Right	0.03mm	0.15mm
		Left	0.05mm	0.10mm



## TRANSMISSION/CRANKSHAFT/ CRANKCASE

### DISASSEMBLY

Remove the L. side cover. (⇒7-2)  
Remove the continuously variable transmission.  
(⇒SECTION 7)  
Remove the exhaust muffler. (⇒3-7)  
Remove the rear wheel. (⇒11-3)  
Install the oil sump under the cover of transmission.  
Loosen the 5 transmission cover flange bolts.  
Remove the transmission cover.

Remove the final shaft gear.  
Remove the thrust washer.  
Remove the countershaft.  
Remove the counter shaft gear.  
Remove the side washer.

Remove the drive shaft from transmission cover with the press.


#### ⚠ NOTE

- Take precautions not to damage the cover joints.


Remove the oil seal of the drive shaft.

### INSPECTION


Inspect the drive shaft for wear or damage.



Inspect the final shaft for wear or damage.



Inspect the countershaft for wear or damage.




## Bearing Inspection

Manually turn the bearing inner race installed inside the transmission cover, and check if the race is turning smoothly.

Verify the outer race is accurately installed in the case. Replace the bearing, if necessary.

### ⚠ NOTE

- Install the bearing with the carved mark directing to the outside.



Use special tools to push in the bearing into the case.

**TOOLS :** DRIVER HANDLE A  
OUTER DRIVER 52X55mm  
DRIVER PILOT 20mm

Check the L. crank case oil seal for wear or damage.


## TRANSMISSION ASSEMBLY

Install the drive shaft on the transmission cover.  
Install a new drive shaft oil seal.

**TOOL : CRANK ASSEMBLY**




Install the thrust washer, final gear and counter gear, side washer on the L. crankcase.



Install new dowel pins.  
Install a new transmission cover seal on the transmission cover.  
Install the transmission cover.  
Tighten the transmission cover with the flange bolts.

**NOTE**


- Tighten bolts diagonally and alternately and tighten with specified torque in the end.



Remove the oil check bolt, release the transmission oil filler ACG cap or the L. crankcase until the oil overflow through oil hole and fill the recommended oil slowly.

Install the oil check bolt and the cap .

**RECOMMENDED OIL : SAE #80~90**  
**TRANSMISSION OIL AMOUNT : 0.09 l**





## CRANKSHAFT REMOVAL

Loosen the 6 R. crankcase flange bolts.

Secure a crankcase puller on the R. crankcase and remove the R. crankcase from the L. crankcase.

**TOOL : CRANKCASE PULLER (0751-00003)**

Secure a crankcase puller on the L. crankcase and remove the crankshaft from the L. crankcase.



### NOTE

- Be careful not to distort the mating surface of the crank case during disassembly.
- Do not force to disassemble by pounding on the crankshaft.


**TOOL : CRANKCASE PULLER (0751-00003)**

Remove the oil seal from the R. and L. crankcases.  
Remove the dowel pin.

## CRANKSHAFT BEARING REMOVAL

If the radial ball bearing is left on the crankshaft, remove the bearings out of the crankshaft using a bearing puller.


**TOOL : UNIVERSAL BEARING PULLER (0755-00001)**




## CRANKSHAFT INSPECTION

Place the crankshaft on a stand or V-block, and check the journal vibration.

**SERVICE LIMIT : RIGHT SIDE 0.1mm  
LEFT SIDE 0.15mm**









Measure the side gap between the connecting rod big end and the crank weight.

**SERVICE LIMIT : 0.6mm**



Check the vertical shaft play of the connecting rod big end from the X and Y direction.

**SERVICE LIMIT : 0.05mm**



## CRANKCASE BEARING REMOVAL


Remove the transmission and crankshaft.

### INSPECTION

Manually turn the bearing inner race to see if it rotates smoothly.

Check the outer race to see if it is accurately pressed into the case.

If the outer race is excessively loose, or is loosely pressed into the case, remove in and replace with a new one.




### REPLACEMENT

#### L. Crankcase


Use special tools to remove the drive shaft bearing.

**TOOLS : BEARING REMOVER SET  
REMOVER SHAFT  
REMOVER HEAD**

Remove the final gear bearing and oil seal.  
Remove the counter gear bearing.




Apply clean engine oil to a new bearing, and assemble it to the crank case.  
Install a new final gear oil seal.



## CRANKSHAFT INSTALLATION

Apply clean engine oil to the new R. crankshaft bearing, and press in the bearing into the R. crank case.


**TOOLS : DRIVER HANDLE A  
OUTER DRIVER 52x55mm  
DRIVER PILOT 20mm**



Use special tools to assemble the crankshaft bearing to the L. crank case.

**TOOLS : DRIVER HANDLE A  
OUTER DRIVER 52x55mm  
DRIVER PILOT 20mm**

Clean the crankcase using cleaning oil, and check for rack and damage to each area.



### ⚠ NOTE

- After removing the liquid gasket from the joining face of the crankcase, amend the scratched areas using oil ston.
- Apply 2-cycle oil to the radial ball bearings and the connecting rod large end portion.


Install the crankshaft to the L. crankcase.

### ⚠ NOTE

- Install not to interfere with the case with being careful of connecting rod location.

**TOOL : CRANKSHAFT ASSEMBLER**

## TRANSMISSION/CRANKSHAFT/CRANKCASE



Apply a liquid gasket to the L. crankcase joining face,  
install the dowel pins.  
Install the R. crankcase.  
Install the 6 flange bolts.



### NOTE

- Make sure that there is no adhesion of gasoline to the R., L. crankcase liquid gasket face.
- Do not apply excessive liquid gasket fluid excessively.

**TOOL : CRANKSHAFT ASSEMBLER**

### CAUTION

- Make sure that the crankshaft is rotated smoothly after installation (prior to oil seal installation).
- If the smooth rotation is not acquired, tap the crankshaft bearing part of crankcase with plastic hammer to ensure proper installation without mismatch.



Install a new L. oil seal in the crankcase end portion at 1.0mm depth.





Install a new R. oil seal in the crankcase end portion at 5.0mm depth.

---

# MEMO

---

# FRONT WHEEL/FRONT FORK/STEERING



# 10. FRONT WHEEL/FRONT FORK/STEERING

<b>SERVICE INFORMATION . . . . .</b>	<b>10-1</b>	<b>FRONT WHEEL . . . . .</b>	<b>10-5</b>
<b>SPECIFICATION . . . . .</b>	<b>10-1</b>	<b>TUBELESS TIRE . . . . .</b>	<b>10-9</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>10-2</b>	<b>FRONT FORK . . . . .</b>	<b>10-14</b>
<b>STEERING HANDLE . . . . .</b>	<b>10-3</b>	<b>STEERING STEM . . . . .</b>	<b>10-19</b>

## SERVICE INFORMATION

### GENERAL SAFETY



Keep oil or brake fluid off the brake disk and pad because the contaminated brake disk and pad reduces the braking performance. If contaminated, replace the pad with a new one, and clean the disk.

Use special tire levers and rim protectors to remove or assemble tires to protect the rim from being damaged.

This section describes how to remove and maintain front wheels, front fork and steering system. For information on the front brake system, refer to section 10.

Place a jack underneath the engine to support the 2-wheeled vehicle.

### SPECIFICATIONS

ITEM		STANDARD VALUE	SERVICE LIMIT
FRONT AXLE DEFLECTION		-	0.2mm
FRONT WHEEL RIM RUNOUT	RADICAL	-	2.0mm
	AXIAL	-	2.0mm
FRONT FORK TUBE DEFLECTION		-	0.2mm
FRONT FORK OIL LEVEL		58	-
FORK SPRING FREE LENGTH		263.5mm	-

### TORQUE VALUES

- STEERING STEM LOCK NUT 7.0kg · m
- BRAKE DISK BOLT 3.9kgf · m
- FRONT AXLE NUT 6.0kgf · m

## TROUBLESHOOTING

### Hard steering

- Steering bearing adjustment nut too tight.
- Faulty steering stem bearings.
- Damaged steering stem bearings.
- Insufficient tire pressure.

### Steers to one side or does not track straight

- Unevenly adjusted right and left shock absorbers.
- Bent front forks.
- Bent front axle : wheel installed incorrectly.

### Front wheel wobbling

- Bent rim.
- Worn front wheel bearings.
- Faulty tire.
- Axle nut not tightened properly.
- Wheel out of balance.

### Soft suspension

- Weak fork springs.
- Insufficient fluid in front forks.

### Hard suspension

- Incorrect fluid weight in front forks.
- Front fork air pressure incorrect.
- Bent fork tubes.
- Clogged fluid passage.
- Clogged anti-dive orifice.



### Front suspension noise

- Worn slider or guide bushings.
- Insufficient fluid in forks.
- Loose front fork fasteners.
- Lack of grease in speedometer gear box.

## STEERING HANDLE

### REMOVAL

- Remove the front cover. (⇒3-5)
- Remove the front handle cover. (⇒3-6)
- Remove the rear handle cover. (⇒3-6)
- Removal must be performed with the rear handle cover and the speedometer installed.
- Loosen the throttle housing fixing pin screw.
- Remove the throttle upper housing.
- Remove the throttle under housing.
- Remove the throttle grip.
- Loosen the 2 master cylinder holder bolts, remove the master cylinder.



### ⚠ CAUTION

- Support master cylinder properly to prevent brake fluid from leaking.
- If the master cylinder is dropped upside down, air may enter the hydraulic system. Fix it to the vehicle while maintaining the correct assembled location.

- Loosen the handle bracket fixing washer bolt.
- Remove the handle bracket bend.
- Remove the handle bracket.
- Remove the L. handle grip.

- Loosen the handle setting U-nut, remove the handle set collar and flange bolt.
- Remove the rear brake cable, front brake hose, speedometer cable, handle cable from the guide.
- Remove the steering handle from the steering stem.

### INSTALLATION

- Install steering handle to the steering stem.
- Install the handle setting bolt, U-nut, handle set collar.


### ⚠ NOTE

- When installing the handle setting collar, match it with the groove accurately.

**TORQUE VALUE : 5.0kgf · m**



## FRONT WHEEL/FRONT FORK/STEERING




Install the rear brake cable, front brake hose, speedometer cable to the handle cable guide.

Apply DAELIM Bond A to the inside surface of the grip and to the clean surface of the left handle bar. Wait 3~6 minutes and install the grip.

**(Bond A :ROYAL BOND 1300)**

### ⚠ NOTE

- Clean the bonding surface to avoid oil, grease or gasoline from attaching.
- Leave it for minimum 1 hour until the bond is dried.
- Use the bond according to the bond manual enclosed and install the grip while rotating it before the bond is dried completely.



Align the positioning pin with the handle hole and install the L. handle bracket.

**TORQUE : 1.2kgf · m**


Clean the throttle grip surface, apply the grease and install the grip.

Connect the throttle cable to the groove of the grip.

Tighten the pin screws after assembling the under and upper throttle housings.

### ⚠ NOTE


- Check the throttle grip for smooth operation and adjust the free play to 2~6mm.



Match the master cylinder with the punch mark of the handle, install it with the mark in the master cylinder holder facing upwards or front and tighten the rear or front first.

### ⚠ NOTE

- Check to see if the cylinder is passing each cable and wire harness directly and make sure that there is any interference by rotating the handle to the right and left.



Install the rear handle cover. (⇒3-6)

Install the front handle cover. (⇒3-6)

Install the front cover. (⇒3-5)


## FRONT WHEEL

### REMOVAL

Remove screws from the speedometer gear box, and separate the speedometer cable.

**NOTE**

- Loosen axle nuts. Support bottom of engine with a jack until the front wheel is lifted.



Loosen the axle nut.  
Remove the front axle.  
Remove the front wheel.

**NOTE**


- Do not operate brake lever after the front wheel is removed.

Remove the speedometer gear box.

### INSPECTION

Check the front axle for deflection. Place the front axle on a V-block, and measure deflection with a dial gauge.


**SERVICE LIMIT : 0.2mm**



Place the front wheel on an inspection stand. Slowly turn the wheel, and check the rim runout with a dial gauge.

**SERVICE LIMIT : Radial 2.0mm  
Axial 2.0mm**





## Bearing Inspection

Manually turn the bearing inner race, and replace if it makes noise or is worn. Check if the bearing outer race is accurately fitted into the wheel hub, and replace worn ones.

 **NOTE**

- Replace bearings in pairs (left and right set).



## FRONT WHEEL DISASSEMBLY

Remove the speedometer gear box, dust seal, and speedometer gear retainer.



Remove the front brake collar A.



Remove the dust seal and brake disc. Check the disc for defects.

# FRONT WHEEL/FRONT FORK/STEERING

## WHEEL BEARING REPLACEMENT



Install the bearing remover head and the remover shaft on the wheel, and remove the bearing and distance collar.

### ⚠ NOTE

- Always replace bearings in pairs, and never use old bearings.

**TOOLS : BEARING REMOVER HEAD  
BEARING REMOVER**




Apply sufficient amount of grease to the bearing. Insert the right bearing with its seal surface facing outside.

Do not tilt the bearing. Insert accurately. Upon assembling the distance collar, insert the left bearing with its seal surface facing outside.

**TOOLS : DRIVER  
ATTACHMENT, 32x35mm  
PILOT, 15mm**

### ⚠ CAUTION

- The bearing inserted in the last must be inserted until it contacts with the distance collar.
- Excessively inserted bearing can cause damage the opposite side bearing.




## SPEEDOMETER GEAR REPLACEMENT

Remove the speedometer gear and washer from the speedometer gear box.

Check the gear for wear or damage.

Install the washer.

Apply grease to the speedometer gear prior to assembling.



## FRONT WHEEL ASSEMBLY

Apply grease to the right side dust seal rim.  
Install the right side dust seal.  
Install the brake disk.  
Install disk bolts.


**TORUE VALUE : 3.9kgf · m**



Install the front brake collar A.



Install speedometer gear box seal.



Assembly speedometer gear box in speedometer gear box seal.



## TUBELESS TIRE

### REMOVAL

Remove the wheel.

#### ⚠ NOTE

- Single brake disk type : To prevent damage to the disk, place the wheel on the level surface with the disk facing up.

Remove the valve cap and bleed air by pressing the valve core.

Remove the valve core after bleeding air completely. Remove the valve stem nut and push the valve stem lightly.

If a bead stopper is installed, loosen the lock nut and push the bead stopper down.

Collapse in the bead with a tire bead breaker.

If no tire bead breaker is available, step on the side wall to collapse the bead.

#### ⚠ NOTE

- Do not step on the rim.

Collapse the bead into the rim center and slide the tire out of position.

#### ⚠ NOTE

- Tire can be easily removed once the beads are collapsed completely.





Apply a mild detergent solution to the rim and tire mating surfaces.

Be sure that the bead is completely collapsed.


Insert the tire lever from the opposite side of the valve and raise the bead over the rim.

#### ⚠ NOTE

- Be sure to use motorcycle tire levers.
- Do not apply the mild detergent solution to the rim and tire mating surfaces of low pressure tire. Apply water only.




# FRONT WHEEL/FRONT FORK/STEERING




Insert another tire lever at 30~50mm from the first tire lever and remove the tire from the rim, little by little.

## ⚠ NOTE


- Do not try to remove the bead too much at one time.



Repeat the above procedures until half of bead is removed. Then remove the remaining bead by hand.



Remove the another tire from the rim according to the same procedures.



## RIM VALVE REPLACEMENT


Cut off the rim valve at its base.

Apply mild detergent solution to a replacement rim valve and insert it from inside of the rim.

## ⚠ NOTE

- Be sure to use the recommended rim valve.
- Do not damage the valve hole.
- Replace the rim valve whenever installing a tubeless tire.

## RIM INSPECTION



If using a solution (brake cleaner, gasoline, thinner) when removing the rust and dirt, wipe off the remainder when reassembling. It may damage the rubber parts.

If there is serious deformation, twist or crack, the air may be leaked. Replace the damaged parts immediately.

If there is scratch on bead contacting face more than 0.5mm in depth or 1.0mm in width, replace the damaged parts immediately.

### WARNING

- If the combination of tubeless tire and rim isn't proper, the tire may come off. It will cause a serious accident. Pay attention to deal it.

## TUBELESS TIRE INSTALLATION


### CAUTION

- Always use the exclusive tire lever for two-wheeled vehicles.
- Use the rim protector to prevent the scratch of rim.
- In case of low pressure tire, if vegetable soapy water is used, it may slip even after the rim and tire are installed. Only use the water.

If the tire has a light mark (yellow paint mark), install the tire with this mark aligned with the valve.


If the tire has an arrow mark, install the tire with the mark pointing in the direction of rotation.

Stand the tire upright, hold it with one hand and, starting from the opposite side to the valve, install one side of the tire on the rim as much as you can by hand.




Be sure to assemble in the sequence shown.

Place the wheel on the level surface and install the remaining portion of the tire using two tire levers.






# FRONT WHEEL/FRONT FORK/STEERING




Install the other side of the bead while holding the assembled portion of the bead with your knee to prevent it from coming off.

After 1/2 of the bead has been installed, insert the two tire levers at a distance of 30~40mm to install it. Repeat this procedure until 3/4 of the bead has been installed.



**NOTE**


- Hold one tire lever upright to remove the other lever.



Check out whether the bead is in the center of the rim when 3/4 of the bead has been installed.


**NOTE**

- The last portion of the bead is more difficult to install. The rim and bead may be damaged if the bead on the opposite side of the point where you are working is not in the rim center.




When the remaining bead is only 50~60mm, pull the two levers up and over and completely install the bead. Install the valve core.

## FRONT WHEEL/FRONT FORK/STEERING



Apply a mild detergent solution to the bead again. Tap on the tire tread surface with a rubber hammer so that the tire and rim fit evenly around the circumference.


Be sure that the tire center and rim center are aligned.



Inflate the tire to 1.5 times the standard recommended pressure to seat the bead on the rim.

### ⚠ NOTE

- When air charging, you may hear a loud sound as the bead seats onto the rim. This is normal.
- When air charging, if air leaks out from between the rim and bead, let the wheel stand with the valve at the bottom and put air in while pushing down on the tire.



Check that the tire bead seats on the tire rim securely and the rim line of the tire is concentric with the rim.




## FRONT WHEEL INSTALLATION

Insert the front wheel between the front forks. Insert the disk, taking precautions not to damage the pad, and assemble the wheel.

Align the slots of the speedometer gear with the tangs of the left fork slider.

Insert the front axle into the speedometer gear box and the wheel hub.

## FRONT WHEEL/FRONT FORK/STEERING




Install the axle nut.  
Assemble the speedometer cable, and tighten with screws.  
Place the front wheel on the ground, and tighten the axle nut to the prescribed torque.

**TORQUE VALUE : 6.0kgf · m**



## FRONT FORK REMOVAL

Remove the front cover. (⇒3-5)  
Remove the front fender. (⇒3-5)  
Remove the front brake caliper. (⇒12-7)  
Remove the front wheel. (⇒10-5)  
Loosen the front brake hose stay bolt, remove the L. fork.  
Remove the speedometer cable from R. fork speedometer cable guide.  
Loosen the R. fork securing bolt, remove the speedometer cable and guide.




Loosen the 2 steering stem front fork R., L. stay bolts.  
Remove the front fork.



## FRONT FORK DISASSEMBLY


Remove the fork tube cap bolt.

## FRONT WHEEL/FRONT FORK/STEERING




### ⚠ NOTE

- If the screw is completely loosened, the fork tube cap bolt may spring out by the force of the spring. Take due precautions.
- Remove the fork spring, and expand and release the fork pipe several times to drain fork oil.




Wrap the bottom case with a piece of cloth, and remove the socket bolt.



### ⚠ NOTE

- If the socket bolt turns idle but cannot be removed, temporarily assemble the spring and the fork tube cap bolt first.
- Hold the bottom case firmly with a vise, taking precautions not to distort or damage it.

RULLER




Remove the dust seal.

# FRONT WHEEL/Front FORK/STEERING




Remove the oil seal stopper ring.




Remove the oil seal.

**NOTE**

- Take precautions not to damage the interior and exterior rim of the bottom case.



Remove the fork tube from the bottom case.  
Remove the piston and rebound spring from the fork tube.




## FRONT FORK INSPECTION

Place the fork spring on a level place, and measure the free length.  
If the free length deviates from the service limit, replace the spring with a new one.  
Check components for damage or abnormal wear.  
Replace defective parts with new ones.


**SERVICE LIMIT : 263.5mm**

Place the fork tube on a V-block, and measure deflection with a dial gauge.

**SERVICE LIMIT : Replace if the deflection is greater than 0.2mm**




Check the slider bush contact face.  
If the slider bush is extensively damaged, replace the bottom case.



## FRONT FORK ASSEMBLY

Wash parts with clean oil prior to assembling.  
Assemble the rebound spring and the fork piston to the fork tube.  
Assemble the fork tube to the bottom case.




Wrap the bottom case with a piece of cloth, and fix it to the vise.  
Apply screw locking agent to the socket bolt thread, and assemble the socket bolt to the fork piston.

**TORQUE VALUE : 2.0kgf · m**

### ⚠ NOTE

- When a vise is used to hold the bottom case, do not insert the case itself but insert the bracket.




Apply ATF to a new oil seal.  
Assemble the oil seal to the bottom case.  
Insert the oil seal with special tools until the attachment groove of the bottom case set ring is exposed.

**TOOLS : FORK SEAL DRIVER  
FORK SEAL DRIVER BODY**

Install the oil seal stopper ring  
Accurately assemble the oil seal stopper ring to the bottom case.


# FRONT WHEEL/FRONT FORK/STEERING



Install the dust seal.  
Fill a prescribed amount of automatic transmission fluid(ATF) into the fork tube.

**CAPACITY : 58cm<sup>3</sup>**

Slowly press the fork tube 2-3 times to discharge air.




Assemble the spring to the fork pipe.

## ⚠ NOTE

- Install the spring with the smaller pitch side facing downward.



Assemble the fork bolt to the fork tube.



## FRONT FORK INSTALLATION

Install the front fork to the steering stem.  
Install the front fork setting bolt.

**TORQUE VALUE : 4.0kgf · m**




Install the following parts.

- Front wheel (⇒10-5)
- Brake caliper (⇒12-6)
- Front fender (⇒3-5)
- Front cover (⇒3-5)

### STEERING STEM REMOVAL

- Front cover (⇒3-5)
- Front fender (⇒3-5)
- Front handle cover/rear handle cover (⇒3-6)
- Steering handle (⇒10-3)
- Front wheel (⇒10-5)
- Front brake caliper (⇒12-6)
- Front fork (⇒10-14)



Loosen the steering stem lock nut.  
Remove the speedometer cable and front brake hose from the steering stem bracket.  
Loosen the steering top cone race.  
Remove the steering stem.

#### NOTE

- When the bottom case fixes in the vice, use the bracket.


Check the steel ball, cone race, and ball race for wear or damage. Replace worn or damaged ones.



# FRONT WHEEL/FRONT FORK/STEERING



Remove the steering steel ball/ upper steering ball race/ steering bottom cone race.



Remove the upper ball race/ steering bottom cone race.

**TOOL : BALL RACE DRIVER**


## ⚠ NOTE

- Check all of the races and balls for damage or abnormal wear and replace as necessary.
- If the vehicle has been involved in a collision, the steering stem may be damaged.



## STEERING STEM INSTALLATION

Insert the upper/under ball race into the steering head pipe.



Using a steering stem driver, drive the steering stem bottom cone race into the steering stem.

## FRONT WHEEL/FRONT FORK/STEERING



Insert the ball race after applying grease thereto.



Install the top cone race and the steering head top thread nut on the steering head.  
Tighten the top thread nut completely, and loosen by 1/8 turn.

**TORQUE VALUE : 1.0 kgf · m**

Check the top and bottom free play, and check for smooth left and right movement.



Temporarily install the R/L front forks first, and tighten the steering stem nuts.

**TORQUE VALUE : 7.0kgf · m**  
**TOOLS : LOCK NUT WRENCH**  
**EXTENSION BAR**



Install the front fork.

Install the following parts.

- Steering handle (⇒10-3)
- Front wheel (⇒10-5)
- Front handle cover/ rear handle cover (⇒3-6)
- Front fender (⇒3-5)
- Front brake caliper (⇒12-6)

## FRONT WHEEL/FRONT FORK/STEERING

---



 NOTE

- Check the cables and wiring for interference.

Install the front cover.

# 11. REAR WHEEL/BRAKE/SUSPENSION

<b>SERVICE INFORMATION . . .</b>	<b>11-1</b>	<b>REAR WHEEL . . . . .</b>	<b>11-3</b>
<b>SERVICE STANDARD . . . . .</b>	<b>11-1</b>	<b>REAR BRAKE . . . . .</b>	<b>11-4</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>11-2</b>	<b>REAR CUSHION . . . . .</b>	<b>11-6</b>

## SERVICE INFORMATION

### GENERAL SAFETY

If the brake drum or lining is contaminated with oil, braking power will be lost. If contaminated with oil, clean the brake drum, and replace the brake shoe.

Inhaled asbestos fibers have been found to cause respiratory disease and cancer. Never use an air hose or dry brush to clean brake assemblies. Use a brake cleaner, designed to minimize the hazard caused by airborne asbestos fibers.

### SPECIFICATIONS

ITEM		STANDARD VALUE	SERVICE LIMIT
AXLE SHAFT RUN OUT		-	0.2 mm
REAR WHEEL RIM RUNOUT	RADICAL	-	2.0 mm
	AXIAL	-	2.0 mm
REAR BRAKE DRUM INNER DIAMETER		110.0~110.3mm	111.0mm
REAR BRAKE LINING THICKNESS		4.0 mm	2.0 mm
REAR CUSHION SPRING FREE LENGTH		234.8mm	-

### TORQUE VALUES :

AXLE SHAFT RUN OUT	10.0~12.0kgf · m
REAR CUSHION UPPER BOLT	3.5~4.5kgf · m
REAR CUSHION LOWER BOLT	3.5~4.5kgf · m

### TROUBLESHOOTING

#### **Wobble or vibration in motorcycle**

- Tire pressure incorrect
- Faulty tire
- Bent rim
- Loose wheel bearing
- Swing arm bushing worn
- Wheel out of balance

#### **Soft suspension**

- Weak springs
- Rear damper improperly adjusted, oil leakage

#### **Hard suspension**

- Rear damper improperly adjusted
- Bent shock absorber rod

#### **Suspension noise**

- Loose fasteners
- Worn shock

### REAR WHEEL

#### REMOVAL

Support the motor cycle on the main stand.  
Loosen the rear brake adjuster, and remove the brake cable.  
Remove the brake arm joint B.



Remove the muffler. (⇒3-7)  
Remove the rear wheel mud guard.  
Loosen the rear wheel U nut.  
Remove the washer.  
Remove the rear wheel.



#### INSPECTION

Turn the wheel, and check the rim for wobbles.

**SERVICE LIMIT : Radical 2.0mm  
Axial 2.0mm**



#### INSTALLATION

Insert the rear wheel over the final shaft.



## REAR WHEEL / BRAKE / SUSPENSION



Insert the washer, and tighten with the U nut.

**TORQUE VALUE : 6.0~8.0kgf · m**



Install the brake arm joint B.  
Install the rear brake cable.  
Install the rear brake rod adjusting nut.  
Install the rear wheel mud guard.  
Install the muffler.

### ⚠ NOTE

- Check the free play of the brake after the rear wheel assembling




## REAR BRAKE

Remove the rear wheel. (⇒11-3)

## INSPECTION

Measure the brake drum of inner diameter

**SERVICE LIMIT : 111mm**




Measure the thickness of the brake lining.

**SERVICE LIMIT : 2.0mm**

## REAR BRAKE DISASSEMBLY

Manually open the brake shoe and remove it.  
Remove the shoe spring from the brake shoe.



Loosen the rear brake arm fixing bolt.  
Remove the rear brake arm, rear brake indicator, brake cam, dust seal.  
Remove the rear brake cam.




## REAR BRAKE ASSEMBLY/INSTALLATION

Apply small amount of grease to the brake cam.  
Install the brake cam.  
Install the rear brake dust seal, indicator, rear brake arm.

### NOTE

- Align the punch marks of the brake arm and the brake cam before assembly.
- Remove the excessive grease after assembling the shoe.



Install the brake shoe and spring.  
Install the rear brake shoe to the rear brake cam.  
Install the rear wheel.  
Install the washer and U nut.

### NOTE

- Check the brake for smooth operation.







## REAR CUSHION

### REMOVAL

Remove the luggage box. (⇒3-3)

Loosen the top and bottom rear cushion setting bolts.



- Support the frame firmly prior to working.



### DISASSEMBLY

Install the compressor attachment as shown in the figure.

Install the cushion on the cushion compressor, and compress the spring.


**TOOLS : COMPRESSOR ATTACHMENT  
REAR COMPRESSOR**



Fix the bottom metal, and loosen the lock nut.

Remove the bottom metal.

Remove the stopper rubber, spring from the damper component.



### INSPECTION

Measure the rear cushion spring free length.

Check the damper rod for deflection or damage.

### REAR CUSHION ASSEMBLY/INSTALLATION

Assemble the spring, spring guide, and stopper rubber.


Apply thread locking agent to the lock nut, and install the rear cushion compressor attachment on the damper rod.

Fix the upper joint, and tighten the lock nut.

**TORQUE VALUE : 4.0kgf · m**

**TOOLS : REAR CUSHION COMPRESSOR**

**REAR CUSHION COMPRESSOR ATTACHMENT**




### INSTALLATION

Install the rear cushion.


Tighten the top and bottom of the cushion with bolt.

**TORQUE VALUE : UPPER SIDE 3.5kgf · m**

**LOWER SIDE 3.5kgf · m**



# BRAKE SYSTEM



---

# 12. BRAKE SYSTEM

<b>SERVICE INFORMATION . . .</b>	<b>12-1</b>	<b>BRAKE DISK INSPECTION . .</b>	<b>12-6</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>12-1</b>	<b>BRAKE CALIPER . . . . .</b>	<b>12-7</b>
<b>BRAKE FLUID/BLEEDING . .</b>	<b>12-3</b>	<b>MASTER CYLINDER . . . . .</b>	<b>12-9</b>
<b>BRAKE PAD REPLACEMENT . .</b>	<b>12-4</b>		

## SERVICE INFORMATION

### GENERAL SAFETY

- Do not allow foreign material to enter the system when replenishing brake fluid.
- To prevent chemical changes, do not mix different types of brake fluid.
- Do not use the old brake fluid again.
- Brake fluid can cause damage to painted, plastic, and rubber surfaces. Take precaution not to allow parts to be contaminated by the brake fluid.
- Do not reuse sealing washers.
- Clean the disassembled parts with brake fluid, and check for any clogged passage with compressed air.
- Bleed the brake hose after removing it.

## TROUBLESHOOTING

### HYDRAULIC DISK BRAKE

#### Braking power unsatisfactory

- Air in the brake system.
- Moisture in brake fluid
- Brake pad and disk contaminated.
- Caliper piston seal worn
- Master cylinder piston seal worn
- Brake pad worn
- Caliper inside contaminated
- Unsatisfactory caliper sliding part operation
- Lopsided wear of brake pad and disk
- Low brake fluid level
- Clogged brake fluid line
- Disk bent or distorted
- Caliper piston seized or worn
- Master cylinder piston seized or worn
- Disk worn
- Master cylinder inside contaminated
- Brake lever bent

#### Hard brake lever movement or unsatisfactory return

- Brake system clogged
- Caliper piston seized or worn
- Unsatisfactory caliper sliding part operation
- Brake fluid line clogged
- Caliper piston seal worn
- Master cylinder piston seized or worn
- Brake lever bent

#### Brake drag

- Brake pad and disk contaminated
- Improper wheel alignment
- Lopsided wear of brake pad and disk
- Disk bent or distorted
- Unsatisfactory caliper sliding part operation
- Hydraulic system contaminated with dust.

# **BRAKE SYSTEM**

---

## **MECHANICAL DRUM BRAKE**

### **Poor brake performance**

- Improperly adjusted brake
- Worn brake linings
- Worn brake drum
- Worn brake cam
- Improperly installed brake linings
- Brake cable sticking/needs lubrication
- Contaminated brake linings
- Contaminated brake drum
- Worn brake shoes at cam contact areas
- Improper engagement between brake arm and camshaft serrations

### **Brake lever hard or slow to return**

- Worn/broken return spring
- Improperly adjusted brake
- Sticking brake drum due to contamination
- Worn brake shoes at cam contact areas
- Brake cable sticking/needs lubrication
- Worn brake cam
- Improperly installed brake linings

### **Brake squeaks**

- Worn brake linings
- Worn brake drum
- Contaminated brake linings
- Contaminated brake drum

## BRAKE FLUID/BLEEDING

### BRAKE FLUID CHANGE

#### ⚠ CAUTION

- A contaminate disk or pad reduces braking power. Do not allow the disk or pad to be contaminated by oil.
- Replace contaminated pads, and remove pollutants from the disk completely.

#### ⚠ NOTE

- Check the brake fluid level often, and replenish new fluid as required. Do not spill fluid on painted, plastic or rubber parts.

Remove the front handle cover. (⇒3-6)

Remove the master cylinder cap, master cylinder holder, and diaphragm from the master cylinder.

Connect the bleeder hose to the bleeder valve. Loosen the bleeder valve, and pump the brake lever repeatedly.

When there is no more fluid flowing out of the bleeder valve, stop pumping the brake lever.

### AIR BLEEDING

Fill the reservoir with DOT 3 or 4 brake fluid up to the upper level.

#### ⚠ CAUTION

- To prevent chemical changed, do not use different types of brake fluid.

Connect the recommended brake bleeder to the bleeder valve.

Loosen the bleeder valve while pumping the brake lever.

Repeat this operation until the brake fluid flows out of the brake bleeder.




#### ⚠ NOTE

- Check fluid level often, and replenish fluid if the amount of fluid is reduced to the lower level.
- Read the user's manual carefully prior to disassembling or using the brake bleeder.
- Protect the bleeder valve with tape to prevent air from entering the bleeder valve.


Repeat the above operation until there is no air flowing out of the bleeder hose.

Squeeze the bleeder valve and operate the brake lever to check the ingress of air.

Add brake fluid.



## BRAKE SYSTEM



If the brake bleeder is not used, do the following.  
First, fill the brake fluid up to the upper limit line.  
Connect the hose to the bleeder valve to receive brake fluid.

Squeeze the brake lever completely loosen the bleeder valve 1/2 turn, and tighten it again.

### ⚠ NOTE

- Do not release the brake lever until the bleeder valve is tightened.

Release the brake lever slowly to its fullest extent, and leave it unattended for a few seconds.

Repeat the process specified in item and until there is no more air bubbles coming out of the bleeder valve.

Check the fluid level often, and add fluid if the fluid level is near the lower level.

If no air leaks out of the bleeder hose, operate the brake lever to check the presence of air.

Assemble the bleeder valve.

**TORQUE : 0.6kgf · m**

Add brake fluid up to upper level. Install diaphragm and master cylinder cap.

**TORQUE VALUE : 1.0kgf · m**

## BRAKE PAD REPLACEMENT



### ⚠ NOTE


- When replacing brake pads, replace whole set.
- Do not remove the brake hose when replacing brake pads.

Loosen the hanger pin.


Loosen the 2 front brake caliper fixing bolts from the front fork.

Remove the front caliper.







To install a new brake pad into the brake, press the piston to return to the original position.  
Remove the hanger pin, pad shim, and brake pad.



Verify that the pad spring is installed in specific position.



Install a new brake pad, pad shim, and hanger pin.



Install the brake caliper into the left front fork.

**NOTE**


- Be careful not to damage the brake pad.

Tighten the caliper bracket bolt.

**TORQUE : 2.7kgf · m**



# BRAKE SYSTEM



Tighten the hanger pin.




## BRAKE DISK INSPECTION

Measure the thickness of the disk.

**SERVICE LIMIT : 3.0mm**

### ⚠ NOTE

- Measure the brake disk thickness at the several points and replace if the smallest measurement is less than the specified service limit.




Check the brake disk for bent and twist.

**SERVICE LIMIT : 0.4mm**

### ⚠ NOTE

- Replace the brake disk if the disk for damage or cracks.




## BRAKE CALIPER

### REMOVAL


Remove the brake oil bolts and the brake hose from the brake caliper.

Remove the caliper from the L. front fork and remove the pad spring, hanger pin and brake pad.



## ⚠ CAUTION

- Pay attention not to let the brake fluid adhere to the parts because it can damage the painted surface.
- Wind the hose joint with cloth to prevent the brake fluid from leaking.
- Clean the removed parts with the brake fluid and make sure that the each port isn't clogged with the compressed air.
- Keep the removed parts in order to avoid dust from adhering.



## DISASSEMBLY

Remove the slide pin, the L. bracket, the pin bush, the boot and the pin bolt from the caliper. If there is any wear or damage in the boot, replace it with the new one.


Wind the caliper with cloth to prevent the piston or brake fluid from leaking.

Remove the piston from the caliper while blowing the low-pressure air in the opening of the brake hose.

## ⚠ CAUTION

- Never use the high-pressure air or bring the air gun too close.
- Never touch the inside of the caliper

Disassemble the piston seal and the dust seal



## ⚠ NOTE

- Pay attention not to damage the inner surface of the caliper.

Clean the piston and the inside of the caliper and remove the oil from the seal groove.

## BRAKE CALIPER INSPECTION


### Caliper Cylinder

Check the caliper cylinder bore for scoring, scratches or other damage.


Measure the caliper cylinder I.D. in X and Y axis at several points.

Replace the caliper cylinder if the largest measurement is beyond the specified service limit.

**SERVICE LIMIT : 27.10 mm**




# BRAKE SYSTEM



## Caliper Piston

Measure the caliper piston O.D. in X and Y axis at several points.  
Replace the caliper piston of the smallest measurement is less than the specified service limit.

**SERVICE LIMIT : 26.84 mm**




## BRAKE CALIPER ASSEMBLY/INSTALLATION


Clean the piston seal and the dust seal with the brake fluid and install them in the caliper. Install the piston in the caliper with the groove side of the piston facing the pad.

### NOTE

- Make sure that each part is free from dust or dirt before reassembly.
- Replace the dust seals and piston seals as a set whenever they are removed.
- When cleaning with the brake fluid, use the specified brake fluid.



Apply the silicone grease to the pin bush.  
Connect the pin bush to the portion of the caliper.  
Install the pad spring in the caliper.  
Install the caliper pin bolt and the slide pin in the caliper.  
Install the brake pad and the hanger pin in the caliper.



Connect the brake hose to the caliper, and install 2 sealing washers and the brake hose bolt.

**TORQUE : 3.5kgf · m**

Install the slide pin cap.  
Fill the brake fluid, and bleed air.

## MASTER CYLINDER

### REMOVAL

- Remove the back mirror.
- Remove the front handle cover. (⇒3-6)
- Remove the rear handle cover. (⇒3-6)
- Disconnect the front brake switch wire.
- Drain the brake fluid.
- Remove the brake hose from the master cylinder.

### ⚠ CAUTION

- Brake fluid causes damage to the painted, plastic or rubber parts. Do not spill fluid on these parts.
- If contaminated, gently wipe off the fluid with a piece of cloth or wash in water. Close hose joints properly to prevent leakage of brake fluid.
- Clean the disassembled parts with brake fluid, and use compressed air to verify each passage is not clogged.
- Do not allow the disassembled parts to be contaminated by waste material or dust.

Remove the master cylinder holder, and lift out the master cylinder.

### DISASSEMBLY

- Remove the front stop switch.
- Remove the piston boot, cir clip from the master cylinder.




#### TOOL : SNAP RING PLIERS

- Remove the washer, piston, spring from the master cylinder.
- Clean the master cylinder, reserve, master piston with the recommended brake fluid.


### MASTER CYLINDER INSPECTION

- Check the piston periphery for kink or scratch.
- Check the primary and secondary cups for wear.
- Measure the O.D of the master pin

**SERVICE LIMIT : 10.90 mm**



# BRAKE SYSTEM




## NOTE

- If there is any leak of fluid when installing new piston, it may indicate the side wear of the cylinder by the direction of the piston contacting face. In this case, the master cylinder must be replaced also.

Check the master cylinder for scores, scratches or nicks and replace if necessary. Measure the master cylinder I.D. in X and Y axis at several points.

**SERVICE LIMIT : 11.08 mm**


## MASTER CYLINDER ASSEMBLY/INSTALLATION



## CAUTION

- Replace the piston, spring, cups and snap ring as a set.
- Be sure that each part is free from dust or dirt before reassembly.
- When cleaning with the brake fluid, use the specified brake fluid.

Coat the piston cup with the fresh brake fluid and install it on the piston. Install the spring with its larger diameter end toward the master cylinder.




## CAUTION

- When installing the cups, do not allow the lips to turn inside out. (Refer to the drawing.)
- Note the installation direction of the snap ring.
- Be certain that the snap ring is seated firmly in the groove.

Install the rubber boot in the groove properly.

**TOOL : SNAP RING PLIERS**



Install the master cylinder to the handle bar.

## NOTE

- Install the holder with its "UP" mark facing upwards, and align the holder joint with the punch mark on the handle bar.
- Tighten the holder upper bolt first.



Install the brake hose to the master cylinder with 2 new sealing washers and the hose bolt.

**TORQUE VALUE : 3.5kgf · m**

Connect the brake stop switch wire.

Fill the brake fluid, and bleed air.

Install the rear handle cover. (⇒3-6)

Install the front handle cover. (⇒3-6)

Install the back mirror.

---

# MEMO

---

# 13. BATTERY/CHARGING SYSTEM

<b>SERVICE INFORMATION . . . . .</b>	<b>13-1</b>	<b>CHARGING SYSTEM INSPECTION .</b>	<b>13-4</b>
<b>CHARGING DEVICES LOCATION .</b>	<b>13-2</b>	<b>HEADLIGHT VOLTAGE INSPECTION .</b>	<b>13-6</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>13-3</b>	<b>REGULATOR/RECTIFIER INSPECTION .</b>	<b>13-6</b>
<b>BATTERY REMOVAL/INSTALLATION .</b>	<b>13-4</b>	<b>A.C. GENERATOR . . . . .</b>	<b>13-7</b>
<b>BATTERY INSPECTION . . . . .</b>	<b>13-4</b>	<b>RESISTER INSPECTION . . . . .</b>	<b>13-9</b>

## SERVICE INFORMATION

### WARNING

- Do not place flammable materials near battery when charging. This can be a fire hazard as hydrogen gas is created during charging battery.
- Do not allow battery acid to come into contact with clothes, skin or eyes. Battery acid contact can cause burns or loss of eye sight. If contact occurs, thoroughly clean with water, and if acid enters eyes, flush with water and see a doctor.
- If battery acid gets on clothing, as it can seep through or make a hole through the clothing and make its way to the skin, make sure to change clothing that has come into contact with battery acid and wash the battery acid from the clothes.

### CAUTION

- This vehicle has a maintenance-free(MF) battery. Because MF batteries use different charging equipment, take special care when performing maintenance and especially when replacing parts. Not all regular battery equipment is compatible with MF batteries.
- When charging the battery, remove the battery from the frame and do not open stopper.
- There is the possibility of damaging the regulator/rectifier, etc. if the terminal or coupler is separated/connected when electricity is over flowing through the electrical devices. Make sure to turn the main switch OFF when performing maintenance to the charging equipment.

If the battery is allowed to repeatedly lose all its charge, is repeatedly over-charged, or if it is left in an un-charged state, the battery can be damaged, its life can be reduced, or it can lose some of its strength. It is important to note here that the battery will naturally last 2-3 years of normal use, and although it will re-charge, its load is reduced, leading to a loss in battery strength.

It is possible for the battery to become overcharged from battery body load. If a battery cell becomes short-circuited and if a state develops where voltage is not created between the terminals, the regulator will not operate and excessive voltage will develop in the battery and normal cell electrolytes will decrease.

If the vehicle is not used for a long period, make sure to charge the battery every three months. If not so, the battery ability to store electricity is reduced.

A new MF battery will not necessarily be ready for use in the vehicle with only the adding of battery acid. Make sure to charge battery after the adding of battery water in the following instances :

-When open voltage (voltage between terminals) does not reach 12.4V after the adding of battery water : charge until open voltage reaches at least 12. 8V.

-When battery acid temperature is under 0°C : charge normally for 2-3 hours.

See the part location drawing for the location of charging system parts. (⇒13-2 )



Follow the trouble shooting for charging equipment inspection. (⇒13-3 )

The charging equipment may often appear to be malfunctioning if the couplers or connectors are incorrectly attached. Make sure to check these connections before starting maintenance work on the charging equipment.



# CHARGING SYSTEM / AC GENERATOR

## CHARGING DEVICE LOCATION





# TROUBLESHOOTING

## Battery is Overcharged

- Headlight bulb is out.
- No headlight beam wire.
- Headlight register is damaged (disconnected).
- Lighting switch is connected incorrectly.
- Regulator/rectifier is not grounded or connected incorrectly.

## Problems with the Charging System





## BATTERY REMOVAL/INSTALLATION

Loosen the battery cover setting bolt.  
Remove the battery cover.  
After removing the negative “-” terminal of battery firstly, must remove the positive “+” terminal of battery.  
Install in the reverse order of removal.

## BATTERY INSPECTION CHARGE LEVEL (OPEN-CIRCUIT VOLTAGE) INSPECTION

Remove the battery cover and disconnect the battery terminals.  
Measure the voltage between the battery terminals.

- FULLY CHARGED : 13.0-13.2V
- INSUFFICIENTLY CHARGED : Under 12.3V

### ⚠ NOTE

- Use a digital voltmeter when measuring charge level.

Measure 30minutes later.

TOOL : DIGITAL CIRCUIT TESTER

## CHARGING SYSTEM INSPECTION LEAK TEST

Trun off the main switch, and remove the earth cable from the battery. Connect an ampere meter between the battery terminal and the earth cable, and check current when the main switch is turned off.

### ⚠ CAUTION

- Use an ampere meter while sequentially changing its measuring range from large to small. If the current level greater than the measuring limit is measured, the ampere meter fuse may be cut.
- Do not turn on the main switch while current is being measured.

LEAK CURRENT : Not to exceed 1mA


## BATTERY ADJUSTMENT VOLTAGE CHECK




Connect the voltmeter between the battery terminals.  
Connect the amperemeter between the main fuse termanals.  
Start the engine and measure the charging voltage and ampere while increasae the rpm gradually.

CONTROL VOLTAGE (CHARGING SIDE) :  $14.5 \pm 0.5V/5,000rpm$   
(LAMP SIDE) :  $13.1 \sim \pm 0.5V/5,000rpm$

### ⚠ NOTE

- Check with fully charge the battery which has the voltage between terminal of 12.8~13.0V.
- In case that the engine is started by the starter motor, measurement must be performed after accelating (charging) for 10 seconds.





## CHARGING VOLTAGE CHECK

Use the full charge battery (12.8~13.2V)

In case that charging the voltage is not controlled properly, the battery cannot be used due to the battery solution dried up by over charging and the deformation caused by the damage of the plates.

Battery control voltage :  $14.5 \pm 0.5V$ (5,000rpm)

### NOTE

- If you have 1EA of tester, measure current first.

## CHARGING CURRENT CHECK

Check the charging current passed through the generator assy, regulator comp is normal with the discharged battery.

**CHARGING CURRENT : 1.5~2.4A/5,000rpm**

**TOOL : DIGITAL CIRCUIT TESTER**

## BATTERY CHARGING

Remove the battery from the frame, and connect it to the battery charger.

- Connect the charger positive (+) cable to the battery positive (+) terminal.
- Connect the charger negative (-) cable to the battery negative (-) terminal.

### NOTE

- Do not connect the charger to the battery coupler terminals.

Never open the sealed filler cap.

### WARNING


- The battery generates hydrogen gas which can be highly explosive. Do not smoke or allow flames or sparks near the battery, especially while charging it.
- Turn power ON/OFF at the charger, not at the battery terminals. If the cable is disconnected or connected at the battery terminal during charging, spark may jump and ignite the flammable gas.
- Always remove the battery from the frame when charging it. If the battery is charged while installed in the frame, the electrolyte may spill and corrode the frame components.

**CHARGING CURRENT : 0.3A**

**CHARGING TIME : 8~10h**

### WARNING

- Do not let the electrolyte temperature rise above  $45^{\circ}C$  ( $113^{\circ}$ ). If the electrolyte temperature becomes too high, lower the charging current.
- Quick-charging will shorten the battery life and cause battery damage. It should only be done in emergency; slow-charging is preferred.



## HEADLIGHT VOLTAGE INSPECTION

Remove the front cover. (⇒3-5)

**CAUTION**

- Check voltage with the headlight coupler connected.

After starting the engine, place the dimmer switch to HI and check the voltage between the blue (+) and green (-) wires of the headlight coupler.

**CAUTION**

- Measurement is performed in AC area.

**CONTROL VOLTAGE : 12.6~13.6V/5,000rpm**

If voltage is incorrect, check the regulator/rectifier.

## REGULATOR/RECTIFIER INSPECTION


### HARNESS CIRCUIT INSPECTION

Remove the front cover. (⇒3-5)

Remove the 4P coupler of the regulator/rectifier and inspect the wiring circuit in the main harness side terminal.

ITEM	MEASUREMENT LOCATION	LEVEL	AREAS OF INSPECTION IF INCORRECT
BATTERY WIRE	Voltage between red “ ” and green “ ”.	There must be battery voltage.	Damaged, disconnected main fuse/harness.
CHARGING COIL	Resistance between white wire and earth wires. Disconnect the starter.	0.4~1.0 (20°C)	AC generator (charging, lighting coil coupler connection damage) resister(6.7 5W) headlight lighting circuit.
LIGHTING COIL	Resistance between yellow wire and earth wires. Disconnect dimmer switch connection	0.2~0.8 (20°C)	

Inspect part after at least 10 minutes later.



## REGULATOR/RECTIFIER INSPECTION

If the inspection of the harness side proves to be satisfactory, check the regulator/rectifier coupler for faulty connection, and measure the resistance between the terminals of the regulator/rectifier.

### RESISTANCE VALUE

Tester	A	L	B	E
A			3-50	
L				5-100
B				
E		5-100		

## A.C. GENERATOR

### REMOVAL

- Remove the luggage box. (⇒3-3)
- Remove the plug maintenance cover. (⇒3-3)
- Remove the center cover. (⇒3-3)
- Remove the floor side cover. (⇒3-4)
- Remove the floor panel. (⇒3-4)
- Remove the engine hanger side RH. cover. (⇒3-5)
- Remove the plug cap.
- Loosen the 3 washer screws, remove the fan cover and the fan cover element A,B.
- Remove the fan cover rubber.
- Loosen the 2 flange bolts, remove the fan cover.
- Loosen the 4 cooling fan fixing flange bolts, remove the cooling fan.
- Hold the flywheel with a universal holder.

#### TOOL : UNIVERSAL HOLDER

Remove the flywheel with a ACG rotor puller.





#### TOOL : ACG ROTOR PULLER 0750-00004

Remove the connector/coupler on the wire harness or starter motor. Remove the ground wires.

- Loosen the 2 pulse generator fixing flange bolts, remove the pulse generator.
- Loosen the 2 stator fixing flange bolts.
- Remove the grommet from the crankcase cover.
- Remove the stator.


#### ⚠ NOTE

- Insert the puller shaft and remove the flywheel after inserting the ACG rotor puller and securing it with spanner.
- The flywheel may easily removed if you rotate the puller while tapping the roller shaft with metal hammer.
- Always use a holder and a puller to remove the flywheel. Do not try to remove the flywheel by hammering directly on it. The crankshaft or components could be damaged.
- Remove the woodruff key with care not to lose it.




## STATOR INSTALLATION

Note the direction of stator, and install the stator on the crankcase.  
Install the grommet to R. crankcase cover.  
Install AC generator wire coupler to wire harness.  
Install the connector to starter motor, then install the ground wire.



## FLYWHEEL INSTALLATION

Clean the tapered portion of the crankshaft.  
If the flywheel is installed with dust or dirt on the taper, the taper will not make secure contact with the flywheel and there will be excessive force on the woodruff key.  
Insert the woodruff key into the key groove in the crankshaft.  
Set the flywheel groove to the woodruff key and install the flywheel on the crankshaft.




### ⚠ CAUTION

- Before installing the flywheel, check that no nuts or bolts are magnetically attached to the flywheel. Installing the flywheel with anything attached to it could damage the stator coil.

Hold the flywheel rotor with a holder and tighten the bolt (nut) to the specified torque.



Install the cooling fan.  
Install the fan cover.  
Install the luggage box. (⇒3-3)



## A.C. GENERATOR(CHARGING COIL) INSPECTION



### ⚠ NOTE

- This test is done with the starter mounted to the engine.

Remove the center cover.  
Disconnect the AC generator coupler. (⇒3-3)  
Measure the resistance of the charging coil (between the white wire and ground) and the lighting coil (between the yellow wire and ground).

**STANDARD RESISTANCE (20°C)**  
**BETWEEN WHITE WIRE AND GROUND : 0.4~1.0 Ω**  
**BETWEEN YELLOW WIRE AND GROUND : 0.2~0.8 Ω**

## RESISTER INSPECTION



Remove the front cover. (⇒3-5)  
Measure the resistance between the resistor lead wire and ground.

**STANDARD VALUE (20°C)**  
**RESISTER (6.7 Ω 5W) GREEN/BLACK/BODY GROUND : 6.3~7.1 Ω**  
**RESISTER (5.9 Ω 30W) PINK/BODY GROUND : 5.6~6.5 Ω**

### ⚠ NOTE

- Problems with the resistor are caused by operational problems of the starter.



---

# MEMO

---

---

# 14. IGNITION SYSTEM

<b>SERVICE INFORMATION . . . . .</b>	<b>14-1</b>	<b>EXCITE COIL INSPECTION . . . . .</b>	<b>14-6</b>
<b>IGNITION DEVICES LOCATION .</b>	<b>14-2</b>	<b>PULSE GENERATOR INSPECTION .</b>	<b>14-6</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>14-3</b>	<b>IGNITION TIMING INSPECTION .</b>	<b>14-7</b>
<b>IGNITION SYSTEM INSPECTION (PEAK VOLTAGE MEASUREMENT) .</b>	<b>14-4</b>	<b>CDI UNIT . . . . .</b>	<b>14-7</b>
<b>IGNITION COIL . . . . .</b>	<b>14-5</b>	<b>SIDE STAND IGNITION CUT-OFF SWITCH . . . . .</b>	<b>14-8</b>

## SERVICE INFORMATION

### GENERAL SAFETY

Refer to the malfunction diagnosis when inspecting ignition devices.

Because the ignition devices have installed electrical advancer devices, it is impossible to adjust ignition timing.

Be careful when handling the ignition devices as they can become easily damaged if dropped or bumped. Also, do not disconnect or connect the connectors and couplers when the main switch is turned ON as excessive electric current can cause damage in the unit. Always perform maintenance work on the ignition devices with the main switch turned OFF.

Ignition devices can often appear to be malfunctioning when the couplers or connectors are disconnected. Check these connections before working on.



Use recommended spark plug. Using incorrect spark plug may make the engine run badly or damage the engine.

This manual gives explanations on inspections to receive peak voltage. As inspections for coil resistance values are also included, it may be difficult to make a correct determination.

Conduct inspection on the main switch by referring to the wiring diagram continuity chart. (⇒chapter 16)

# IGNITION SYSTEM

## IGNITION DEVICES LOCATION




# TROUBLESHOOTING

Spark plug does not emit sparks.

	<b>ABNORMAL STATE</b>	<b>POSSIBLE CAUSES (START FROM 1 AND GO THROUGH LIST IN ORDER)</b>
<b>IGNITION COIL PRIMARY VOLTAGE</b>	Maximum voltage is low.	<ol style="list-style-type: none"> <li>1. Using a tester with a low internal resistance.</li> <li>2. Cranking speed is low.     Battery is low or kick power is weak.</li> <li>3. Influence of tester sampling time (normal state if measured a number of times and shows over the set voltage).</li> <li>4. Problem in ignition system wiring (disconnected, damaged).</li> <li>5. Ignition coil is damaged.</li> <li>6. Excite coil is damaged (measure peak voltage).</li> <li>7. CDI unit is damaged (when no problems in 1~6 and spark plug does not emit sparks)</li> </ol>
	No, or almost no peak voltage.	<ol style="list-style-type: none"> <li>1. Adaptor is connected incorrectly.</li> <li>2. Main switch damaged.</li> <li>3. CDI unit coupler is connected incorrectly.</li> <li>4. CDI unit ground wire disconnection.</li> <li>5. Damage to excite coil (measure peak voltage).</li> <li>6. Pulse generator is damaged (measure peak voltage).</li> <li>7. Peak voltage adaptor is damaged.</li> <li>8. CDI unit is damaged (when no problems in 1~7 and no sparks emitted from spark plug).</li> </ol>
	Spark plug peak voltage is normal but spark plug does not emit sparks.	<ol style="list-style-type: none"> <li>1. Damage to spark plug or leakage of ignition coil secondary current.</li> <li>2. Damaged ignition coil.</li> </ol>
<b>EXCITE COIL</b>	Peak voltage is low.	<ol style="list-style-type: none"> <li>1. Using a tester with a low internal resistance.</li> <li>2. Cranking speed is too low.     Battery is insufficiently charged or kick power is weak.</li> <li>3. Influence of tester sampling time (normal state if measured a number of times and shows over the set voltage)</li> <li>4. Excite coil is damaged (when 1~3 is okay).</li> </ol>
	No, or almost no peak voltage.	<ol style="list-style-type: none"> <li>1. Peak voltage adaptor is damaged.</li> <li>2. Excite coil is damaged.</li> </ol>
<b>PULSE GENERATOR</b>	Maximum voltage is low.	<ol style="list-style-type: none"> <li>1. Using a tester with a low internal resistance.</li> <li>2. Cranking speed is too low.     Battery is insufficiently charged or kick power is weak.</li> <li>3. Influence of tester sampling time (normal state if measured a number of times and shows over the set voltage).</li> <li>4. Pulse generator is damaged (when 1~3 is okay).</li> </ol>
	No, or almost no maximum voltage.	<ol style="list-style-type: none"> <li>1. Maximum voltage adaptor is damaged.</li> <li>2. Pulse generator is damaged.</li> </ol>

## IGNITION SYSTEM INSPECTION (PEAK VOLTAGE MEASUREMENT)




### ⚠ NOTE

- When sparks are not emitted from spark plug, after checking for disconnection in wires and looseness, measure peak voltage for each wire.

Connect the peak voltage adaptor to the digital tester.

### DAELIM PVA MULTI TESTER

## IGNITION COIL PRIMARY VOLTAGE



### ⚠ NOTE

- Make sure each wire is correctly connected to ensure correct measurement.
- Inspect when there is cylinder compression pressure and with the spark plug cap securely connected to the spark plug.

Remove the luggage box. (⇨3-3)

With the ignition coil wire connected, contact the peak voltage adaptor to the initial wire adaptor terminal (black/yellow) and ground (on vehicle body.). Turn the main switch ON, operate the starter motor, and measure the ignition coil initial side peak voltage.

**CONTACT POINTS : BLACK/YELLOW TERMINAL " " -BODY EARTH " "**  
**PEAK VOLTAGE : OVER 120V**

### ⚠ CAUTION

- When measuring voltage, do not touch the metal part of the handle rod as there is the danger of receiving an electric shock.

## EXCITE COIL

### ⚠ CAUTION

- Assemble the spark pug to the cylinder head, inspect in a state having compression pressure.

Remove the luggage box. (⇨3-3)

Remove the CDI unit. (⇨14-7)


Remove the coupler from the CDI unit contact the peak voltage adaptor to the excite coil wire (black/red and green) of the harness side coupler.

Operate the starter motor and measure the excite coil peak voltage.


**CONTACT POINTS : BLACK/RED TERMINAL " " -BODY EARTH " "**  
**PEAK VOLTAGE : OVER 120V**

### ⚠ CAUTION

- When measuring voltage, do not touch the metal part of the handle rod as there is the danger of receiving an electric shock.



## PULSE GENERATOR



### NOTE

- Inspect with the spark plug assembled and while there is compression pressure.

Remove the CDI unit. (⇒14-7)

Remove the coupler from the CDI unit and connect the peak voltage adaptor to the pulse generator wire (blue/yellow and green) of harness coupler.

Operate the starter motor and measure the peak voltage of the pulse generator coil.

**CONTACT POINTS : BLUE/YELLOW TERMINAL “ ”-BODY EARTH“ ”**  
**PEAK VOLTAGE : OVER 1.5V**

### CAUTION

- When measuring voltage, do not touch the metal part of the handle rod as there is the danger of receiving an electric shock.



Perform the following inspections if measured peak voltage in the CDI unit coupler portion is abnormal.

Disconnect the AC generator cord coupler and connect the adaptor.

In the same manner as with the unit coupler side, measure peak voltage and compare with the first peak voltage.

When the measured value in the unit side is abnormal and normal in the pulse generator side, the problem is either incorrect coupler connection or disconnection of the wire harness.

When both measurements are abnormal, this indicates a problem with the pulse generator. Refer to the malfunction diagnosis are go through each step.



## IGNITION COIL

### REMOVAL/INSTALLATION

- Remove the luggage box. (⇒3-3)
- Remove the plug maintenance cover.
- Remove the spark plug cap.
- Loosen the ignition coil fixing bolt.
- Disconnect the ignition coil wire.
- Remove the ignition coil.
- Install in the reverse order of removal.

### CAUTION

- Arrange the cords in the right place.

### INSPECTION (RESISTANCE MEASUREMENT)

Remove the luggage box. (⇒3-3)

Measure primary coil resistance between the green and black/yellow terminals.

**STANDARD VALUE : 0.1~0.5 Ω (20°C)**

## IGNITION SYSTEM



Measure the secondary coil resistance between the plug cap and green wire terminals.

**RESISTANCE VALUE  
(SPARK PLUG CAP CONNECTION) : 6.5~9.5 k $\Omega$  (20°C)**

The coil which the resistance value indicate “ ”(disconnection) remove the plugcap, and measure the resistance of secondary coil.

Measure the resistance between the high tension code and green code terminals.

**RESISTANCE VALUE : 2.6  $\pm$ 1.25 k $\Omega$  (20°C).**

## EXCITE COIL INSPECTION

### ⚠ NOTE

- Assembly the spark plug to the cylinder head, and inspect in an state having compression pressure.

Remove the luggage box. (⇨3-3)

Remove the connection of the AC Generator wire connector (black/red), measure the resistance between the terminal of AC generator and body earth.

**STANDARD VALUE : 500  $\Omega$   $\pm$ 20% (20°C)**



## PULSE GENERATOR INSPECTION

### ⚠ NOTE

- The inspection of pulse generator is performed in a state assembling to the engine.

Remove the luggage box. (⇨3-3)

Remove the connection of the AC generator 6P coupler, and measure the resistance between the blue/yellow of starter and green code.


**STANDARD VALUE : 100  $\Omega$   $\pm$ 20% (20°C)**




## IGNITION TIMING INSPECTION

### ⚠ NOTE

- As a CDI device is used in this vehicle, there is no need for adjusting ignition timing. If ignition timing problems occur, inspect the CDI unit and the AC generator and replace if any malfunctions are found in the devices.
- Ignition timing inspection well read the instruction manual of timing light or revolution-indicator, and handle it exactly.





Warm up the engine.  
 Remove the center cover.  
 Remove the floor panel.  
 Remove the fan cover.  
 Connect timing light to the high-tension cord.  
 When engine rpms are at 1,800, ignition timing is correct if the "F" mark and crank case index mark are aligned.

**IGNITION TIMING : 17 DEGREES  $\pm$  2 BTDC/1,800 rpms**


**NOTE**

- Index mark must face the spark plug.

## CDI UNIT


### REMOVAL/INSTALLATION

Remove the luggage box. (⇒3-3)  
 Disconnect the coupler from the CDI unit and remove CDI Unit.  
 Install in the reverse order of removal.



### CIRCUIT INSPECTION

Remove the coupler from the CDI unit, and check the ignition system circuits from the wiring coupler side.



INSPECTION ITEM	CHECK POINT	STANDARD VALUE
PULSE GENERATOR	BLUE/YELLOW AND GREEN	50~200 $\Omega$ (20°C)
IGNITION COIL		
-PRIMARY COIL	BLACK/YELLOW AND GREEN	0.1~0.5 $\Omega$ (20°C)
-SECONDARY COIL	GREEN AND HIGH-TENSION CORD	
	(ATTACH THE PLUG CAP)	6.3~10.3K $\Omega$ (20°C)
	(DETACH THE PLUG-CAP)	3.3 $\pm$ . K $\Omega$ (20°C)

### TESTING BY CDI TESTER

Check the CDI unit spark performance by using a CDI tester.


**NOTE**

- Read tester manual carefully prior to using the tester.

## SIDE STAND IGNITION CUT-OFF SWITCH




### INSPECTION

Remove the plug maintenance cover/ center cover. (⇒3-3)  
 Remove the coupler of the side stand switch.  
 Check for continuity between the terminal as shown below:





# IGNITION SYSTEM



ITEM	TERMINAL	SPECIFICATION
ON (Side stand is Retracted)	BLACK/WHITE AND GREEN	NO CONTINUITY
OFF (Side stand is Lowered)	BLACK/WHITE AND GREEN	CONTINUITY

## REMOVAL

- Remove the floor side cover. (⇒3-4)
- Remove the plug maintenance cover/ center cover. (⇒3-3)
- Remove the side stand switch mounting 2 bolts.
- Release the wire clamps and remove the side stand switch.

## INSTALLATION

- Install in the reverse order of removal.

---

# 15. STARTING SYSTEM

SERVICE INFORMATION . . . . .	15-1	STARTER MOTOR . . . . .	15-4
STARTING DEVICES LOCATION .	15-2	STARTER RELAY INSPECTION . .	15-7
TROUBLESHOOTING . . . . .	15-3	STARTER PINION GEAR INSPECTION . .	15-7

## SERVICE INFORMATION

### GENERAL SAFETY



**⚠ WARNING**

· When performing maintenance on the starter motor and related parts, turn the main switch to OFF. There is the danger of the starter motor unexpectedly operating if the main switch is not turned to OFF.

First check connection with battery and battery charge level before beginning maintenance on the starter motor. It is possible for the starter motor coil to become damaged if the starter is operated when the engine does not turn over.

# STARTING SYSTEM


## STARTING DEVICES LOCATION



# TROUBLESHOOTING

## Starter motor does not rotate (No response from starter motor).

- Check to see if the fuse is burned out.
- Check to turn on the lamp of stop switch.



## Starter motor rotates but crank shaft doesn't

- Incorrect starting clutch.
- Incorrect starter gear.
- Starting clutch slip

## Starter motor operates in free-wheel

- Internal fault of starter motor
- Driven gear slips.

## Weak rotational power in starter motor

- Battery is insufficiently charged.
- Incorrect connection of battery terminal cord.
- Damaged starter motor.
- Ground wire is connected incorrectly
- Brush is damaged or worn.

## Starter motor and crank shaft rotate but does not turn engine over.

- Incorrect starting system.
- Faulty engine.

## STARTER MOTOR

### REMOVAL/INSTALLATION

- Remove the luggage box. (⇒3-3)
- Remove the center cover. (⇒3-3)
- Remove the floor side RH. cover. (⇒3-4)
- Disconnect the starter wire connector, remove the wire from the wire fixing clamp.
- Loosen the 2 starter motor fixing bolts.
- Remove the starter motor.
- Install in the reverse order of removal.

**⚠ NOTE**

- Accurately tighten the earth wire.
- Turn off the main switch prior to servicing the starter motor. If power is connected, the starter motor may be activated and damaged.

### DISASSEMBLY

- Remove the starter motor screws and remove the motor cover.

**⚠ NOTE**



- Record the order so the parts can be installed correctly later.

### INSPECTION

- Check for continuity of the starter motor case.
  - Between cord terminal“ ” and bracket“ ”: normal if no continuity.
  - Between cord terminal and brush (black wire) : normal if there is continuity.
- If abnormal, replace with a new one.

Measure the brush length. Replace the brush if it is worn beyond the service limit.


**SERVICE LIMIT : 3mm**





Check the commutator for :

- Damage or abnormal wear. Replace with a new one.
- Discoloration of the commutator bar. Replace with a new one.
- Metallic debris between commutator bars. Clean it off.



Check for continuity between pairs of commutator bars.


Make a continuity check between individual commutator bars and the armature shaft.

There should be no continuity.



Check the bearings.

- Do not rotate smoothly. Replace with a new one.
- Loose bearing. Replace with a new one.



## STARTER MOTOR ASSEMBLY

Carefully insert the armature shaft into the front bracket.

Align the front bracket notch with the brush.

**CAUTION**

- The sliding surfaces of the brushes can be damaged if they are not installed properly.

## STARTING SYSTEM




Insert the brush spring into the brush holder and install the front bracket.

 **NOTE**

- Insert the brush spring with care so that it does not lean in the holder.



Apply grease to both ends of the armature shaft.



Install the starter motor cover.


 **NOTE**

- The coil may be damaged if the magnet pulls the armature against the case.



Align the front bracket with the cover.  
Tighten the washer screw.

## STARTER RELAY INSPECTION



Remove the luggage box. (⇒3-3)

When battery voltage is applied between the starter relay green/yellow wire and yellow/red terminals, there should be continuity between the red and red/white terminals. The terminals are distinguished by the corresponding wire color of the wire harness connector.


## STARTER PINION GEAR INSPECTION

Remove the L. side cover. (⇒7-2)

Remove the drive face. (⇒7-6)

Remove the starter pinion gear.

Install in the reverse order of removal.




## INSPECTION

Wear or damage to the pinion, reduction gears.

Replace with a new one.

Worn journals. Replace with a new one.



Check if the pinion gear moves smoothly along the axis.

Pinion gear does not move smoothly. Replace with a new one.





---

# MEMO

---

---

# 16. LIGHTS/METER/SWITCHES

<b>SERVICE INFORMATION . . . . .</b>	<b>16-1</b>	<b>HANDLE SWITCH INSPECTION .</b>	<b>16-4</b>
<b>TROUBLESHOOTING . . . . .</b>	<b>16-1</b>	<b>FRONT STOP SWITCH INSPECTION .</b>	<b>16-4</b>
<b>FUEL UNIT . . . . .</b>	<b>16-2</b>	<b>BULBS REPLACEMENT . . . . .</b>	<b>16-5</b>
<b>OIL LEVEL SWITCH . . . . .</b>	<b>16-3</b>	<b>METER REPLACEMENT . . . . .</b>	<b>16-6</b>
<b>MAIN SWITCH . . . . .</b>	<b>16-3</b>	<b>HORN INSPECTION . . . . .</b>	<b>16-7</b>

## SERVICE INFORMATION

### GENERAL SAFETY

Refer to tester owner's manuals when performing continuity inspections.  
Refer to wiring diagram (chapter 17) for switch continuity.  
After inspecting and/or performing maintenance work make sure the wires and cables are properly placed and connected.

## TROUBLESHOOTING

### Fuel meter indicator malfunctioning

- Coupler separated.
- Harness disconnected.
- Float operation malfunction.
- Fuel unit damaged.
- Meter damaged.

### Fuel meter needle unstable

- Coupler loose.
- Fuel unit damaged.
- Meter damaged.

### Headlight hi-lo not operating





- Bulb malfunction.
- Dimmer switch damaged.

### Oil indicator light not operating (when there is oil).

- Burned out fuse.
- Battery insufficiently charged.
- Main switch damaged.
- Meter damaged.
- Oil level switch damaged.
- Loose connector.
- Harness disconnection.

### Oil indicator does not turn off (when oil is out)

- Oil level switch damaged.
- Green/red wire joined.



## FUEL UNIT

### REMOVAL

- Remove the luggage box. (⇔3-3)
- Remove the fuel unit wire from the wire harness.
- Turn the fuel unit fixing unit set cap comp to the left, and remove it.
- Remove the fuel unit from the fuel tank.

**⚠ NOTE**

- Be careful of prevention the fuel unit wire from damaging.
- When disassembling, be careful of prevention the float arm from damaging.

Remove the base packing.

**⚠ NOTE**

- Check for damage.

### INSTALLATION

- Install the base packing to the fuel tank.
- Install the fuel unit.

**⚠ NOTE**

- Install it aligning the part of the fuel unit with the loop part of fuel tank.
- Check the fuel leakage.

### INSPECTION

Move the float upward and downward, and measure the resistance between the terminals.

WIRE TERMINAL	FLOAT UPPER LINE	FLOAT LOWER LINE
GREEN AND YELLOW/WHITE	33	400~750
GREEN AND BLUE/WHITE	400~750	33
BLUE/WHITE AND BLUE/WHITE	450~750	450~750

When the measured value differs greatly from the standard value, replace the fuel unit.

## OIL LEVEL SWITCH

### REMOVAL/INSTALLATION




- Remove the luggage box. (⇨3-3)
- Remove the body cover.
- Loosen the bolt jointed with the fuel tank.
- Remove the wire of oil level switch.
- Remove the oil level switch from the oil tank.
- Install in the reverse order of removal.

**NOTE**

- Disassemble after adjusting the oil level.

### INSPECTION

- Move the float to farthest extreme up and down and check the continuity of the terminals.
- It's normal state if there is no continuity when the float is up, but continuity when it is down.



## MAIN SWITCH

### REMOVAL/ INSTALLATION




- Remove the front cover. (⇨3-5)
- Remove the inner box. (⇨3-5)
- Disconnect the main switch coupler.
- Remove the seat lock cable.
- Loosen the 2 screws and remove the main switch.
- Install in the reverse order of removal.

### INSPECTION

- Inspect continuity of each terminal.

TERMINAL	IG	E	BA1	BA2
ON			○—○	○—○
OFF	○—○	○—○		
LOCK	○—○	○—○		
COLOR	BLACK/WHITE	GREEN	RED	BLACK





**HANDLE SWITCH INSPECTION**

Remove the front handle cover. (⇒3-6)  
 Remove the handle switch coupler, connector, and inspect continuity of each terminal.  
 If abnormal, inspect the switch.

**LIGHTING SWITCH**

	HL	C1	TL	RE
OFF		○	—	○
(N)		○	○	
PO		○	○	
(N)	○	○	○	
H	○	○	○	
COLOR	BROWN / WHITE	BROWN	YELLOW	PINK

**STARTER SWITCH**

	ST	E
FREE		
PUSH	○	○
COLOR	YELLOW/RED	GREEN

**DIMMER SWITCH**

	HI	LO	HL
LO		○	○
N	○	○	○
HI	○		○
COLOR	BROWN	WHITE	BLUE

**WINKER SWITCH**

	R	L	WR
L		○	○
N			
R	○		○
COLOR	SKY BLUE	ORANGE	GRAY

**HORN SWITCH**

	HO	BAT
FREE		
PUSH	○	○
COLOR	LIGHT GREEN	BLACK

**FRONT STOP SWITCH INSPECTION**

Remove the front handle cover. (⇒3-6)  
 Remove the black wire and green/yellow wire terminals inside the speedometer assembly, and check the following.  
 -When the brake lever is pulled - continuity.  
 -When the brake lever is released - no continuity.

## BULBS REPLACEMENT

### HEADLIGHT BULB

- Remove the front cover. ( ⇨3-5 )
- Remove the headlight rubber cover.
- Push down on the socket and turn to the left.
- Replace with new bulb.



**NOTE**

- Before replacing the bulb, be sure to check the switches for loose connection of the connectors.

Install in the reverse order of removal.

**WARNING**

- Headlight bulbs become very hot while the headlight is ON, and remain hot for a while after they are turned OFF.
- Be sure to turn the ignition switch OFF and let the bulb cool down before replacement.

**CAUTION**

- If you touch the bulb with your bare hands, clean it with a cloth moistened with denatured alcohol to prevent early bulb failure.
- Be sure to install the dust cover after replacing the bulb.

### FRONT WINKER BULB

- Remove the front cover. ( ⇨3-5 )
- Remove the bulb from the socket, replace with new bulb.
- Install in the reverse order of removal.



### REAR WINKER BULB REPLACEMENT

Press the winker lens groove and open the winker lens using plain screwdriver.  
Remove the bulb from the socket, replace with new bulb.  
Install in the reverse order of removal.

#### NOTE

- Pay attention not to damage the lens.
- Do not apply excessive force when removing the lens.




### TAILLIGHT BULB REPLACEMENT

Loosen the 2 pan screws, remove the tail light lens.  
Replace the tail stop light bulb with the new one.

#### NOTE

- Pay attention not to damage the tail light lens when removing it.




### METER BULB REPLACEMENT

Remove the front handle cover. (⇒3-6)  
Remove the bulb socket, replace with new bulb.




### METERS REPLACEMENT

Remove the front cover. (⇒3-5)  
Remove the front handle cover. (⇒3-6)  
Remove the front/rear stop switch wire.  
Remove the speedometer cable from the meter.  
Loosen the 4 steering handle tapping screws.  
Remove the speedometer coupler connected to the wire harness  
Remove the speedometer wiring from the steering handle cable guide.  
Remove the speedometer and the gear handle cover assembled from the steering handle.  
Remove the 3 tapping screws securing the speedometer and the rear handle cover.  
Disconnect the R/L wiring.  
Remove the speedometer assembly.  
Install in the reverse order of removal.



## ⚠ NOTE

- Check the each switch for proper operation.
- The wire and cable must be connected accurately.



## HORN INSPECTION

Remove the front cover. (⇨3-5)

Remove the horn wiring, and connect a fully charged 12V battery. Check the sound quality for any abnormalities.



## LICENCE LAMP

Loosen 2 screws.

Remove the lamp cover.

Replace the lamp (12V 4W)

Install in the reverse order of removal.






---

# MEMO

---

# 17. WIRING DIAGRAM



LIGHTING S/W				COMB S/W				DIMMER S/W			WINKER S/W				START S/W			HORN S/W			SIDE STAND S/W			
HL	C1	TL	RE	IG	E	BAT1	BAT2	HI	HL	HI	LO	WL	RH	LH	FREE	ST	E	FREE	HO	BAT2	FREE	IG	E	
OFF				ON																				
(N)				OFF				N							PUSH			PUSH			PUSH			
Po				LOCK				LO							CORD COLOR	Y/R	G	CORD COLOR	Lg	B	CORD COLOR	B/W	G	
(N)				CORD COLOR	B/W	G	R	B	CORD COLOR	Y	L	W	CORD COLOR	Gr	Sb	O								
H																								
CORD COLOR	Br/W	Y	Br	P																				

B	BLACK	BR	BROWN
Y	YELLOW	O	ORANGE
L	BLUE	SB	SKY BLUE
G	GREEN	LG	LIGHT GREEN
R	RED	P	PINK
W	WHITE	GR	GRAY


COLOR COMB GROUND/MARK NG

# 18. TROUBLESHOOTING

ENGINE DOES NOT START OR IS HARD TO START . . . . .	18-1
ENGINE OUTPUT INSUFFICIENT . . . . .	18-2
POOR PERFORMANCE AT LOW SPEED AND IDLING . . .	18-3
POOR PERFORMANCE AT HIGH SPEED . . . . .	18-3
UNSATISFACTORY OPERATION . . . . .	18-4
FUEL GAUGE . . . . .	18-6
STARTER MOTOR . . . . .	18-7


## ENGINE DOES NOT START OR IS HARD TO START

### CAUSE OF TROUBLE




## ENGINE OUTPUT INSUFFICIENT

### CAUSE OF TROUBLE




## POOR PERFORMANCE AT LOW SPEED AND IDLING

### CAUSE OF TROUBLE



## POOR PERFORMANCE AT HIGH SPEED

### CAUSE OF TROUBLE



## UNSATISFACTORY OPERATION

### CLUTCH DRIVE/DRIVEN PULLEY

### CAUSE OF TROUBLE

- |   |   |  |
|---|---|--|
| 1. Engine starts but motorcycle does not move.              | → | (1) Drive belt worn or slips.<br>(2) Ramp plate damaged.<br>(3) Drive face spring damaged.<br>(4) Clutch lining came off.<br>(5) Driven pulley shaft spline damaged.<br>(6) Faulty transmission.<br>(7) Transmission seized. |
| ↓   |   |  |
| 2. Vehicle moves slow, engine starts but stops immediately. | → | (1) Shoe spring damaged.<br>(2) Clutch outer and weight seized.<br>(3) Pivot seized.   |
| ↓   |   |  |
| 3. Engine weak at start.                                    | → | (1) Drive belt worn or slips.<br>(2) Weight roller worn.<br>(3) Drive pulley bearing seized.<br>(4) Weak drive face spring.<br>(5) Drive pulley bearing worn or seized.  |
| ↓   |   |  |
| 4. Engine weak at high speed.                               | → | (1) Drive belt worn or slips.<br>(2) Weight roller worn.<br>(3) Drive pulley bearing worn.   |
| ↓   |   |  |
| 5. Abnormal noise or odor.                                  | → | (1) Oil or grease spilled on the drive belt and inside pulley.<br>(2) Drive belt worn.<br>(3) Weak drive face spring.<br>(4) Driven pulley bearing worn or seized.   |

### POOR MECHANICAL PERFORMANCE

Check tire pressure.

### CAUSE OF TROUBLE

- |                                  |   |  |
|----------------------------------|---|--|
| 1. Steering is heavy.            | → | (1) Steering head adjuster excessively tightened.<br>(2) Steering cone race or steel ball damaged. |
| ↓                                |   |  |
| 2. Wheels wobbling.              | → | (1) Excessive wheel bearing play.<br>(2) Rim bent.<br>(3) Axle nut loose.                          |
| ↓                                |   |  |
| 3. Motorcycle pulls to one side. | → | (1) Front wheel and rear wheel not aligned.<br>(2) Front fork bent.                                |

**POOR FRONT/REAR SUSPENSION PERFORMANCE** ————— Check tire pressure.

**CAUSE OF TROUBLE**

- |                                 |   |  |
|---------------------------------|---|--|
| 1. Suspension excessively soft. | → | (1) Cushion spring weak.<br>(2) Overloaded.<br>(3) Damper oil leaks. |
| ↓                               |   |  |
| 2. Suspension excessively hard. | → | (1) Fork pipe or cushion rod bent.                                   |
| ↓                               |   |  |
| 3. Noise from the suspension.   | → | (1) Sliders stuck.<br>(2) Cushion stopper rubber damaged.            |

**POOR BRAKE PERFORMANCE** ————— Check brake adjustment.

**CAUSE OF TROUBLE**

- |   |   |   |
|---|---|---|
| 1. If the arrow were mark and the brake panel mark match with each other. | → | (1) Brake shoe worn.<br>(2) Brake cam worn.<br>(3) Shoe and cam contact surface worn.<br>(4) Brake drum worn.   |
| ↓   |   |   |
| 2. Brake noise.   | → | (1) Brake shoe worn.<br>(2) Foreign matter in the brake lining.<br>(3) Brake drum and shoe contact surface curved.  |
| ↓   |   |   |
| 3. Poor braking.  | → | (1) Brake wire defective or expanded.<br>(2) Only part of the brake shoe makes contact with the brake drum.<br>(3) Clay or moisture inside the brake drum.<br>(4) Brake lining contaminated by grease or oil. |

## FUEL GAUGE

### GAUGE READING INACCURATE (IGNITION SWITCH ON)

### CAUSE OF TROUBLE

1. Operate the turn signal to check the battery circuit.

Signal operates satisfactorily.

Signal continuously operates dim or does not operate at all.

- (1) Fuse cut.
- (2) Battery weak or totally discharged.
- (3) Faulty ignition switch.
- (4) Faulty terminal connection.
- (5) Wire harness damaged.

2. Remove the fuel level sensor, and move float to check the status of operation.

**Float up : Full position**

**Float down : Empty position**

Needle not moving.

Needle moves.

- (1) Faulty float.

3. Short-circuit the tank unit terminal on the wire harness side.

Needle not moving.

Needle not moving.

- (1) Balance coil damaged or shorted.

4. Terminal joints loose or faulty connection.

Unsatisfactory

- (1) Terminal loose.
- (2) Faulty terminal connection.

Check

- (1) Balance coil/lead shorted or damaged.

### GAUGE NEEDLE SHAKES OR VERTICALLY WOBBLER. (IGNITION SWITCH ON)

### CAUSE OF TROUBLE

1. Operate the turn signal to check the battery circuit.

Signal operates satisfactorily.

Signal continuously operates dim or does not operate at all.

- (1) Fuse cut.
- (2) Battery weak or totally discharged.
- (3) Ignition switch damaged or shorted.
- (4) Terminal loose or faulty connection.
- (5) Wire harness damaged.

2. Remove the tank and operate the float.

Needle moving.

Needle not moving.

- (1) Faulty fuel level sensor connection.

3. Move the float rapidly. One up/down motion per second.

Needle moving.

Needle not moving.

- (1) Damper oil inside the meter insufficient.

4. Start the engine, and measure the fuel level sensor resistance.

Resistance not changed.

Resistance changed significantly.

- (1) Faulty connection between the sliding arm and the resistance.

5. Check each joint.

Unsatisfactory

- (1) Terminal connection loose or faulty connection.

Satisfactory

- (1) Balance coil/lead shorted or damaged.



# STARTER MOTOR

## STARTING MOTOR WILL NOT TURN

## CAUSE OF TROUBLE

1. Apply the brake and check the brake stop light for operation.

Light is activated.

Light not activated.

- (1) Fuse cut.
- (2) Battery weak or totally discharged.
- (3) Faulty stop switch.
- (4) Faulty terminal connection.
- (5) Ignition switch damaged or shorted.

2. Operate the turn signal to check the battery circuit.

Signal operates satisfactorily.  
(60~120 signaling/second)

Signal continuously operates dim or does not operate at all.

- (1) Battery totally discharged.

3. Press the starter switch to check the starter magnetic.

Satisfactory

Unsatisfactory

- (1) Faulty starter switch connection.
- (2) Starter magnetic damaged or shorted.
- (3) Connector and terminals loose.

4. Connect the starter to battery and check operation. Light not activated.

Starter turns.

Starter does not turn.

- (1) Worn brush worn.
- (2) Faulty connection between the rotor and brush.
- (3) Faulty the starter motor subwire connection.
- (4) Terminal loose.

- (1) Wire harness damaged.

## STARTER MOTOR TURNS SLOW OR FAILS TO CRANK MOTOR

## CAUSE OF TROUBLE

1. Operate the turn signal to check the battery circuit.

Signal operates satisfactorily.

Signal continuously operates dim or does not operate at all.

- (1) Battery totally discharged.

2. Connect the starter subwire to the battery.

Turns slowly.  
(with speed not changing)

Operates satisfactory.

- (1) Connector/terminal loose.
- (2) Faulty starter relay connector.

3. Operate the kick starter.

Operates light.

Operates heavy.

- (1) Engine seized.
- (1) Faulty connection between the rotor and brush.

## STARTER ROTATE WITHOUT STOPPING

## CAUSE OF TROUBLE

1. Turn off the ignition switch.

Will not stop

- (1) Pinion seized.

→ Starter relay connection seized.

---

# MEMO

---