



Service manual

BLUR

Manufactured by Motive Power Industry Co., Ltd

PREFACE

This manual provides every service specialist with professional techniques of maintenance and repairing for G-MAX (BLUR-150). It provides a detailed guide for those who may concern with how to maintain, repair, reassemble, and change parts of their scooters.

This manual includes:

- G-MAX 150 (BLUR- 150):
abbreviated as “M2-150” is 4 stroke engine (4T),
150cc displacement.

At every section, we illustrate each important point by assembling procedures, explosive diagrams and photographs.

Although we have tried our best to make this manual as perfect as possible, please kindly inform us if any fault needs to be corrected in this manual.

Thank you for purchasing our PGO scooters.

FACTORY
Motive Power Industry Co.,Ltd.

CONTENTS :

Page

- . The specification of G-MAX (ALLORO)
- .Service information
 - (1)The operation notice
 - (2)Locking torque value
 - (3)Lubrication instruction
 - (4)Periodical maintenance table
 - (5)Troubleshooting
- .Checking and adjustment
 - (1)Regular checking table
 - (2)Battery
 - (3)Cleaning air cleaner
 - (4)The final reduction mechanism oil
 - (5)Spark plug
 - (6)Compression pressure measurement
 - (7)Ignition timing
 - (8)Throttle cables adjustment
 - (9)Idle adjustment
 - (10)Front brake adjustment
 - (11)Rear brake adjustment
 - (12)Tire
- .Dismantling, maintaining, repairing and assembling operation
 - A. Plastic parts
 - B. G-MAX 50 Engine dismantling
 - (1)Lubrication system
 - (2)Engine dismantling
 - (3)Drive pulley, starter, clutch,
 - (4)Cylinder and, piston
 - (5)AC Generator
 - (6)Final transmission mechanism
 - (7)Crankcase, crankshaft.
 - (8)Carburetor, reed valve
 - C. G-MAX 125/150 Engine dismantling
 - (1) Lubrication system
 - (2) Engine dismantling
 - (3) Install Engine

- (4) Drive pulley, starter, clutch, driven pulley
- (5) Cylinder head and valve
- (6) Cylinder and piston
- (7) AC generator
- (8) Final transmission mechanism
- (9) Crankcase, crank shaft
- (10) Carburetor

(D) Steering column, front wheel, front brake comp, front fork

(E) Rear wheel, rear brake, rear damper

(F) Fuel supply

.Electric equipment

- (1) Troubleshooting
- (2) Battery
- (3) Recharge system
- (4) Ignition system
- (5) Starting system
- (6) Switch operation
- (7) Wiring diagram

1.3 G-MAX 150

SPECIFICATION							
BRAND		PGO		FRAME		STEEL PIPE	
MODEL		M2-150		SUSP ENSI ON	FRONT	TELESCOPE	
DIMENSION	LENGTH		1855 mm		REAR	SWING	
	WIDTH		730 mm		TRANSMISSI	PRIMARY	DIRECT
	HEIGHT		1170 mm			2ND	42/15*42/13
	AXLE DISTANCE		1365 mm			CLUTCH	CENTRIGUAL
WEIGHT	GROSS	FRONT	55 KG			TIRE	FRONT
		REAR	77 KG		REAR		130/70-13
		TOTAL	132 KG		BRA KE		FRONT
	PASSENGER		2 (110KG)			REAR	DISK
	TOTAL	FRONT	95 KG		SPEEDOMETER		1400 km/hr
		REAR	147 KG		LIGIGHT	HEAD(HI, LO)	12V-35W/35W
		TOTAL	242 KG			REAR	12V-5W
PERFORMAN	TOP SPEED		87 km/hr		BRAKE	12V-21W	
	FUEL CONSUMPTION		40 km/l		SIGNAL	12V-10W*4	
	GRADIENT		24 °		HORN		DC 12V
	ENGINE MODEL		C5M		SILENCER		DIFFUSER
ENGINE	FUEL		92 UNLEADED		EXHAUS	PARTICLE	BELOW 15 %
	STROKE		4T AIR FORCED			CO	BELOW 4.5%
	CYLINDE	BORE	57.0 mm			HC	BELOW 7000 ppm
		STROKE	58.6 mm		EXHAUST LAYOUT		RIGHT
	CYLINDER		SINGLE		LUBRICATE		SEPARATE PUMP & SPLASH
	DISPLACEMENT		149.5 cc		FUEL TANK		7.5 L
	C.R.		9.4 : 1				
	MAX H.P.		7.7kw/7250rpm				
	MAX TORQUE		10.6N-M/6250rpm				
	LAYOUR		HORIZONTAL				
	IGNITION		CDI				
STARTING		ELECTRIC & KICK					

.Service information :

- (1)The operation notice
- (2)Locking torque value
 - 1.For engine
 - 2. For chassis
 - 3. Others
- (3) Lubrication instruction
 - a.For engine
 - b. For chassis
 - c. Wheel bearing
- (4)Periodical Maintenance Table
- (5)Troubleshooting
 - 1.Difficult starting or starting
 - 2.Weak acceleration
 - 3.Engine running not smoothly (low speed)
 - 4.Engine running not smoothly(high speed)
 - 5.Clutch, drive & driven pulley
 - 6.Handlebar steering was astray when running
 - 7.Front and rear damper not balanced
 - 8.Brake disorder
 - 9.Oil indicator malfunction
 - 10. Fuel indicator malfunction
 - 11. Starting motor malfunction
 - 12.No sparking
 - 13.Charging abnormal

(1)The operation notice :

- 1.For parts like the gasket, o-ring, clips and circlets, please change a new part whenever re-assembled.
- 2.When trying to tighten screws or nuts, please lock tightly according to each recommended locking torque and in the sequence of the "X" pattern.
- 3.Please use PGO or PGO recommended parts.
- 4.After dismantling, please clean all parts involved or used for checking and grease all contact surfaces when reassembling.
- 5.Use grease recommended by P.G.O.
- 6.When removing the battery, please disconnect the negative pole(-) first. However, please connect the positive pole(+) first when assembling.
- 7.Before installing a new fuse, please be sure that the specification is correct.
- 8.After reassembling, please re-confirm that all connecting point, locking parts, circuits, polar characteristics are functioning well before selling out.

2. 4T Engine (125/150 CC)

NO	Locking location	Q' ty	Thread dia. (mm)	Locking torque (kg-m)
1	Fixing nut (Tappet screw nut)	2	5	0.7~0.8
2	Nut of oil pump sprocket	1	6	0.7~1.0
3	Cylinder head bolt A (intake)	2	6	0.9~1.1
4	Guiding pin bolt, chain extensioner	1	6	0.4~0.6
5	Screw, chain extensioner	2	6	0.9~1.1
6	Cylinder head bolt B (Exhaust)	2	8	2.0~2.3
7	Flange nut, cam shaft holder	4	8	2.0~2.3
8	Gear oil drain bolt	1	8	1.7~2.0
9	Spark plug	1	10	1.2~1.3
10	Nut of fly wheel	1	12	5.0~6.0
11	Fixing nut, clutch outer	1	12	5.0~6.0
12	Nut, driving plate	1	12	5.0~6.0
13	Bolt of engine oil drain	1	12	2.5~3.0
14	Bolt of 2 nd oil filter	1	12	0.8
15	Nut (LH thread), one-way clutch	1	22	9.0~10.0
16	Cap, coarse oil filter	1	30	1.5~2.0

3. Chassis

NO	Locking location	Q'TY	Thread dia. (mm)	Locking torque (kg-m)
1	Air bleed bolt of caliper	1	6	0.6
2	Brake arm bolt, front drum	1	6	0.8~1.0
3	Brake arm bolt , rear drum	1	6	0.8~1.0
4	Nut of starter relay	2	6	0.5~0.6
5	Front brake caliper bolt	2	8	2.0 ~ 3.0
6	Bolt of disk	3	8	2.5~3.0
7	Locking nut, steering stem	1	10	3.5~4.5
8	Rear shock absorber bolt(lower)	1	10	3.5 ~ 4.5
9	Rear shock absorber bolt(upper)	1	10	3.5~4.5
10	Chassis bolt, engine hanger bracket	2	10	4.5 ~ 5.0
11	Engine bolt, engine hanger bracket	1	10	3.0 ~ 4.0
12	Hose bolt, master cyl. & caliper	2	10	2.5 ~ 3.0
13	Front axle nut	1	12	4.5 ~ 5.5
14	Nut, swing arm & connecting rod	1	14	4.5 ~ 5.5
14	Rear axle nut	1	16	10.0~11.0

4. Other parts standard torque values:

No	Item	Torque kg-m
1	5mm bolt and nut	0.45-0.6
2	6mm bolt and nut	0.8-1.2
3	8mm bolt and nut	1.8-2.5
4	10mm bolt and nut	3.0-4.0
5	12mm bolt and nut	5.0-6.0
6	5mm screw	0.35-0.5
7	6mm screw	0.7-1.4
8	6mm flange bolt and screw	1.0-1.4
9	7mm flange bolt and screw	1.0-1.4
10	8mm flange bolt and screw	2.0-3.0
11	10mm flange bolt and screw	3.0-4.0

(3)Lubrication instruction

A. 2T Engine (50 cc)


NO	Lubrication location	Oil type	Remarks
1	Crankcase: rotating part, Sliding part	Premium 2 stroke Motorcycle oil Or SAE#30	Separated-pump Lubrication
2	Cylinder: rotating part, Sliding part.		
3	Drive gear box	SAE85-140	Total 110 c.c. Replacement 90c.c
4	Gasket of starter shaft	Clean grease	(#3)
5	Start idle gear sliding parts	Clean grease	(#3)

B. 4T Engine (125/150 cc)

NO	Lubrication location	Oil type	Remarks
1	Crankcase: rotating part, Sliding part	premium 4 stroke motorcycle oil or SAE15W40	Auto-Separated Lubrication
2	Cylinder: rotating part, Sliding part.		
3	Drive gear box	SAE85-140	Total 110 c.c. Replacement 90c.c
4	Gasket of starter shaft	Clean grease	(#3)
5	Start idle gear sliding parts	Clean grease	(#3)

C. Chassis appearance


1. Apply oil : #1, #2



2. Apply grease (#3, #4, #5. #6 ,#7, #8)

D.Wheel bearing

Final transmission mechanism gear oil



Speedometer gear: clean grease



(4)PERIODICAL MAINTENANCE TABLE


Item	Model 2T or 4T	Checking Content	MONTHS/DISTANCE(IN MILE)FOR CHECKING						
			1 or 200 mile	3 or 2000 mile	6 or 4000 mile	9 or 6000 mile	12 or 8000 mile	15 or 10000 mile	18 or 12000 mile
Engine oil*	4T	Replace (800cc, total 900cc)	Replace it per 1,000mile						
Oil Filter	ALL	Replace	Replace it per 4,000mile						
Coarse oil filter* (on oil draining bolt)	4T	Clean or replace it if necessary	Clean it per 2,000mile or replace it if required						
Air cleaner	ALL	Clean or replace it if necessary							
Air filter	ALL	Clean or replace it if required							
Gear oil*	ALL	Replace (90cc, total 110 cc)							
Disk & drum brake	ALL	Leaking and function check							
Clutch shoes*	ALL	Check or replace it if necessary							
Rear brake arm	ALL	Function check and adjustment							
Tires	ALL	Worn-out check or replace it if necessary							
Wheel bearing*	ALL	Fasten tightly if loosen							
Front fork*	ALL	Leaking and function check							
Steering head bearing*	ALL	Check looseness. Adjust it if required							
Rear absorber*	ALL	Leaking and function check							
Main/Side Stand	ALL	Function check or replace it if required							
Nuts, bolts, fasteners	ALL	Tighten it if required							
Battery	ALL	Make sure that the voltage stayed over 12.8V. Recharge the battery it required. Clear the poles.							
Valve gap*	4T	Check and adjust when engine is cool (0.08mm for IN & EX)	Adjust it when necessary						
Spark plug*	ALL	Clear or replace if required							
V belt*	ALL	Worn out check or replace if necessary.				A		A	
Fuel feeding system*	ALL	Crack and blockage check. Replace it if necessary.							
Engine idle speed*	ALL	4T engine: 1700±100 rpm							
Carburetor idle A/F Adjustment*	ALL	Check and adjust referring to CO/HC Percentage.							

NOTE :


1. Items with “*” mark indicate our recommendation to have it done by PGO dealer.
2. “A” denotes that function check or replace it when the engine performance reduces significantly.
3. For 4T engine, the engine oil shall be changed completely after run-in period 200mile or one month later. This can make sure the engine runs smoothly.

(5) Trouble shooting:


1. difficult starting or can't start:




2. Weak acceleration:




For 4T engine only:




3.Engine running unsmoothly (low speed and idling)




4.Engine running unsmoothly (high speed)




5. Clutch, drive and driven pulley




6. Handlebar steering astrayed when running.



7. Front, rear damper not in balanced




8. Brake disorder.




9.Oil indicator malfunction (Only available for 2T engine)

(a)The oil lamp doesn't light up, (when the main switch is at "ON" position)




(b)Oil is enough but the indicator turns on all the time (when the main switch is "ON")




10. Fuel indication malfunction

(a) wrong fuel level indication (when the main switch is "ON")




(b) Fuel gauge needle is not steady and sometimes moves up and down (when the main switch is "ON")




11.The starting motor abnormal


(a)Starting motor can not rotate




(b) Starting motor running slowly or no pick-up




© Starting motor can not stop after starting



12.No sparking



13.Charging abnormal(battery over charging or over discharging)



3. Checking and Adjustment:

- (1)Regular checking table
- (2)Battery
- (3)Clean air cleaner
- (4)The final reduction mechanism oil
- (5)Spark plug
- (6)Compression pressure measurement
- (7)Ignition timing
- (8)Throttle cables adjustment
- (9)Idle adjustment
- (10)Front brake adjustment
- (11)Rear brake adjustment
- (12)Tire

(1)Regular checking table:

1. **【O】** mark indicates periodical checking
2. **【 】** indicates changing the parts

Item			Checking period						Judgement standard	Remark
			gen-eral che-cki ng	first month or Initial 300km	home		office			
					every6 months or 5000km	every12 months or 10000km	every1 months or 1000km	every3 months or 2500km		
Suspension	Handlebar steering column	Loose or swing								
		Operation								
		Turning angle								
	front fork	Damaged								
		Shaft fixed condition								Check from Stering column
		Shaft:loose							Check from Stering column	
Brake	Lever	a. clearance							Clearance: Front: 10-20mm Rear : 10-20mm	
		b. movement of brake								
	Brake cable	loose or damage								
		Change brake cable							every 2 years	
	Brake cam	worn out								
	Wheel hub and brake shor	a. clearance between hub and lining								
		b. brake shoe and brake lining worn-out								
c. wheel hub worn and damaged								standard dia:rear:110.0mm limit of use:rear:111.0mm	For M2-50 only	
Wheel	Front wheel axle	damaged or distorsion								
	Rear wheel axle	damaged or distorsion								
	tire	Pressure							unit: kg/c m ² ;l driver	
									front tire rear tire	
		Cracked or damaged								
		tire thread worn out							Change tire according to mark	
		tire surface or other intruders								
	Axle	Tighten the bolt and nut							Front axle nut torque 5.0-6.0kg-m rear axle nut torque 11.0-13.0kg-m	Nut location
Rim	swingness and damage condition							Swingness limit Vertical: below 2.0mm Horizontal: below 2.0mm		


Item			Checking period						Judgement standard	Remark	
			gen-eral check- ing	first month or Initial 300km	home		office				
					every6 months or 5000km	every12 months or 10000km	every1 months or 1000km	every3 months or 2500km			every12 months or 10000km
wheel	Bearing	Clearance on Front axle									
		Clearance on rear axle									
Rear Damper	Spring	Damage Condition									
	Ass'y part	Loose or damaged condition									
	Connecting part	loose or									
	Bracket	loose or damage condition									
	Suspension arm	Looseness on Connecting Part									
	Absorber	Oil leakage									
Damaged Condition											
Loose on ass'y part											
Transmission	Clutch and Shift mechanism	Function									
		Gear oil leakage								LH crank case	
	Gear oil	Change gear oil								90CC / replace 110CC / total	
Electric	Ignition	Spark plug							Clearance: 0.6~0.7mm NCK:BP7HS NGK:C7HSA	M2-50 M2-125& M2-150	
	Start Mechanism	Starting motor gear									
	Wiring	Recharge Function									
	Battery	Electrolyte level								Level between "UPPER" and "LOWER"	
		Electrolyte gravity								When 20 Specific gravity: 1.270-1.290	
Wire circuit	Looseness or Damage on connection plug										

Item		Checking period					Judgement standard	Remark			
		gen-eral che-cki ng	first month or Initial 300km	home		office					
				every6 months or 5000km	every12 months or 10000km	every1 months or 1000km			every3 months or 2500km	every12 months or 10000km	
Engine mechanism	Engine parts	Performance, Noise									
		Low speed, Acceleration							Idling: 1900 ± 100rpm Idling: 1700 ± 100rpm	M2-50 M2125&150	
		Exhaustion								Check the color of exhausting-air	
		Air cleaner									
		Cylinder, cylinder head, inlet pipe, locking Condition								Locking torque Cylinder head: (cold) 1.0-1.2KG-m Cam holder nut: 2.0-2.3kg-m	M2-50 M2125&150
		Compression Pressure (G-MAX 50)								. 6kg/c m ² @ 600rpm	Using starting motor
		Compression Pressure G-MAX 125								. 12kg/c m ² @ 750rpm	Using starting motor
		Compression Pressure G-MAX 150								. 11kg/c m ² @ 650rpm	Using starting motor
	Lubrication system	Oil leakage									
		Oil quantity, Dirty									
		Oil quantity,									
		Oil filter blocked									
	Fuel system	Fuel quantity									
		Fuel leakage									
		Clean Carburetor									
		Carburetor's Throttle and Choke function									
		Carburetor Float height									
		Carburetor Adjustment									
		Change fuel pipe								every 4 years	

Item		Checking period							Judgement standard	Remark
		gen-eral che-cki- ng	first month or Initial 300km	home		office				
				every6 months or 5000km	every12 months or 10000km	every1 months or 1000km	every3 months or 2500km	every12 months or 10000km		
Lamp system	Function									
	Dirty or broken									
Horn, signal Lamp, reflector	Function									
lock	Function									
Rear view mirror	Dirty or broken									
License plate	Dirty or damaged									
Dashboard	Function									
Muffler silencer	Losseness or Damage on Ass'y part									
	Function									
chassis	Loose or Damaged									
The previous Abnormal case	Confirm it does Not happen Again									
others	Chassis Lubrication									
	Decarbonate on Combustion room And muffler									

(2) Battery: Recharge when power is out

1. Remove the rear luggage cover by hand.
2. Screwing out the two screws on the battery cover. Remove the battery cover. (G-MAX125/150)
3. Remove the negative cable and then the positive cable, take out the battery to recharge.
4. To re-assemble the battery, please follow the opposite procedure of disassembling after recharging.



Positive Pole

Negative Pole

Note:

A. The battery is totally sealed, do not remove seal bolts when recharging

B. It's no need to add any electrolyte for this re-filling free battery

Please recharging (12V) by the following currency

G-MAX50: Standard recharging:0.4A* 5-10 hr or rapid recharging:4A* 30min.

G-MAX125/150: Standard recharging:0.7A* 5-10 hr or rapid recharging:3A* 60min.

(3)Cleaning air cleaner

- 1.Remove air cleaner cover
- 2.Take out the air cleaner filter

G-MAX125/150



- 3.Clean the filter by the compressor air.




- 4.Assemble the air cleaner by the opposite procedure.

Note: Do not start the engine When the air cleaner is Not installed

(4)The final reduction mechanism oil

- 1.Change the oil in the gear box:
 - a. Turn off the engine after warm up.
 - b. Put a bowl under the engine.
 - c. Remove the draining bolt and Filler bolt to drain the gear oil off.
 - d. Lock the draining bolt before refill 90c.c gear oil and then lock the filling bolt.
 - e. Locking torque: 1.8kg-m



Draining

Filling Bolt

Note: Be sure the crankcase, tire or wheel are cleaned if there is grease/oil on it

(5)Spark plug


- 1.Remove spark plug
- 2.Check the spark plug electrode and check if it is Burnt out or not and carbonized or not
- 3.Clean the electrode, whether it is dirty
- 4.Spark plug specification
 - G-MAX50: BP7HS (NGK) or equivalent spec.**
 - G-MAX125/150: C7HSA (NGK) or equivalent spec.**

Gap of spark plug:0.6~0.7mm

Electrode burn out/
Carbon piled up

Washer is
Distorted or not

Procelain is
Cracked or not



(6) Compression pressure measurement:

1. Measure it when the engine is warm.
2. Remove the cover.
3. Remove spark plug then place compression pressure gauge.
4. Fully open the throttle, and using starting motor 5 seconds continuously, measure the compression pressure.
5. Compression pressure:

150cc: 11 kg/c m² @650rpm

6. when the compression pressure is too low, check the following:
 - a. cylinder head gasket cracked.
 - b. piston cylinder worn out.
 - c. piston ring worn out.
7. If the compression pressure is too high it may be due to the carbon piled up on combustion chamber and piston tip.



(7) Ignition timing:

This scooter is using CDI set, it is no need to adjust ignition timing.

If ignition timing is not correct, check the CDI sets and AC magneto, change it if it is

checking ignition timing:

1.remove seat the luggage compartment

2.Remove right body cover

3.Remove the fan case.

4.Check with ignition timing lamp.

keep the engine running at $1,900 \pm$

100 r.p.m the checking mark should

lay in $\pm 3^{\circ}$ apart From "F", mark.

5.ignition timing: B.T.D.C.

$17^{\circ} \pm 3^{\circ} /$

1900rpm



(8)Throttle cables adjustment:

1.check the clearance of throttle.

2.Normal clearance:1.5-3.5mm

3.Adjust it by rotating the

adjust nut ; change it if the throttle cables

can' t be adjusted.



(9) Idle adjustment:

Note: adjust it when the engine is warm.

- 1.remove left body cover
- 2.start the engine and connect the tachometer
- 3.adjust the throttle valve screw
to the specified revolution
1700 ± 100rpm. (M2-125&150)
- 4.if the idling rpm is still unsteady or
fuel up is not smooth, please adjust it by
followings.
 - a. Screw in the air adjust screw clockwise,
then screw out counterclockwise.
Recommended loop: 1 3/8 × 1/2
 - b. Rotate air adjust screw clockwise and counterclockwise to find out the highest
revolution location.
 - c. Rotate the throttle valve screw to idling condition.
 - d. Fuel up gradually until the idling running rpm is steady.
 - e. If the rpm is still not steady please repeat above procedure.

(10)front brake adjustment:

- 1.check the clearance of front brake lever.
Clearance:10-20mm
- 2.if the clearance is beyond, standard check whether:
 - a. The air mix into the pipe/caliper.
 - b. The oil brake system is leaking.

Note:

Try brake lever to see if it's loose.
Check the brake fluid. Once air mixed in
The fluid pipe, which will reduce or
Damage the brake efficiency or even its
Function.

- 3.check the fluid level:
 - a. Refill the brake fluid when the level is under the LOWER line.
 - b. Brake fluid specification: SAE J-1703F-DOT3&DOT4.

Note:

- a. To prevent the fluid splitting onto the parts or clothes, put a piece of cloth on
the bottom when refilling.
- b. Be caution not to mix water or particles into the master cylinder when refilling.
- c. Never use the fluid not complied with spec.
- d. In case the fluid stains on the eyes, wash with water at once and then ask for
medical care immediately.

(11)Rear brake adjustment (drum brake only)

- 1.Check the clearance
Of rear brake lever.
Clearance: 10-20mm
- 2.If the clearance is
beyond the above standard,
Adjust it by rotating the screw.
 - a. Left-handed rotation-enlarge
the clearance.
 - b. Right-handed rotation-reduce the clearance.



Note:

When the arrow of rear brake indicator align with the arrow of left crankcase, change the brake lining.

(12)Tire:

- 1.Check the tire air pressure(when it's cold)
- 2.Tire pressure:
Front tire: 2.0 kg/c m²
Rear tire: 2.0 kg/c m²
- 3.Tire dimension:

G-MAX 125/150:

Front tire: 120/60-13

Rear tire: 130/60-13




Note:

- a. Check and adjust the tire pressure when it is too low.
The pressure is according to the carrier, Driver, passenger, accessories and cruise Speed.
- b. Proper loading is very important for steering, riding, braking, performance and safety.
- c. Never carry any parcel unfastened.
- d. Load the heaviest parcel on the center of vehicle, balancing the weight on both sides.
- e. Beware of the weight loaded properly and check the tire pressure. The total weight of carrier, driver, passenger, and accessories cannot exceed the approved limit, An overload vehicle is easy to cause tire damage and accident for rider.

- 4.Check is there any sharp Object pierce the tire.
- 5.Check the depth of tire Thread.
 - a. Depth(front & rear):
According to mark of tire “ ”to change a new tire

A. Plastic part dismantle Overview



Dismantle the plastic parts according to above figure sequence by sub-assembly, especially pay attention to followings:

- Before dismantle front fender, dismantle the front wheel assy. First. (G-MAX125/150 only)
- Windshield & frt signal lamp cover shall be dismantled together.
- LH & RH body cover shall be dismantled together.

● **Actual dismantle procedure:**

- Dismantle the upper cover & windshield.
- Loosen 2 tapping screws at the upper with the inner cover.
- Withdraw the windshield decorated cover.



- Dismantle the handle upper cover.
- Loosen 5 tapping screw under the handle.



- Dismantle windshield & turn signal front cover.
- Loosen 1 tapping screw under windshield.
- Loosen 1(LH) & 1(RH) tapping screw under turn signal front cover.



- Loosen 3(LH) & 3(RH) tapping screws of front inner cover.



- Loosen 3(LH) & 3(RH) tapping screws of front inner cover.



- Loosen 1 machine screw in the middle of windshield.
- Dismantle windshield & front turn signal cover together.



- Dismantle the front fender.
- Only for G-MAX125/150:
Loosen nut of front wheel, dismantle the front wheel & brake disc together.
- Loosen screws at LH & RH of front fender, dismantle front fender



- Open the seat.
- Loosen 3 bolts of rear luggage bracket, dismantle it.



- Loosen 4 bolts of front luggage compartment.
- Disconnect the coupling of lighting lamp, dismantle the front luggage compartment.



- Loosen 2 bolts of rear luggage compartment



- Lift the cover with finger, withdraw the cover of rear luggage compartment.
- Withdraw the rear luggage compartment.



- Turn the tank inner cover counterclockwise a little bit, dismantle it.
- Dismantle the tank upper cover by releasing coupling ribs
- Withdraw fuel tank decorated cover.



- Dismantle the keel cover.
- Loosen 2(LH) & 2(RH) screws at the front upper section.




- Loosen 2(LH) & 2(RH) inner socket screws, dismantle the keel cover.



- Dismantle the LH & RH lower cover
- Loosen 4 tapping screws on the top of LH & RH lower cover
- Dismantle quick plastic screw(2 EA in each side)



- Dismantle 1 tapping screw in the front side.
- Withdraw LH & RH lower cver.



- Dismantle other PP covers.



- Dismantle the license plate
- Push the middle of quick plastic screw.




- Loosen 2 screws at the rear of vehicle.
- Withdraw the license plate.



4. G-MAX 125/150 engine Dismantling, Maintaining, Repairing and assembling operation


- (1) Lubrication system
- (2) Engine dismantling
- (3) Install Engine
- (4) Drive pulley, starter, clutch, driven pulley
- (5) Cylinder head and valve
- (6) Cylinder and piston
- (7) AC generator
- (8) Final transmission mechanism
- (9) Crankcase, crank shaft
- (10) Carburetor

(1) Lubrication System




■ Oil Pump Dismantling

1. Remove the rear section of muffler.
2. Remove the AC flywheel magneto.




3. Remove the AC generator coil.
4. Take off the locking bolts of the right crankcase cover.
5. Remove the crankcase cover



6. Remove the washer, lock pin
7. Remove starter reduction gear and the starting clutch.




8. Remove oil pump separate plate by taking off the 2 bolts.
9. Remove the bolts from oil pump driving gear
10. Take off the driving gear and chain.
11. Remove the oil pump by taking off the locking bolt of the oil pump.




■ Oil pump Assembly

1. Install the inner and outer of the oil pump.
2. Install the oil pump shaft.




Note:
The notch of the oil pump shaft should comply With the notch of the inner gear.

3. Install the lock pin.
4. Match the lock pin hole to the pump cover and install the oil pump cover.
5. Put on the screws and tighten them.
6. After installing, turn the shaft lightly to assure installation.
7. Place the oil pump into the crankcase.





Note:
When installing, the arrow on the oil pump body should be pointed upwards. Then fill in the recommended oil before the installation.

8. Tighten the oil pump after installation.



Measurement data

item		Standard Value (mm)	Limit of use (mm)
Oil pump	Clearance between the inner gear And outer gear	-	0.12
	Clearance between the outer gear And oil pump body	0.045-0.10	0.12
	Clearance between gear end and Oil pump body	0.045-0.10	0.12



Troubleshooting

Reduction in fuel oil volume

- Natural consumption
- Leakage of fuel
- Piston loop seizes, or improperly installation
- Worn out of valve's oil seal

Engine burning-out

- Zero or too low oil pressure
- Blockage in oil route
- Did not use the fuel oil recommended

(2) Engine dismantling

1. Take off the luggage compartment.
2. Take off the left and right body covers.
3. Take off the air cleaner fixing screws.



4. Loosen 2 nuts of intake manifold, withdraw intake system assembly.
5. Remove vacuum pipe, fuel pipe, auto choke, cap of spark plug, rear brake cable carburetor pipe, starter motor cable.



6. Remove the rear section of muffler, dismantle the 2 bolts of rear brake caliper, then remove the rear brake system assembly away from rear fork.



7. Loosen bolts of upper & lower engine hanger.

8. Remove the engine.

(3).Installing Engine

1. To install engine, please reverse the Above procedures.

2. Locking torque:

M8: 2.0-3.0kgf.m


M10: 3.0-4.0kgf.m

M12: 5.0-6.0kgf.m

3. After installing, please do the following

Checking and adjustment:

- a. Wiring for each circuit.
- b. Throttle cable
- c. Rear brake check.
- d. fuel and oil route



(4) Drive pulley, starter clutch. driven pulley

A. Troubleshooting

B. Measurement data

C. Driving pulley

D. Starter

E. Clutch driven pulley

A. Troubleshooting:

a. Engine starts, but vehicle don't move.

1. driving belt worn out
2. driving plate worn out
3. clutch lining worn out
4. driving plate's spring broken

b. the vehicle stops or tremble when running.

1. clutch lining spring cracked or broken.

c. Can't reach high speed, no pick-up

1. driving belt worn out.
2. Driving plate spring distortion.
3. Weight roller worn out
4. Driving plate dirty.

Note:


No grease and oil should be distributed over driving belt and driving plate.

B. Measurement data


Item	Standard value (mm)	Limit of use (mm)
The inner dia. Of slide driving plate	24.011~24.052	24.10
The outer dia. Of boss, movable Driving plate	23.960.~23.974	23.940
Belt width	20.0~21.0	19.0
Clutch lining thickness	3	1.5
Clutch outer inner diameter	125.0~125.2	125.5
Driven plate spring, free length	151	127
The outer diameter of driven Plate sets	33.965~34.025	33.95
The inner diameter of slide Driven plate	34.000~34.025	34.06
The outer diameter of weight Roller set	17.920~18.080	17.40

(C)Driving Pulley


1.Take off the screws of left cover, remove the left cover.




2.Remove the lock nuts of driving Plate and the nuts of Starter gear And clutch.



3.Take off the ramp plate, Belt and clutch.



4. Take off the boss and driving plate.



5. Continuous Various Transmission engagement speed inspection

- Connect an electric tachometer.
- Seated on the motorcycle with on level ground, increase the engine's speed slowly and notice the RPM at which the motorcycle begins to move forward.

Specified Engagement RPM : 3100 ± 300 rpm

6. Clutch "LOCK-UP" inspection

- Apply the rear brake as firm as possible
- Briefly open the throttle fully and notice the maximum engine RPM sustained during the test cycle.

Specified Clutch "LOCK-UP" RPM : 5200 ± 400 rpm

5.To assemble the driving pulley, reverse the whole procedure.

Locking torque:

1.Nut of driving pulley M12: 4.0-5.5kg/m.


2.Locking nut of clutch M12: 4.0-5.5kg/m

6.Checking driving belt

(1)check driving belt is cracked or not rubber and fiber is loosened or not also check if they are extraordinary worn out.

(2)driving belt width:

limit of use :change it below 19mm



7.Disassemble slide driving plate set.

(1)Remove bush of slide driving plate.

(2)Remove screw, and disassemble the cover of slide driving plate.


(3)Remove ramp plate.

(4)Remove weight roller.

8.Checlong


(1)Check the wearing condition of weight roller.

Limit of use : change it below 17.4mm



Check the wearing condition


- (2) Check gasket inner dia of slide driving plate: limit of use : change it over 24.1mm.



- (3) Check the driving pulley surface wearing condition.

- (4) Check the outer diameter of the contact surface of the movable driving plate.

limit of use : change it below 23.94mm.



9. Assemble the slide driving plate.

- (1) Clean up the inside surface of slide driving plate, then assemble the roller.
- (2) Assemble the ramp plate.

- (3) Other procedure refers to the opposite procedure of disassembling.



D.Starter dismantle

1.Dismantle left crankcase cover

2.Remove hexagon nut, then remove the starter lever.


3.Remove five screw of separated plate.

4.Remove start spring from
start returning position.

5.Remove driven gear comp. of
kick starter.

6.Remove the retaining C-type
Ring.

7.Remove spindle comp.
of kick starter.



8.Checking starter

- a. Check the wearing condition of the outer diameter of spindle comp and the inner diameter of bush and gear.
- b. Check the wearing condition of shaft of driven gear comp. Gear sets and ratchet.

9.Assembling the starter

Assemble the starter follows the.

Opposite procedure of dismantling.

Locking torque : M6: 1.0~1.2kg/m.

Note:

- ①Make sure one end of the torsion spring is hooked on the groove of driven gear, and another end of torsion spring is hooked on the pole of inside of left crankcase.
- ②Put some grease in every shaft and gear sets before assembly.

E. Clutch driven pulley

1. Dismantling the clutch

- a. Remove left crankcase cover.
- b. Remove driving plate.
- c. Remove driving belt.
- d. Remove locking nut, then remove clutch.

2. Assemble the clutch : follows the opposite procedure of dismantling.

Locking torque:

M12: 4.0~5.5kg.m


3. Checking clutch:

dismantling tool

a. Check clutch driving face.

Check clutch cover about its wearing condition
And inner diameter measurement.


- limit of use: change it above 125.5mm



b. Check clutch lining wearing condition and

Measure the lining thickness.

- limit of use : change it below 1.5mm.



c. Check driving spring free length.

Standard: 151mm

Limit of usage:

Change it below 127 mm

d. Check wearing condition of driving plate sets. And measure outer diameter.

● limit of use: change it above 33.95mm.


e. Check wearing condition of slide driven plate.

And measure its Inner diameter.

● limit of use : change it above 34.00mm.

f. Check is there any wearing occur to the ditch


g. Check wearing condition of oil seal, if necessary,
change a new one.



(5)Cylinder head and valve

A.Trouble shooting

B.The operation data information



1	HEAD COMP. CYLINDER	19	"CAM, SHAFT ASSY. "
2	"GUIDE, EXH VALVE "	20	"SHAFT, EX.ROCKER ARM"
3	O-RING	21	VALVE RXKER ARM
4	"GUIDE, IN VALVE "	22	SCREW TOPPED ADJUSTER
5	VALVE EXHAUST	23	HEXAGON NUT
6	VALVE INLET	24	"SHAFT, EX.ROCKER ARM "
7	GASKET HEAD CYL.	25	LOCK PIN
8	LOCK PIN (D10*14L)	26	CAMSHAFT HOLDER
9	HEXAGON FLANGE BOLT	27	PLAIN WASHER
10	STUD BOLT	28	HEXAGON FLANGE NUT
11	STUD BOLT	29	CYL.HEAD COVER COMP.
12	INSULATOR CARB GASKET	30	CYL.HEAD COVER
13	INSULATOR CARB	31	"PACKING,CYL. HEAD COVER "
14	IGNITION PLUG (CR7HSA)	32	HEXAGON FLANGE BOLT
15	PLAIN WASHER	33	VALVE SEAL
16	"SPRING, VALVE "	34	CLIP
17	RETAIER VALVE SPRING	35	TUBE CYL. COMP.

A.Troubleshooting.

If the cylinder head is malfunctioned, usually it can tell from the measurement of the Compression pressure or from the noise that comes from the upper part of the engine.

1.Unsmooth idle speed

-Compression pressure is too low.

2.Insufficient compression pressure.

-Poor adjustment of valve clearance

-Valve being burned out or bent

-Valve timing is not correct

-Valve spring is damaged.

-Poor sealing of valve base.

-Leakage in Cylinder head gasket.

-Cylinder head twisted or cracked.

-Spark plug is not properly installed.

3.Compression pressure is too high.

-There is too much carbon accumulated in the combustion chamber.

4.There is white fume coming out from the exhaust pipe.

-The valve stem or valve guide pipe is worn out.

-Valve stem's oil seal is damaged.

5.Abnormal noise

-Poor adjustment of valve clearance

-Valve burned or damaged spring

-Camshaft is worn out.

-Chain adjuster is worn out.


-Camshaft, valve rocker arm is worn out.

B.The operation data information


Description	IN/EX	Standard Value (mm)	Limit of use (mm)
Clearance between adjuster tapped Screw and valve stem (Before warm up)	IN	0.08	-
	EX	0.08	-
Compression pressure(throttle open full)		11kg/650rpm	(150CC)
Height of the cam's convex part	IN	26.625(150CC)	26.23(150CC)
	EX	26.53(150CC)	26.13(150CC)
Inner diameter of rocker arm shaft	IN	10.00~10.015	10.10
	EX	10.00~10.015	10.10
Outer diameter of rocker arm shaft	IN	9.972~9.987	9.91
	EX	9.972~9.987	9.91
Valve base angle	IN&EX	1.0	1.8
Outer diameter of valve stem	IN	4.975~4.900	4.90
	EX	4.955~4.970	4.90
Inner diameter of valve guide	IN	5.000~5.012	5.30
	EX	5.000~5.012	5.30
Clearance between valve stem and Valve guide	IN	0.010~0.037	0.08
	EX	0.030~0.057	0.10

C.Dismantling and installing the Cam shaft


- 1.Take off the left cover.
- 2.Remove the intake pipe from the Cylinder head cover.
- 3.Take off the 4 bolts of the cylinder head cover and take off the cylinder head cover.



- 4.Turn the flywheel counterclockwise and let the "T" mark on the flywheel point to the crankcase mark and make the round hole on the cam chain gear point upwards.



- This is the upper dead point of compression.
- 5.Take off the cam shaft holder, the nut and the locking pin.
 - 6.Remove the cam gear from the cam chain.
 - 7.Remove the cam shaft.



Check cam shaft

Check the convex surface and the height and see whether it has been damaged.



Limit of Use:

IN :replace it below 25.90(125CC), 26.23mm(150CC)

EX :replace it below 25.90(125CC), 26.13mm(150CC)


Check camshaft. If the bearing is loosen or worn out, change the whole set if necessary.

Check cam shaft holder

1.Check the cam shaft holder, cam rocker arm, and cam Rocker arm shaft and see whether it is loosen or worn out.

NOTICE:

Do check if there is any damage on the cam rocker arm Sliding surface.



2.Cam shaft holder and cam rocker arm outer dia measurement:

Limit of use : replace it above 10.10mm.

3.Cam rocker arm inner dia measurement:

Limit of use : replace it above 10.10mm.

4.Cam rocker arm shaft and rocker arm outer dia measurement:

Limit of use : replace it below 9.91mm

5.Clearance between the Cam rocker arm and rocker arm shaft.

Limit of use : replace it above 0.10mm.

WHEN INSTALLING:

1.The mark “EX” on the cam shaft holder is the exhaust rocker arm, one-way stopper.

Install the exhaust rocker arm, the inlet rocker arm, and the rocker arm shaft.

NOTICE:

a.The tangen angle of the heat side of intake valve’s rocker arm shaft is to match with the bolt of the cam holder.

b.The tangen angle of the exhaust valve’s rocker arm shaft is to match with the bolt of the cam holder.

2.Turn the flywheel to make the T mark pin correctly. The hole on the cam chain gear should point upwards. Both the left and right concave points and the cylinder head are at parallel position (convex part of cam shaft points upwards), then install the cam shaft on the cylinder head.

3.Install the cam chain onto the cam shaft gear.

4.Install the locking pin.

5.Install the camshaft holder, washer and nuts on the cylinder head.

6.Lock tightly the cylinder head nuts.

Locking torque: Cam shaft holder nuts:2.0kg·m

NOTICE:


a.Put some grease on the bolt thread of cam shaft holder

b.Lock the nuts of the cam shaft bracket in “cross” sequence for 2-3 times.

7.Adjust the valves clearance.

Dismantling the cylinder head:


- 1.Remove the carburetor.
- 2.Remove the muffler.
- 3.Remove the fan cover.
- 4.Remove the bolts on the engine cover.
- 5.Remove the camshaft.



- 6.Remove the cylinder head
- 7.Remove the lock pin, cylinder head gasket.
- 8.Remove cam chain guide

Notice:

- Not to injure the contact Surface of the cylinder.
- Avoid any object dropping into the engine.



Further dismantling

- Use the valve contracting tool to remove valve pin, supporter, the valve spring collar, valve spring and valve stem oil seal.

Notice:

- Valve Spring has to be operated by the valve spring contractor.
- To assemble the cylinder head, please follow the opposite procedure as above.

(6)Cylinder and piston

- A.Trouble shooting
- B.The Operation notice
- C.Data
- D.Dismaniling cylinder, piston
- E.Installing cylinder, piston

C.Data (150CC)

Part name /description		Standard value (mm)	Limit of use (mm)	
Cylinder	Bore	56.990~57.010	57.100	
	Curve	-	0.005	
	Cylindrility	-	0.005	
	Roundness	-	0.005	
Piston/ Piston ring	Clearance b/w Piston and Piston ring	1st ring	0.03~0.07	0.10
		2 nd ring	0.02~0.06	0.10
	Clearance of cutting section	1st ring	0.10~0.25	0.50
		2 nd ring	0.10~0.25	0.50
		side ring	0.2~0.7	---
	Piston outer diameter		56.970~56.990	56.900
	Measuring location of piston outer dia.		Down to 5 mm from the piston skirt	---
	Clearance b/w piston and cylinder		0.025~0.035	0.10
Piston pin hole inner dia		15.006~15.012	15.030	
Piston pin outer diameter		14.990~14.992	14.96	
Clearance between piston and piston pin		0.020~0.017	0.025	
Connecting rod small end inner dia		15.010~15.028	15.060	

A. Troubleshooting.

a. Compression pressure is too low, difficult to start engine and engine running unsmoothly.

1. Cylinder head gasket cracked
2. Spark plug is not well locked
3. Piston ring worn out or cracked
4. Cylinder, piston worn out.
5. Reed valve is out of order.

b. Compression pressure is too high; Engine overheating; abnormal noise.

1. piston tip has too much carbon accumulated.

c. Abnormal piston noise

1. Cylinder and piston worn out.
2. Piston pin hole or Piston pin worn out.
3. Connecting rod small end or bearing worn out.

d. Abnormal piston or cylinder noise

1. Piston ring worn out or cracked
2. Cylinder worn out or cracked

B. The operation notice

1. Clean before operation to avoid particles dropping into the engine.
2. The contact surface of gasket must be clean.
3. Dismantle cylinder and cylinder head by screw driver. Do not injure the contact surface.
4. Cylinder inner surface and piston outer face can't be injured. Contact surface should lubricate by specified oil.


C. Data (125CC)

Part name /description		Standard value (mm)	Limit of use (mm)	
Cylinder	Bore	51.490~51.510	51.60	
	Curve	-	0.005	
	Cylindricity	-	0.005	
	Roundness	-	0.005	
Piston/ Piston ring	Clearance b/w Piston and Piston ring	1st ring	0.03~0.07	0.10
		2 nd ring	0.02~0.06	0.10
	Clearance of cutting section	1st ring	0.15~0.35	0.50
		2 nd ring	0.15~0.35	0.50
		side ring	0.2~0.8	-
	Piston outer diameter	51.460~51.480	51.40	
	Measuring location of piston outer dia.	Down to 7mm from the piston skirt	-	
	Clearance b/w piston and cylinder	0.025~0.035	0.10	
Piston pin hole inner dia	13.022~13.013	13.045		
Piston pin outer diameter	12.996~13.00	12.96		
Clearance between piston and piston pin	0.02~0.017	0.025		
Connecting rod small end inner dia	13.015~13.028	13.060		

D.Dismantling

a.Dismantling Cylinder

- 1.Remove the cylinder head.
- 2.Remove 2 bolts, then the camshaft chain adjuster
- 3.Remove CAM chain guide.
- 4.Remove cylinder.
- 5.Remove the cylinder gasket, lock pin and clean the gasket on the cylinder.



b.Dismantling piston

- 1.Remove the piston pin clip.

NOTICE:

Don't drop the clip into the crankcase.

- 2.Remove the piston pin and take off the piston.
- 3.Check piston, piston pin, piston ring.
- 4.Remove the piston ring

NOTICE: NOTICE:

Don't make piston ring worn out or damaged

- 5.Clean the carbon in the groove of the piston ring.


c.PISTON OUTER DIA MEASUREMENT:

- 1.Measuring location:

Perpendicular to the piston pin hole, down to 7mm(125CC), or 5mm(150CC) from the piston skirt.

Limit of use : change it when less than 51.4mm.(125CC)

Limit of use : change it when less than 56.9mm.(150CC)



- 2.The clearance between the piston and piston pin:


Limit of use : change it when above 0.005mm

- 3.Checking any wearing, damage inside the cylinder.

Vertical to piston pin, and in X-Y direction to measure cylinder bore from the upper, middle and lower location.

Limit of use : Change it when above 51.6mm.(125CC)

57.1mm(150CC)




- 4.The maximum clearance between the cylinder and piston pin.

Limit of use : Change it when above 0.1mm.

5.The difference between the X and y is the roundness.


6.The cylindrility is the max value of the difference between the upper, Middlle and lower position of the inner dia in X or Y direction.

Limit of use : Roundness:change it when above 0.005mm.
Cylindrility:change it when above 0.005mm.




d.Checking the flatness of cylinder contact surface.

Limit of use : change it when above 0.05mm.



e.Connecting rod small end inner diameter measurement.

Limit of use : change a new one when above 13.06mm.(125CC)
15.06mm.(150CC)



E. Installing Cylinder and piston

a. Installing piston and piston rings

1. Lubricate the piston rings by motor oil.

NOTICE:

a. Be careful not to scratch the piston and not to break the piston ring.

b. The mark (on the ring) should be upward when installing.

c. after installing, the ring should be smoothly rotated.

2. Clean up the residual gasket on the crankcase.


NOTICE:

Do not drop other objects into the crankcase.

3. Assembly the piston, piston pin and piston pin clip.

NOTICE:

- a. The mark "IN" on the piston tip should face to the INLET side.
- b. Do not drop the piston pin clip into the crankcase and to clog the crankcase with rags.



b. Installing piston

1. Fix the lock pin and gasket on the crankcase.
2. Lubricate the Cylinder inner surface, piston and piston rings by Motor Oil.
3. Install the piston ring into the cylinder carefully.

NOTICE:

- a. The piston ring cannot be damaged or cracked.
- b. The cutting section of three rings must be arranged at intervals of 120°


(7)A.C. Generator

A.Dismantling AC generator


B.Installing AC generator

Dismantling AC generator

1. Dismantle the rear section of muffler.
2. Remove fan cowl.
3. Remove the M6 screws
4. Remove screws of flywheel magneto.
5. Remove the AC flywheel magneto by special tool.



6. Remove the flywheel.
7. Remove the electric plug of AC flywheel magneto.




B. Installing AC generator

To install, please reverse the dismantling procedure.

Locking torque:

M6: 1.0~1.2kg/m

M12: 3.2~4.0kg/m



(8)Final transmission mechanism

- A. Troubleshooting.
- B. Dismantle the final transmission mechanism.
- C. Check the final transmission mechanism.
- D. Assemble the final transmission mechanism.

A. Troubleshooting

- Engine can be started, but the vehicle doesn't move.
 - 1.Gear worn-out or cracked.
 - 2.Gear burnt out.
- Noise occur when running.
 - 1.Gear worn out, burnt or gear surface.
 - 2.Bearing worn out of loosen.
- Oil leakage
 - 1.Too much oil
 - 2.Seal worn out or damaged.

B. Disassemble the final transmission mechanism:

1.Remove the rear wheel.




2.Drain the oil in the gear box.



3.Remove the bolt in the gear box cover.

Take off the gear box.




3.Remove the final reduction gear
And idle gear.

5.Clean up the gear box.

C. Check the final transmission mechanism


1.Check the wearing condition of driving shaft and gears.

Gear teeth number: 14 T (125CC) ; 15 T (150CC)




2. Check the wearing condition of idle gear shaft and idle gears.

Gear teeth number 43 T (125CC) ;
 42 T (150CC)



3. Check the wearing condition of the final reduction gear.



4. Check the wearing condition of the oil seal and bearing.

D. Assemble the final transmission mechanism, please follow the opposite procedure of disassembling. After locking the drain bolt, refill 90cc of gear oil SAE90.


Locking torque:	M6: 1.0~1.2kg/M
	M10: 3.5~4.0kg/M
Drain bolt:	M8: 1.8kg/M

(9)Crankcase, Crankshaft:

- A. Disassembling diagram.
- B. Troubleshooting.
- C. Data
- D. Remove crankcase and crankshaft.
- E. Check crankshaft.
- F. Assemble the crankcase.

A. Disassembling diagram

Torque : 1.0~1.2kg- m



B. Troubleshooting

Engine noise:


- 1.The bearing of final transmission mechanism is loosen.
- 2.Crank pin of bearing is slack.
- 3.The bearing of gear box is loosen.

C.Data

Item	Standard value(mm)	Limit of use.(mm)
Clearance of connecting rod big end axle direction	0.10~0.35	0.55
Clearance of connecting rod big end vertical direction.	-	0.04
Swingness of the crank shaft journal.	0.03	0.10

D. Remove the crankcase and crankshaft by the following procedures:


- 1.Remove the engine.
- 2.Remove the muffler.
- 3.The carburetor.
- 4.Engine corer.
- 5.Cylinder head.
- 6.Cylinder.
- 7.The driving plate.
- 8.AC flywheel magneto.
- 9.The starter clutch.
- 10.Oil pump.
- 11.Bolts of left/right crankcase.



E. Check crankshaft


1. Measure the difference of the connecting rod big end between the X and Y

Limit of use : replace it when above 0.04mm.




2. Measure the swing ness of the crankshaft journal.

Limit of use	
A	B
Change it when above 0.1mm	Change it when above 0.1mm



3. Check the looseness of crankshaft bearing.
If it is loosen, replace to a new one.



F. Assemble crankcase:

1. assemble crankcase according to the opposite procedure of disassembling.
2. The locking torque of bolts and nuts are described in previous chapter please refer.

(10)Carburetor:

- A.Troubleshooting.
- B.Dismantling the carburetor.
- C.Dismantling the float and nozzle.

CARBURETOR SPECIFICATIONS:

ITEM	SPECIFICATION	SPECIFICATION
Model	M2-125	M2-150
Carburetor type	KEIHIN CVK24	KEIHIN CVK24
Bore size	24mm	24 mm
I.D. NO	013	115
Idle r/min	1700 ± 100	1700 ± 100
Float height	18.0 ± 0.5 mm	18.0 ± 0.5 mm
Main jet	#102	#102
Jet needle	4HGGN	4HGGN
Needle jet	P-O	P-O
Pilot jet	#35	#38
Pilot screw (PRE-OPENING)	2 1/4 turns out	1 1/ 2 turns out

(A) Troubleshooting

●Difficult to start

- 1.No sparking in spark plug.
- 2.Compression pressure too low.
- 3.No fuel in the carburetor
 - air cleaner blocked
 - oil pipe blocked
 - bad adjustment of the fuel level
- float valve is jell

●Mixed air too dilute

- 1.Main jet blocked
- 2.Float valve blocked
- 3.Fuel level too low
- 4.Fuel system blocked
- 5.Second air sucked into intake system
- 6.Bad vacuums during piston movement
- 7.Throttle valve malfunction

● Too much fuel in the engine

1. Air cleaner blocked
2. Mixed air is too dilute in the idle system

● Sparking unsteady while increasing speed

1. Ignition system malfunction.
2. Air mixture is too dilute

● Difficult to start, Ignition off, Unstable idling


1. Fuel system blocked
2. Ignition system malfunction
3. Air mixture is too dilute or too thick
4. Fuel deterioration
5. Second air sucked into intake system.
6. Bad idle adjustment
7. Bad fuel volume adjustment
8. Idle system or fueling system blocked
9. Bad adjustment of fuel level

● Mixture air too thick

1. Auto choke system malfunction
2. Float valve malfunction
3. Fuel level is too high
4. Air route blocked
5. Dirty air cleaner
6. Fuel overwhelming in carburetor

(B)Dismantling the carburetor

- 1.Remove the auto starter connector.
- 2.Remove the throttle cable, then the fuel pipe from the carburetor.



- 3.Remove the screws on the intake manifold.
- 4.Unscrew the fixing belt on the connecting pipe.
- 5.Remove the carburetor.

Assembling the carburetor

To assemble the carburetor, please follow the reversed procedures of the dismantling and do the following adjustment after installation is finished:

- Adjust the throttle cable
- Idle adjustment

Adjustment of fuel volume adjusting screws

Note :Fuel volume adjusting screws have been set up properly before sale thus there is no need for self-adjustment. However, when dismantling, a record of the turning loop has to be kept for future assembling purpose. Put up the center stand while adjustment.

- 1.After the engine is warm up, adjust the stopping screw throttle of throttle valve to the standard rpm.
Idle rpm $1,700 \pm 100$ rpm
- 2.Adjust the fuel volume adjusting screws to the highest stable rotation.
This rotation value is the optimum setting of throttle
- 3.Fuel up for several times, make sure that the idle rpm is within the standard rpm.
Repeat the above procedure if the idle rpm is unstable.

(C)The float nozzle

1.Dismantling

- Remove the screws to take off the float chamber.
- Remove the float, the float pin, and float valve.

2.Checking

- Check the float valve, valve base to see whether it is blocked or damaged.
- Check the float valve, valve base surface if sectional worn out or dirty.

Note:
When the valve is too dirty or severely worn-not, the Valve base will not close completely thus will result In increasing of fuel level and fuel leakage problem. A new replacement is needed.

- Remove the main jet, needle jet base, needle jet, slow jet and fuel adjusting screws.

Note:
●Avoid any damage on the jets and the fuel adjusting screws.
●Before dismantling, record the number of turning loops.
●No screwing-in movement by force to avoid any damages.

- Use the detergent solution to clean the jets. Fuel adjusting
After cleaning off the blockage and the dirt, screw
blow dry by compressed air.

Note:
Remove the vacuum and air-interrupt valve for Cleaning.

3.Assembling



- Assemble the slow jet, needle jet, main jet and fuel adjusting screws.

●Notice
Record the number of turning loops before dismantling

- Assemble the float valve, float and float pin.

4.Checking fuel level

Notice
●Check after the checking on the float valve and the float is done.
●Put the float gauge on the float chamber perpendicularly to the main jet for measurement.





DIAPHRAGM AND PISTON OPERATION

The carburetor is a variable-venturi type, whose venturi cross sectional area is increased or decreased automatically by the piston valve①. The piston valve moves according to the negative pressure present on the downstream side of the venturi **A**. Negative pressure is admitted into the diaphragm chamber ② through an orifice ③ provided in the piston valve①.

rising negative pressure overcomes the spring ④ force, causing the piston valve ① to rise into the diaphragm chamber and prevent the air velocity from increasing. Thus, air velocity in the venturi passage is kept relatively constant for improved fuel atomization and precise air/fuel mixture.

LOWER POSITION OF
THE PISTON VALVE

UPPER POSITION OF
THE PISTON VALVE



NEGATIVE
PRESSURE →


SLOW SYSTEM

This system supplies fuel during engine operation when the throttle valve ① is closed or slightly opened. The fuel from the float chamber ② is metered by the pilot jet ③ where it mixes with air coming in through the pilot air jet ④. This mixture, rich with fuel, then goes up through the pilot passage to the pilot screw ⑤. Part of the mixture is discharged into the main bore through bypass ports ⑥. The mixture is metered by the pilot screw ⑤ and sprayed into the main bore through the pilot outlet port ⑦.


COASTING ENRICHMENT SYSTEM

The coasting enrichment system is included in the slow system. At the normal running operation, joining of the air from upper part of the carburetor inlet side to pilot air passage ⑧ which obtains proper fuel/air mixture ratio. But if the throttle valve is closed suddenly, a large negative pressure generated in the cylinder which is applied to the diaphragm ⑨. The valve ⑩ which interlocks with the diaphragm ⑨ closes an air passage ⑧, thus, the fuel/air mixture ratio by controlling air flow in the pilot circuit.

(NORMAL CONDITION)



(LARGE NEGATIVE PRESSURE GENERATED CONDITION)




MAIN SYSTEM

As the throttle valve ① is opened, engine speed rises and negative pressure in the venturi **A** increases. This causes the piston valve ② to move upward.

The fuel in the float chamber ③ is metered by the main jet ④. The metered fuel enters the needle jet ⑤, mixes with the air admitted through the main air jet ⑥ and forms an emulsion.

The emulsified fuel then passes through the clearance between the needle jet ⑤ and jet needle ⑦ and is discharged into the venturi **A**, where it meets the main air stream being drawn by the engine. Mixture proportioning is accomplished in the needle jet ⑤. The clearance through which the emulsified fuel must flow ultimately depends on throttle position.



AUTO-ENRICHENER (AUTO-CHOKE) SYSTEM

The automatic enrichener (automatic choke) device consists of the PTC heater **A**, the thermo-wax **B** and the plunger/needle **1**. When the thermo-wax **B** is cold, the plunger/needle **1** moves upward, Fuel is drawn into the enrichener circuit from the float chamber **2**.

Enricher jet **3** meters this fuel, which then flows into fuel pipe **4** and mixes with the air coming from the upper part of the float chamber **5**. The mixture, rich in fuel content, reaches upper part of the fuel pipe and mixes again with the air coming through a passage extending from main bore **6**. The two successive mixings of fuel with air are such that proper fuel/air mixture for starting is produced when the mixture is sprayed out through outlet port **7** into the main bore.

NOTE:


An enrichener is operated almost the same way as a choke.

When the engine is cold:

The automatic enrichener passage is always open as the thermo-wax remains atmospheric temperature.

When the engine is started:

According to the PTC heater temperature, the thermo-wax gradually expands and closes enrichener passage by the needle of the plunger.





FLOAT SYSTEM

The float ① and needle valve ② work in conjunction with one another. As the float chamber ③, the float ① rises and the needle valve ② pushes up against the valve seat. When this occurs, no fuel enters the float chamber ③.

As the fuel level falls, the float ① lowers and the needle valve ② unseats itself; admitting fuel into the float chamber ③.


In this manner, the needle valve ② admits and shuts off fuel to maintain the appropriate fuel level inside the float chamber ③.



ACCELERATOR PUMP SYSTEM

This system works only when the rider opens throttle grip quickly as pump send the necessary amount of fuel to the carburetor bore for correcting fuel/air mixture ratio. When the rider open the throttle grip quickly, the intaken air volume becomes large and air velocity at the bottom of the throttle valve (piston valve) is slow and sucking volume of fuel is less.


The throttle valve lever ① pulls lever ② with the cable, and lever ③ turns and pushes rod ④. The rod ④ pushes plunger ⑤. This plunger pushes out the fuel through outlet pipe ⑥, spraying fuel into the main bore.



INSPECTION

Check the following parts for damage and clogging.

- * Pilot jet
- * Main jet
- * Main air jet
- * Pilot air jet No.1 & No.2
- * Needle jet holder
- * Float
- * Jet needle
- * Piston valve
- * Starter jet
- * Gaskets and O-rings
- * Pilot outlet and bypass
- * Coasting enrichment valve
- * Needle valve
- * Valve seat




if any abnormal condition is found, wash the part clean. If damage or clogging is found, replace the part with a new one.

CARBURETOR CLEANING

!WARNING

Some carburetor cleaning chemicals, especially dip-type soaking solutions, are very corrosive and must be handled carefully. Always follow the chemical manufacturer's instructions on proper use, handling and storage.



- Clean all jets with a spray-type carburetor cleaner and dry them using compressed air.
- Clean all circuits of the carburetor thoroughly-not just the perceived problem area. Clean the circuits in the carburetor body with a spray-type cleaner and allow each circuit to soak, if necessary, to loosen dirt and varnish. Blow the body dry using compressed air.

!CAUTION

Do not use a wire to clean the jets or passageways. A wire can damage the jets and passageways, if the components cannot be cleaned with a spray cleaner it may be necessary to use a dip-type cleaning solution and allow them to soak. Always follow The chemical manufacturer's instructions for proper use and cleaning of the carburetor components.

- after cleaning, reassemble the carburetor with new seals and gaskets.

AUTO-ENRICHENER INSPECTION

- Disconnect the lead wire coupler①.
- Remove the cover②.
- Connect the positive terminal of a 12V battery to Yellow/white lead and the negative terminal to Black/White.
- Check that the auto-enrichener section ③ (PTC heater built-in area) is heated in 5 minutes after the battery has been connected.

NOTE:

To inspect the function, check for change of temperature from the cold condition.

!CAUTION


Do not attempt to disassemble the auto-enrichener for the purpose of checking temperature.

FLOAT HEIGHT ADJUSTMENT

To check the float height, turn the carburetor upside down. Measure the float height **A** while the float arm is just contacting the needle valve using vernier calipers.

Bend the tongue as necessary to bring the float height **A** to the specified level.

Float height **A**: $20.8 \pm 1.0\text{mm}$



(D)Handle bar, front wheel, front brake and front fork:

A. Troubleshooting


- 1.steering handlebar is abnormal, too tight.
 - a.steering mechanism; washer of conical bush locked too tightly.
 - b.steering mechanism; steel ball is cracked.
 - c.steering mechanism; steel ball base and washer of conical base is damaged.
 - d. wheel pressure is too low.
- 2.steering handlebar is aslant.
 - a.left and right damper are not even.
 - b.Front fork is crooked.
 - c.The axle of front fork is crooked or the wheel is aslant.
- 3.front wheel swings.
 - a.wheel rim is distorted.
 - b.bearing of front axle is loose.
 - c.wheel spoke is distorted.
 - d.Tire worn out.
 - e.The wheel axle is improperly assembled.
- 4.front damper is too soft, or spring fatigue.
- 5.Noise in front damper.
 - a.noise comes form the shock absorber tube.
 - b.locking screw of damper is loose.

B. Data

Item	Model	Standard value(mm)	Limit of use.(mm)
thickness of frt pad	M2-50	5.3	3.3
thickness of frt pad	M2-125/150	8.3	5.3
Disk of frt brake	M2-50	3.5	3.0
Disk of frt brake	M2-125/150	4.0	3.5
thickness of REAR pad	M2-125/150	10.0	7.0
Swingness of frt/rr wheel	M2-50/125/150	-	2.0
The lining of rr Brake	M2-50	4.0	2.0

C. Change the speedometer cable:

1.Remove the front handle cover.



2.Remove the nut of the speedometer cable.



3.Remove the fixed screw of the speedometer cable on the front wheel.

4.Pull out the damaged speedometer cable.

5.To assemble the new cable, please follow the opposite of dismantling procedures.

Note: Put some grease onto the inner cable before assembling.

(D)Steering handlebar

- 1.Remove the LH/RH back mirrors.
- 2.Remove the upper handle cover.
- 3.Remove the nuts on front fork and handlebar.
- 4.Take off the fixing bolt.
- 5.Remove the nut and bolt of the front fork fixed on
The handlebar.
- 6.Take off the handle bar.



- 7.When assembling, please follow the opposite procedures.

Locking Torque:

M6 : 1.0-1.2kg- m

M10 : 3.0-4.0kg- m

- 8.Before assembling, please add grease on each cable.

(E)Front wheel

- 1.Remove the locking nut of the front wheel on the right side.
- 2.Draw out the axle of front wheel, remove the ring and take off the gear sets of speedometer.
- 3.Remove the front wheel assy.
- 4.Assemble the front wheel follows the opposite procedure of dismantling.


Locking Torque:

M10: 3.0-4.0kg·m




Note:

- 1.Put the lock block of speedometer gear assy upon the extrusion of the front fork.
- 2.Put the grease onto the grease sets of speedometer before assembling.
- 5.Checking the front wheel axle
 - a. Check the bending degree of the front axle.
 - b. Take note of the bending degree on the middle of axle.
 - c. Limit of use: Change it when above 0.2 mm.



6. Front wheel bearing checking

Turn the tire. If the bearing is
Loosen or any occurrence for noise,
Please change a new one.



7. Front wheel rim checking

(1) Check the swing of the front wheel rim.


(2) Limit of use:

- Horizontal direction:

Change a new one when above 2.0mm.

- Vertical direction:

Change a new one when above 2.0mm.



(F)Front brake


1. Disassembling and assembling of the front brake comp.

- a. Remove two bolts fixed on the front brake comp and the front fork.
- b. Remove the front brake comp.
- c. Assemble the front brake comp.

Follows the opposite procedure of dismantling.

Locking Torque:


M8: 2.0~3.0kg-m



2. Air releasing of the front brake comp

The procedure of air releasing

- A. Fill the enough brake oil to the container
- b. Do not let the brake oil overflow from the master cylinder or container when assemble the master cylinder cover.
- c. Put the spanner upon the drain screw.
- d. Lock and unlock the screw several times to Release the bubbles.



- e. Operate slowly the brake lever several times.
- f. Clamp the brake lever to the end.
- g. Loose the drain screw, then open the lever completely.
- h. Locking the drain screw and then loose it when the lever is opened completely.
- i. Repeat above procedure until all the air in the brake system has been released Completely.

Locking torque of leaking screw: 0.6 kg-m

3. Front fork checking:

If it is bent or cracked, please replace with a new one.

4. Front shock absorber checking

Check if there is any unusual damage or worn-out condition, and whether the guide rod of the front fork is crooked or not.



Fork oil type: SAE 10W20

Capacity (each side): 84 CC (M2-50)

Capacity (each side): 95 CC (M2-125/150)

NOTE:

If the guide rod is crooked, it should be replaced by a new one or repaired.



5. Disassembling and assembling the front brake-disk.

- a. Remove the front wheel.
- b. Remove bolts on the disk.
- c. Remove the disk.
- d. Assemble the disk follows the disassembling procedure.

Locking torque M8: 2.0~3.0kgm

6. Checking the front brake-disk.

Standard thickness of disk: 3.5 mm (M2-50); 4.0 mm (M2-125/150)

Limit of usage: change it when below 3.0 mm (M2-50); 3.5 mm (M2-125/150)

7. Checking the front brake-PAD.

a. standard thickness: 5.3mm(M2-50); 8.3mm(M2-125/150).

limit of use: As the thickness is below using limit, change it.


Note: No grease on the lining.



M2-125/150



M2-50



(E)Rear wheel, rear brake, rear damper:

A. Troubleshooting.

1.Rear wheel swings.

- a. Wheel rim is distorted.
- b. Tire worn out.
- c. The wheel axle is improperly assembled.

2.rear damper is too soft.

- a. Spring fatigue.

3.Bad braking

- a. The adjustment of brake is not proper.
- b. The brake lining is dirty.
- c. The brake lining worn out.
- d. The cam of brake lining is worn out.
- e. The brake cam lever worn out.
- f. The wheel hub worn out or damage.
- g. The operation on the brake arm tooth is not good.

B. Data

Item	Model	Standard value(mm)	Limit of use(mm)
The swingness of rear wheel	G-MAX	-	2.0
Wheel hub (inner diameter)	M2-50	110.0	111.0
Thickness of brake lining	M2-50	4.0	2.0
Brake disc thickness	M2-125/150	4.0	3.5
Thickness of brake pad	M2-125/150	8.3	5.3

C. Disassembling and assembling the rear wheel.


- 1.Remove the rear mudguard and the exhaust pipe.
- 2.Remove the locking nut of the rear wheel
- 3.Remove the rear wheel
- 4.To assemble the rear wheel please reverse the dismantling procedure.

Locking torque: M6 : 0.7-1.1kg-m
M14: 8.0-10.0kg-m



D. Checking the rear wheel

- a. check the swingness of rear wheel.
- b. vertical direction:
change it when above 2.0mm
- c. horizontal direction:
change it when above 2.0mm



E. Rear brake: (M2-50)

1. Rear brake disassembling diagram.


(1) Checking the rear brake hub:

- a. measure the inner diameter of rear brake hub.
- b. Limit of use: change it when above 111.0mm



2. Checking the brake lining: (M2-50)

- a. measure the thickness of the rear brake lining.
- b. limit of use: As the thickness is less than 2.0 mm, change it.




3. Brake pad inspection for M2-125/150



F. Rear absorber

1. Check the locking torque of rear absorber at lower & upper.
2. Both locking torque is 3.5~4.5 kg-m.
3. Oil leakage check is always necessary.



(F) Fuel supply

A. Troubleshooting.


1. Engine can't start:

- a. No fuel in fuel tank.
- b. Fuel pipe is blocked.
- c. Auto cock and filter is blocked.
- d. The membrane of auto cock is over swell.

2. The membrane of auto cock is over-extended.

- a. Fuel tank cover's ventilation hole is blocked.
- b. Fuel pipe is crooked, squeezed, or blocked.
- c. Auto cock and fuel filter is dirty.

B. Fuel supply system diagram:




C. Dismantling and assembling Fuel Tank

- 1.Remove the front luggage box.
Open the fuel tank cover cap.
- 2.Remove the fuel tank cover..

- 3.Remove the fuel pipe.
- 4.Remove the connecting terminal of
the fuel gauge.

- 5.Remove the fuel gauge.
- 6.Remove the fixing blot of the fuel tank.
- 7.Take off the fuel tank.
- 8.When re-assembling, please follow the
opposite procedure of disassembling.
Locking torque: M6: 1.0-1.2kgf·m



V. Electric equipment:

(1) Troubleshooting

(2) Battery

1. Check the cells of battery
2. recharging
3. Test the recharging performance

(3) Recharge system

1. the wiring diagram of recharge system
2. check A.C. flywheel magneto.
3. Check regulator/rectifier.

(4) Ignition system

1. the wiring of ignition
2. check spark plug
3. check H.T. cable and H.V. coil
4. check C.D.I. set

(5) Starting system

1. the wiring of starting
2. checking the starter
3. dismantling the starting motor
4. checking the starting motor

(1) Troubleshooting:

A. Recharge system:

•No power:

1. Battery over discharging
 - ① No electrolyte in battery.
 - ② Battery is bleached
 - ③ Short circuit in the Battery.
 - ④ Regulator malfunction
2. The battery wires are disconnected.
3. Fuse is broken.
4. Ignition switch is abnormal.

•Voltage is too low:

1. Battery recharges insufficiently.
2. The bad connection on wiring system.
3. Recharge system is abnormal.
4. Regulator malfunction.

B. Ignition system:

•The sparking of spark plug is abnormal:

1. Spark plug is dead.
2. Wire connection is broken or short Circuit.
 - ① between A.C. generator and CDI sets
 - ② between CDI sets and High Voltage coil.
 - ③ between CDI sets and main switch.
 - ④ between main switch and spark plug.
3. Main switch is out of order.
4. H.V. coil is not in good function.
5. CDI sets is out of order.
6. A.C. generator is not in good function.

C. Starting system:

•Starting motor can't rotate:

1. The fuse is broken.
2. Battery recharges insufficiently.
3. Main switch is out of order.
4. Starting motor switch is out of order.
5. Front/rear brake switch is out of order.
6. Starter relay is out of order.
7. Wire disconnects or broken.
8. Starting motor is out of order.

•Currency is unstable.

1. The wiring of battery connection is not good.
2. Ignition system connection is not good.
3. Ignition system is short circuit.
4. Lamp system connection is not good or short circuit.

•Abnormal recharge system:

1. The plug connection is not good.
wire broken or short circuit.
2. Rectifier is out of order.
3. A.C. flywheel magneto is abnormal.

D. Engine running unsmoothly:

1. Ignition primary circuit.

- ① the wire or plug of wiring connection is not good.
- ② main switch disconnects.

2. Ignition secondary circuit.

- ① Ignition coil is not in good function
- ② Spark plug is dead.
- ③ H.V. coil is not in good function.
- ④ The spark plug cap is not in good function.

3. Ignition timing

- ① A.C. generator is out of order.
- ② A.C. coil is not in good function.
- ③ C.D.I. sets is out of order.

•Starting motor runs weakly.

1. Battery recharges insufficiently.
2. Wiring system disconnects.
3. The alien objects drop in the motor or gear.

•Starting motor can rotate, but engine can't start up.

1. Starting gear is abnormal.
2. Starting motor is reversedly rotating.
3. Battery is out of order.

(2)Battery:

1.Check the cells of battery.

Always remove the battery negative
Cable(-)first, then positive cable
(+). But connect the positive cable
(+)first, then connect the
Negative cable(-) when assembling.

M2-50



M2-125/150



2.Recharge

- Connection procedure:

connect the positive cable(+) of the negative cable(+) of the battery, and the negative cable(-) of the recharge to the negative cable(-) of the battery.

- Recharging currency:

Please recharge (12V) according to the following current and time.

Standard: 0.4A * 4-10Hr or Rapid:3A * 60min(50cc)


Standard: 0.7A * 5-10Hr or Rapid:3A * 60min(125/150cc)

NOTICE:

This battery is totally sealed. Do not remove seal bolt when recharging.

Notice:

- Keep away from fire when recharging.
- The “ON” or “OFF” of recharging. currency must be operated by the switch of recharge. It will cause spark or explosive if plug or unplug the cable directly.




3. Testing the recharging performance

- This test needs to be done when the battery is fully recharged.
- This test needs to be done after engine is warm-up.

- a. Disconnect the orange cable of regulator.
- b. Open the fuse box, to remove the white cable.
- c. Connect currency meter between red/white cable and fuse.

While testing, the red wire cable must not touch the frame.



- d. Set the head lamp switch at “OFF”, engine revolution is at 2000 rpm while testing. Then increase the rpm slowly. (Assume the battery is fully charged. situation)

Head Lamp Switch	Recharging rpm	2,500rpm	6,000rpm
OFF(DAY)	Under 2,000rpm	0.6A(MIN)	1.5A(MIN)
ON(NIGHT)	Under 2,000rpm	0.6A(MIN)	1.5A(MIN)

- e. If the testing result does not match the standard value, check the regulator.

BATTERY CONSTRUCTION

This motorcycle uses an MF (Maintenance Free) battery. As shown in the right illustration, the battery consists of electrodes, separators, safety valve, filter, etc. Fine glass fiber is used for constructing the separator which holds electrolyte inside.

When a discharged conventional open type battery is recharged fully, lead sulfate turns to lead dioxide and sponge-like lead. If recharging is further continued, charging current is consumed for electrolytic action producing oxygen gas from the positive and hydrogen gas from the negative electrodes. This causes electrolyte to be lost thereby requiring addition of water.

In an MF battery, however, no water loss is caused. In this Battery, the negative electrode is designed not to fully turn To lead (sponge-like lead) even under fully charged condition. For this reason, the negative electrode remains always in non-complete charged condition producing no hydrogen gas. Oxygen gasses produced at the positive electrode will immediately react With an active material (lead) at the negative electrode to turn back to water, thus preventing water from losing.

PRECAUTION WHEN HANDLING BATTERY ELECTROLYTE

- Take most care so as not to cause battery acid to contact a person and the vehicle.
- If battery acid has contacted the skin, clothes or vehicle, immediately flush with plenty of water. If battery acid remains contacted, burns of skin, damage to clothes, peeling or discoloration of paint will occur.
- Should battery acid gets in eyes, immediately flush with plenty of water and call physician.

ELECTROLYTE FILLING

! CAUTION




Make sure to use electrolyte specified for each Battery type.

Using electrolyte designed for other battery type can cause Electrolyte leak, performance deterioration or shortened life.

- Remove the aluminum tape ① sealing the battery electrolyte filler holes ②.
- Remove the cap ③ from the electrolyte container.

! CAUTION


- Handle the removed cap carefully after filling electrolyte as the cap is reused for sealing the battery filler holes.
- Do not remove or pierce the sealed areas ④ of the electrolyte container.



- Insert the nozzles of the electrolyte container into the battery's electrolyte filler holes, holding the container securely.

! CAUTION

- Take precaution not to allow any of the fluid to spill.
- Insert the nozzles squarely to the battery.



- Check that air bubbles are coming up from each electrolyte container and leave in this position for more than 20 minutes.


NOTE:

If no air bubbles are coming up from the filler port, tap the Bottom of the container two or three times.

Never remove the container from the battery.

! CAUTION

Make sure to fill all the amount of electrolyte into The battery.



it is important to check all the cells are filled with electrolyte completely because insufficient filling of electrolyte in even one cell will result in deteriorated performance and shortened life.

INSERTING CAP (SEALING PLUG)

! CAUTION





Fit the cap securely.

To install the cap, temporarily fit the cap to all the cells Lightly, thereafter press the cap little by little into each filler Hole evenly and horizontally.

Inserting the cap at once in one cell and then in the next Cell will cause the cap to deform resulting in poor sealing.

! CAUTION

- Wipe completely if the filler hole is wet with electrolyte.
- Do not remove the caps once it has been installed to the battery.



PRECAUTION FOR HANDLING BATTERY

The battery produces combustible gasses and therefore can explode if handled improperly. Use Caution for the following in addition to general service precautions.



- Never allow the battery to short-circuit. Keep away from sparks and fire.
- Charging of the battery must be operated in an open and well ventilated area and never operate in an closed indoor.
- Using pocket tester, measure the battery terminal voltage. The tester should indicate more than 12.5 – 12.6V. If the battery voltage is lower than the specification, recharge the battery with a battery charger in accordance with the following instructions.

NOTE:

Initial charging of a new battery is recommended if two years or longer have elapsed since the date of manufacture.

RECHARGING

- Using the pocket tester, check the battery voltage. If the voltage reading is less than the 12.0V, recharge the battery with a battery charger.
- When recharging the battery, remove the battery from the motorcycle.
- Practice the standard charging unless otherwise necessary.



Recharging	
Standard	0.7A*5-10 hours
Quick	3A*1hour

- After recharging, wait for more than 30 minutes and check the battery voltage with a pocket tester.
- If the battery voltage is less than the 12.5V, recharge the battery again in the same condition. If battery voltage is still less than 12.5V after recharging, replace the battery with a new one.

NOTE:

When the motorcycle is not used for a long period, check the battery every 1 month to prevent the battery from deterioration.

! CAUTION


The charging system on this model is designed For MF battery and therefore do not use a battery of other specification.

BATTERY REMOVAL


1. Open the front trunk.
2. Remove the battery cover①.
3. Disconnect the battery lead first.
4. Disconnect the battery lead.
5. Remove the battery.

(3) Recharge system:

A. Recharge system diagram for M2-50




B. Recharge system diagram for M2-125/150



2. Check A.C. Generator

- a. Open the seat cover and remove the luggage box.
- b. Measure the resistance value of terminals.

Yellow V.S. black 0.1-1.0
White V.S. black 0.2-2.0




ACG inside


3. Check regulator

Measure the resistance value between each terminal,
It should be in the specified range, otherwise change a new one.

M2-50




M2-125/150



(4) Ignition system:

1.the wiring or ignition



2.Check spark plug.


3.Check the H.V. cable and H.V. coil by using the CDI tester.

4.CDI sets checking.

Check with the CDI tester and please follow the instruction manual.

If the CDI test failed, please change a new one.

Ignition coil




CDI



(5)The starting system:

1.The wiring of starting




2.Make sure the Engine RUN/OFF switch is in “Run” position.


3.Check the safety switch by operating the brake lever, and the brake lamps shall light on.

4. check the starting relay

a. Find the control coil by measuring the resistance.



b. Connect green/white cable to positive pole of battery, connect black cable of negative pole of battery, It means starter is function well if above connection and both Red Black cable of starting motor have currency passing through.



3. Dismantling the starting motor

- (a) Remove 2 screws on starting motor.
- (b) Remove starting motor cables.



4. Checking the starting motor

- Check the function by connecting the starting motor to battery.
(Check if it is rotating counter clockwise)

Note: Do not operate starting motor for a long time.

PGGO

SCOOTERS



Office: 5400 N Damen Ave
Chicago IL 60625
Tel: 773-271-8514
Fax: 773-271-8518
email: info@genuinescooters.com

www.genuinescooters.com