



Touring 150 DE Diagram 5 ----- Steering & Front End

Touring 150 DE Diagram 5 ---- Steering & Front End

# in Diagram	Name/Description	Category	Phone Reference #
1	RIGHT MIRROR	BODY & HARDWARE	150T-H-5-1
2	BOLT M8*45	BODY & HARDWARE	150T-H-5-2
3	WASHER	BODY & HARDWARE	150T-H-5-3
4	BUSHING M8x14	BODY & HARDWARE	150T-H-5-4
5	LEFT GRIP	Electrical & Control Parts	150T-H-5-5
6	BRAKE LEVER	Brakes, Tires & Wheels	150T-H-5-6
7	LOCK NUT M6	BODY & HARDWARE	150T-H-5-7
8	M6*30 FLANGE BOLT	BODY & HARDWARE	150T-H-5-8
9	REAR HYDRAULIC BRAKE LINE, CYLINDER & CALIPER	Brakes, Tires & Wheels	150T-H-5-9
10	M8*35 FLANGE BOLT	BODY & HARDWARE	150T-H-5-10
11	MOUNT BLOCK,REAR HYDRAULIC BRAKE	Brakes, Tires & Wheels	150T-H-5-11
12	BOLT M6*22	BODY & HARDWARE	150T-H-5-12
13	THROTTLE HOUSING	Electrical & Control Parts	150T-H-5-13
14	THROTTLE TWIST GRIP	Electrical & Control Parts	150T-H-5-14
15	BRAKE LEVER SAME AS 6	Brakes, Tires & Wheels	150T-H-5-15
16	FRONT HYDRAULIC BRAKE LINE, CYLINDER & CALIPER	Brakes, Tires & Wheels	150T-H-5-16
17	M8*30 FLANGE BOLT	BODY & HARDWARE	150T-H-5-17
18	THROTTLE CABLE	Electrical & Control Parts	150T-H-5-18
19	HANDLE BARS	Frame, Steering & Suspension	150T-H-5-19
20	M10*45 FLANGE BOLT	BODY & HARDWARE	150T-H-5-20
21	TRIPPLE TREE BEARING & RACE SET	Frame, Steering & Suspension	150T-H-5-21
22	M8*40,FLANGE BOLT	BODY & HARDWARE	150T-H-5-22
23	TRIPPLE TREE	Frame, Steering & Suspension	150T-H-5-23
24	LEFT FRONT SHOCK	Frame, Steering & Suspension	150T-H-5-24

# in Diagram	Name/Description	Category	Phone Reference #
25	HYDRAULIC BRAKE TUBE HOLDER 1	Brakes, Tires & Wheels	150T-H-5-25
26	M6,FLANGE BOLT	BODY & HARDWARE	150T-H-5-26
27	BOLT M6	BODY & HARDWARE	150T-H-5-27
28	HYDRAULIC BRAKE TUBE HOLDER 2	Brakes, Tires & Wheels	150T-H-5-28
29	BOLT M6*12	BODY & HARDWARE	150T-H-5-29
30	RIGHT FRONT SHOCK	Frame, Steering & Suspension	150T-H-5-30
31	SPEEDO WHEEL PUCK	Brakes, Tires & Wheels	150T-H-5-31
32	BEARING	Brakes, Tires & Wheels	150T-H-5-32
33	WHEEL CENTER BUSHING	Brakes, Tires & Wheels	150T-H-5-33
34	OIL/DUST SEAL	Brakes, Tires & Wheels	150T-H-5-34
35	FRONT WHEEL SPACER	Brakes, Tires & Wheels	150T-H-5-35
36	FRONT WHEEL AXLE	Brakes, Tires & Wheels	150T-H-5-36
37	LOCK NUT M14	BODY & HARDWARE	150T-H-5-37
38	FRONT BRAKE DISK BOLTS	Brakes, Tires & Wheels	150T-H-5-38
39	FRONT BRAKE DISK	Brakes, Tires & Wheels	150T-H-5-39
40	FRONT RIM	Brakes, Tires & Wheels	150T-H-5-40
41	FRONT TIRE 4.00-12	Brakes, Tires & Wheels	150T-H-5-41
42	VALVE STEM	Brakes, Tires & Wheels	150T-H-5-42
43	BRAKE PADS FRONT	Brakes, Tires & Wheels	150T-H-5-43
44	BRAKE PADS REAR	Brakes, Tires & Wheels	150T-H-5-44
45	BRAKE LIGHT SWITCH	Electrical & Control Parts	150T-H-5-45
47	RIGHT MIRROR	BODY & HARDWARE	150T-H-5-47
48	FRONT AXLE AND NUT	Brakes, Tires & Wheels	150T-H-5-48
49	FRONT HYDRAULIC BRAKE ASSY without 45	Brakes, Tires & Wheels	150T-H-5-49
50	REAR HYDRAULIC BRAKE ASSY without 45	Brakes, Tires & Wheels	150T-H-5-50
51	FRONT WHEEL COMPLETE	Brakes, Tires & Wheels	150T-H-5-51