



## B01 STEERING

1	SS49-B01.01	40100BMBT001	Handlebar	1
2	VN49-B06.20	B01091004565	Bolt M10x1.25x45mm	1
3		B04171012565	Nut M10x1.25mm	1
4	SS49-B01.04	40001J4AT001	Left Grip	1
5	SS49-B01.05	40210J4AT001	Right Grip Assy.	1
6		40211J4AT001	Right Grip	1
7		40212J4AT001	Throttle Guide Tube	1
8	SS49-B01.08	40300BM0T001	Throttle Cable Assy	1
9	SS49-B01.09	40008BM0T000	Rear Brake Cable Jacket	1
10		B02000501025	Screw 5x10mm	1
11	SS49-B01.11	40270BMBT000	Brake Cable Assy	1
12		40273BM0T000	Stop Pin (Gold)	1
13		40271BM0T000	Adjusting Nut	1
14		40340BM0T001	Junction Box	1
15		40274BMBT000	Spring (Gold)	1
16		40306BM0T000	Throttle Cable 1	1
17		40307BM0T000	Carburetor Line	1
18		40308BM0T000	Oil Pump Line	1



## B02 SWITCH ASSY

1	SS49-B02.01	40500BM0T000	Left Main Switch	1
2	SS49-B02.02	40002BM0T000	Left Brake Lever (145mm)	1
3		40004BMAT000	Lever Mounting Screw 5mm	1
4		B04000500065	Nut 5mm	1
5		91600BMAT000	Stop Switch Assy	1
6	SS49-B02.06	40600BM0T001	Right Control Switch	1
7		40610BM0T001	Right Brake Lever	1
8		40620BM0T000	Right Switch Fixing Seat	1
9		B02000502025	Screw 5x20mm	2
10		B02000502525	Screw 5x25mm	2
11		40510BM0T000	Left Switch Bracket	1
12		40520BM0T000	Left Switch Fixing Seat	1




13		B07000000505	Washer 5mm	1
----	--	--------------	------------	---




### B03 FRONT FORK

1	SS49-B03.01	43300BMBT000	Front Right Fork	1
2	SS49-B03.02	43200BMBT000	Front Left Fork	1
3		43204BMBT000	Cap Bolt	2
4		B190123200B0	O-RING 23.2X2.65MM	2
5		43230BMBT000	Inner Tube Comp	2
6		43202BMBT000	Spring	2
7		43290K00P000	Anti-Dust Cover	2
8		43207K00P000	Clip	2
9		43260K00P000	Oil Seal	2
10		43214BMBT000	Front Fork Piston	2
11		43208BMBT000	Fork Piston Ring	2
12		43203BMBT000	Front Fork Spring	2
13		43201BMBT000	Outer Tube 1	1
14		43237BMBT000	Shaft 2	2
15		43301BMBT000	Outer Tube 2	1
16		43209J0AP000	Gasket	2
17		B01090601265	Bolt 6x12mm	2
18		43008BMAT000	Nut	2
19		43005BMBT001	Ball Race Cover	1
20		43001BMBT001	Ball Race Connecting	1
21		B06010150000	Steel Ball 5 (Set of 42)	42
22		43003BMBT000	Ball Race 2	2
23		43004BMBT000	Ball Race 4	1
24	SS49-B03.24	43100BM0T001	Steering Column	1
25		B01091003065	Bolt 10x1.25x30mm	2
26		B01090601265	Bolt 6x12mm	1
27		43035BMBT000	Brake Hose Holder 2	1
28		B01070601625	Bolt 6x16mm	2
29		43021BMBT001	Front Brake Hose Holder	1
30		43150BMAT000	Cable Holder	1




### B04 FRONT WHEEL

1	SS49-B04.01	44100BM0TBHA	Front Wheel Rim 3.5 x 12"	1
2	SS49-B04.02	44600BM0T910	Collar	1
3	SS49-B04.03	44300BM0T000	Oil Seal 22x35x7 R	1
4	SS49-B04.04	B12016020100	Ball Bearing 6201-2RS	2
5	SS49-B04.05	B140107D12AB	Front Tire 120/70-12 DOT	1
6	VN49-B19.29	B1403Z201100	Air Valve	1
7	SS49-B04.07	B04171212563	U Nut 12x1.25mm	1
8	SS49-B04.08	44004G4CT000	Front Wheel Axle	1
9	SS49-B04.09	44005BM0T000	Collar	1
10	SS49-B04.10	44200BM0T000	Speedometer Pickup	1
11		B1404Z2011C0	Valve Cap	1




### B05 FRONT BRAKE ASSY

1	SS49-B05.01	45000J4FTB33	Front Disc Brake Assy.	1
2	SS49-B05.02	45014BMBT000	Front Brake Lever	1
3	SS49-B05.03	45015J1CT000	Lever Mounting Screw	1
4		B04160600065	Nut 6mm	1
5	SS49-B05.05	45400BMBTB30	Master Brake Cylinder	1
6	SS49-B05.06	45023J1DT000	Master Brake Cylinder Bracket	1
7		B01070602365	Bolt 6x23mm	1
8	SS49-B05.08	45200BMBT000	Front Brake Hose	1
9	SS49-B05.09	45500J4FTB30	Caliper Assembly	1
10	SS49-B05.10	45110J4FT000	Brake Pad Kit	1
11	SS49-B05.11	91700J3AT000	Front Brake Switch	1
12	SS49-B05.12	45033BMBTB30	Brake Disc	1
13	SS49-B05.13	45036BMBT000	Bolt	3




14		45653BMBT000	Washer	4
15		45651BMBT000	Flange Bolt	2
16		45039J4FT000	Bolt 8x35mm	2




### B06 MUFFLER

1	SS49-B06.01	47100BMBT00G	Muffler Assy (w/Catalyst)	1
2		47200BMBT00C	Muffler Canister	1
3	SS49-B06.03	47121B20T000	Seal Washer	1
4		47105BMBT00B	Exhaust Pipe Assy	1
5	SS49-B06.05	47123BMBT000	Muffler Fixing Plate	1
6	SS49-B06.06	47740B0ET000	Muffler Bush	1
7	SS49-B06.07	B01090803565	Bolt 8x35mm	1
8	SS49-B06.08	B01090802065	Bolt 8x20mm	1
9	SS49-B06.09	47800B0DT000	Exhaust Pipe Gasket	1
10		B01090601665	Bolt 6x16mm	2
11		47041B20T000	Muffler Clamp	2
12		47042B20T000	Clamp Cushion	2
13		B01090805565	Bolt 8x55mm	2
14		B02050802565	Bolt 8x25mm	3
15		B07030000805	Washer 8mm	3
16		B07000000805	Washer 8mm	3
17		B07030000804	Washer 8mm	2
18		B07000000804	Washer 8mm	2




### B07 AIR CLEANER

1		49101BMBT003	Air Cleaner Body	1
2		49001BMBT004	Air Cleaner Cover	1
3		49002BMBT005	Air Cleaner Intake Pipe	1
4	SS49-B07.04	49200BMBT003	Filter Element	1
5		49103BM0T001	Seal Gasket	1




6		49005BM0T001	Connecting Pipe	1
7		B05074202005	Screw 4.2x20mm	5
8		B13060602005	Screw 6x20mm	2
9		49023BM0T000	Bushing	2
10		49022BM0T000	Grommet	2
11		49016BM0T000	Clip 42.5 (Gold)	1
12		B05074201205	Screw 4.2x12mm	4
13	SS49-B07.13	49000BMBT001	Air Cleaner Assy	1
14	SS49-B07.14	49371B0DT000	Brake Cable Guide	1
15		B0109061265	Screw 6x12mm	2
16	SS49-B07.16	57051B2GT000	One Way Valve Plate	1
17	SS49-B07.17	49853BMBT001	Hose 2 (185mm)	1
18	SS49-B07.18	49852BMBT001	Hose 1 (250mm)	1
19	SS49-B07.19	49851BMBT001	Hose (210mm)	1
20	VN49-B25.18	49840B0ES000	One Way Valve II	1
21	VN49-B26.19	49805BMBT000	Spring II, Lock 17.5	4
22	VN49-B26.20	49870B2GT000	Air Cleaner Small	1
23	VN49-B25.21	49855B0ES000	Spring II, Lock 16.5	2



## B08 FUEL TANK

1	SS49-B08.01	50100BMBT001	Fuel Tank	1
2		B01090601265	Bolt 6x12mm	4
3	SS49-B08.03	50300BM0T000	Fuel Petcock Assy	1
4	SS49-B08.04	50301BM0T000	Fuel Hose 1 (4.5x5x80) SAE 30 R9	1
5	SS49-B08.05	50316BMBT000	Spring	1
6		50307BM0T000	Clip 8mm	4
7	SS49-B08.07	50302BM0T000	Vacuum Hose 1 (4x8x360)	1
8		50306BM0T000	Clip 7mm	2
9	SS49-B08.09	50303BM0T000	Fuel Hose 2 (4.5x8.5x250) SAE 30 R9	1
10	SS49-B08.10	50340BMA T000	Fuel Filter Assy	1
11	SS49-B08.11	50800BMBT000	Fuel Sensor	1
12		50801BM0T001	Bolt 5x16mm	4
13	SS49-B08.13	50004BMBT000	Sensor Gasket	1
14		50312JOET000	Seal Ring	1
15		B070200005005	Washer 5mm	4




16		50352BM0T000	Fuel Filter	1
----	--	--------------	-------------	---




### B09 SEAT ASSY

1	SS49-B09.01	51100BMBT002	Seat Assy	1
2	SS49-B09.02	51080BMBT000	Seat Hinge	1
3	SS49-B09.03	51001BMBT000	Pin, Seat Hinge	1
4		08011H60X000	Bolt 6x14mm	2
5	SS49-B09.05	51004BMBT001	Storage Compartment	1
6		B01090601265	Bolt 6x12mm	2
7	SS49-B09.07BLK	52011BMBTB10	Rear Carrier	1
7	SS49-B09.07YEL	52011BMBTY50	Rear Carrier	1
8		B02050803565	Screw 8x35mm	2
9		B05075001605	Screw 5x16mm	1
10		B04070600063	Nut 6mm	2
11	SS49-B09.11	08032BM0T000	O-Ring 84.4x3.1mm	1




### B10 REAR WHEEL

1	SS49-B10.01	54100BM0TBHA	Rear Wheel Rim 3.5 x 12"	1
2	SS49-B10.02	B140108D12BB	Rear Tire 130/70-12	1
3	VN49-B19.29	B1403Z201100	Valve Z2-01-1	1
4	SS49-B10.04	54200BMBT000	Brake Shoe Assy (Set of 2)	2
5	SS49-B10.05	54001BMBT000	Spring	2
6	SS49-B10.06	54003BM0T000	Camshaft, Rear Brake	1
7	SS49-B10.07	54250BM0T000	Camshaft Lever	1




8	SS49-B10.08	54002BM0T000	Indicator Plate	1
9	SS49-B10.09	54008BMBT000	Tension Spring	1
10		08012BM0T000	Hexbolt 6x30mm	1
11		B04171615063	U Nut 16x1.5mm	1
12	SS49-B10.12	65701BMBT001	Inner Rear Fender	1
13		65803J0ET000	Spring Nut	2
14		B01090602060	Bolt 6x20mm	2
15		54027BM0T000	Cap	1
19	SS49-B10.19	B190101000A0	O-Ring 10x1.9mm	1



### B11 FRAME

1		57100BMBT007	Frame	1
2	SS49-B11.02	58303BM0T000	Engine Mounting Bolt 1 (Gold)	1
3		B04171212563	Nut 12x1.25mm	1
4	SS49-B11.04	58301BMBT000	Engine Mounting Bolt 2	2
5		B04171012565	Nut 10x1.25mm	2
6		58320BMBT000	Engine Bracket Joining	1
7		58302B0DT000	Damper	2
8		58304BMBT000	Spring	2
9	SS49-B11.09	58800BM0T000	Seat Catch	1
10		B01090602065	Bolt 6x20mm	2
11		57080BMBT000	Carrier Bracket	1
12		B01090601265	Bolt 6x12mm	4
13		B04070800064	U Nut 8mm	1
14		58350BMAT000	Buffer, Engine Bracket	2
15	SS49-B11.15	58900BMBT000	Seat Cable	1
16	SS49-B11.16	58507BM0T000	Cushion Mid Stand	1
17	SS49-B11.17	58360BMBT000	Engine Bracket Component	1
18	SS49-B11.18	58520BM0T000	Main Stand	1
19	SS49-B11.19	58590BM0T000	Pin (Gold)	1
20	SS49-B11.20	58508B0DT000	Rubber Washer 10mm	1
21		63016B0DT000	Cotter Pin	1
22	SS49-B11.22	58510BM0T000	Main Stand Spring	1




23		B100432007P0	Rivet 3.2x7mm	2
24	SS49-B11.24	58700BM0T000	Side Stand	1
25	LS49-B12.13	57005B0DT000	Bolt, Side Stand	1
26	LS49-B12.12	57010BM0T001	Spring, Side Stand	1
27		B07030001005	Washer 10mm	1
28		57001BMBT000	Frame Body Number Plate	1
29		57006BM0T000	Hook	1




### B12 REAR SHOCK ABSORBER

1	SS49-B12.01	63100BM0T005	Rear Shock Absorber	1
2		B01090803564	Bolt 8x35mm	1
3		B01141004063	Bolt 10x1.25x40mm	1
4		63016B0DT001	Cotter Pin	1
5		B04070800065	Nut 8mm	1




### B13 OIL TANK

1	SS49-B13.01	64001BMAT000	Oil Tank	1
2	SS49-B13.02	64090BMAT000	Oil Tank Cap	1
3		B01090601265	Bolt 6x12mm	2
4	SS49-B13.04	64100BMAT000	Oil Level Gauge	1






5		50307BM0T000	Clip 8mm	1
6		64000BMAT000	Oil Tank Assy	1




#### B14 FRONT FENDER

1	SS49-B14.01BLK	65101BMBTB40B	Front Fender, Black	1
1	SS49-B14.01YLW	65101BMBTB40Y	Front Fender, Yellow	1
2		B04070600063	Nut 6mm	2
3	TNG-B11.02	66300BMBT000	Front Reflector, Amber	2
4	SS49-B14.04	65120BMBT000	Front Fender Bracket 1	1
5	SS49-B14.05	65110BMBT000	Front Fender Bracket 2	1
6	SS49-B14.06	65114BMBT000	Screw w/Washer 6x16mm	4




### B15 HANDLEBAR COVER

1	SS49-B15.01BLK	65201BMBT001B	Handlebar Cover, Upper, Black	1
1	SS49-B15.01YLW	65201BMBT001Y	Handlebar Cover, Upper, Yellow	1
2	SS49-B15.02	65202BMBT000	Handlebar Cover, Lower, Black	1
3	SS49-B15.03	65203BMBT000	Meter Cover	1
4	SS49-B15.04	B05075001605	Screw 5x16mm	2
5	SS49-B15.05	B05075001205	Screw 5x12mm	2
6	SS49-B15.06	B05074001205	Screw 4x12mm	2
7	SS49-B15.07	B05074001605	Screw 4x16mm	2
8	SS49-B15.08	B05073001005	Screw 3x10mm	4
9	SS49-B15.09	B13010501405	Screw 5x14mm	1
10	SS49-B15.10	40470BM BT003	Mirror, Right, Black	1
11	SS49-B15.11	40460BMBT003	Mirror, Left, Black	1



### B16 FRONT COVER ASSY

1	SS49-B16.01BLK	65301BMBT00AY	Front Cover, Black	1
1	SS49-B16.01YLW	65301BMBT00AY	Front Cover, Yellow	1
2	SS49-B16.02	65314BMBT000	Screw	1
3	SS49-B16.03	08027J4AT000	Plastic Washer	1
4	SS49-B16.04	B05074201605	ST 4.2x16	4
5	SS49-B16.05BLK	65367BMBT000	Cover, Right, Black	1
5	SS49-B16.05YLW	65367BMBT000	Cover, Right, Yellow	1
6	SS49-B16.06BLK	65366BMBT000	Cover, Left, Black	1
6	SS49-B16.06YLW	65366BMBT000	Cover, Left, Yellow	1
7	SS49-B16.07	B05074001205	ST 4.2x12	6
8	SS49-B16.08	65801BMAT000	Spring Nut ST4	4




### B17 BODY PANELS

1	SS49-B17.01	65402BMBT000	Front Inside Body Panel	1
2	SS49-B17.02	65403BMBT000	VIN Plate Cover	1




3		51011BMBT000	Helmet Hook	1
4		B01090603065	Bolt 6x30mm	1
5		B05074801605	Screw 4.8x16mm	6
6		65802BMAT000	Spring Nut 5mm	4
7		65801BMAT000	Spring Nut 4mm	10
8	SS49-B17.08	65407BMKT001	Front Inner Fender Cover	1
9		B05074001605	Screw 4x16mm	10
10	SS49-B17.10BLK	65406BMBT000B	Belly Pan, Black	1
10	SS49-B17.10YLW	65406BMBT000Y	Belly Pan, Yellow	1
11	SS49-B17.11	65813BMBT000	Floorboard Compartment Cover	1
12	SS49-B17.12	65401BMBT000	Floorboard, Black	1
13		08011H60X001	Bolt 6x14mm	4
14		B01090601265	Bolt 6x12mm	4
15		B07030000505	Washer 5mm	4




### B18 SIDE PANELS

1	SS49-B18.01BLK	65601BMBT000B	Side Panel Left, Black	1
1	SS49-B18.01YLW	65601BMBT000Y	Side Panel Left, Yellow	1
2	SS49-B18.02BLK	65602BMBT000B	Side Panel Right, Black	1
2	SS49-B18.02YLW	65602BMBT000Y	Side Panel Right, Yellow	1
3	SS49-B18.03	65605BMBT001	Center Panel	1
4	SS49-B18.04	65619BMBT000	Compartment Lid, Center Panel	1
5	SS49-B18.05BLK	65606BMBT000B	Fuel Fill Panel, Black	1
5	SS49-B18.05YLW	65606BMBT000Y	Fuel Fill Panel, Yellow	1
6		B05074001205	Screw 4x12mm	4
7		B05075001605	Screw 5x16mm	5




8		65802BMAT000	Spring Nut 5mm	4
9		B05075001205	Screw 5x12mm	4
10	SS49-B18.10	65608BMBT000	Decoration Cap	2
11		B02000602003	Screw 6x20mm	2
12		08021BMBT000	Washer	2
13		65616J00P000	Rubber Washer	2
14		65627BMBT000	Bushing	2
15	TNG-B11.01	66300BMBT001	Rear Reflector, Red	2
16		B04070600063	Nut 6mm	2




### B19 INSTRUMENT ASSY

1	SS49-B19.01	70000BMBT00S	Instrument Assy	1
2		B05074001205	Screw 4x12mm	2
3	SS49-B19.03	72900BMBT000	Speedometer Cable	1
4	VN49-B04.37	70001BMBT000	Bulb 12v3w	2
5	VN49-B04.51	70036BMBT000	Bulb 12v2w	4
6		B05074001005	Screw 4x10mm	1
7	SS49-B19.07	70003BMBT001	Guage Cover	1
8	SS49-B19.08	76000BMBT002	Digital Clock	1
9	SS49-B19.09	75000BMBT004	Speedometer Wire Harness	1
10	SS49-B19.10	88900BM0T001	Key Blank Left	1
11	SS49-B19.11	88900BMBT001	Key Blank Right	1
12	SS49-B19.12	76001BMBT000	Clock Battery	1




### B20 HEADLIGHT / FRONT TURN SIGNALS

1	LS49-B01.28	81100BM0T002	Left Front Turn Signal Assy	1
2	LS49-B01.29	81300BM0T002	Right Front Turn Signal Assy	1
3		B13060501205	Screw M5x12	2
4	SS49-B20.04	80000J4AT000	Headlight Assy W/ Halogen Bulb	1
5	LS49-B01.30	81501H70X001	Bulb 12v10w	2
6	VN49-B04.37	70001BMBT000	Bulb 12v3w	2
7	LS49-B22.34H	80002B20T000	Bulb 12v35/35w	2




8		81302B20T000	Turn Signal Lens Front Right	1
9		81102B20T000	Turn Signal Lens Front Left	1
10		08011B20T000	Screw	2
11	VN49-B04.46	81107BM0T000	Turn Signal Bulb Cover, Amber	2
12			Screw	2



### B21 TAILLIGHT / REAR TURN SIGNALS


1	SS49-B21.01	81700BMBT001	Turn Signal, Rear Right	1
2	SS49-B21.02	81500BMBT001	Turn Signal, Rear Left	1
3		81102BMBT001	Turn Signal Lens, Rear Left	1
4		81302BMBT001	Turn Signal Lens, Rear Right	1
5	VN49-B04.46	81107BM0T000	Turn Signal Bulb Cover, Amber	2
6		81105BM0T001	Bowl, Reflex Light	2
7		81502BM0T001	Bulb Base	2
8		B05004001203	Screw 4x12mm	1
9	LS49-B01.30	81501H70X001	Bulb 12v10w	2
10		81510BM0T000	Wire, Left Rear Turn signal	1
11		81710BM0T000	Wire, Right Rear Turn Signal	1
12	SS49-B21.12	82000BM0T001	Taillight Assy	1
13		B05074002005	Screw 4x20mm	2
14		82011G00P000	Rubber Washer	3
15	VN49-B04.08	82000B50T000	Bulb 12v21/5w	1
16	SS49-B21.16	82008BM0T001	Indicator Lens	1
17		82003BM0T000	Taillight Base	1
18		86502BM0T000	Rear Reflector	1
19		82900BM0T000	Wire Harness, Taillight	1
20	SS49-B21.20	08202BM0T000	Mud Flap	1
21		B04061012565	Nut 10x1.25mm	2
22		B04070600065	Nut 6mm	3
23		81511BM0T000	Turn Signal Left Spacer	1



24		65802BM0T000	Spring Nut 5mm	2
25		81708BM0T000	Turn Signal Right Spacer	1
26		B07030001005	Washer 10mm	2
27		B04070600054	Nut 6mm	2
28	SS49-B21.28	08203BMBT000	License Bracket	1
29		B04070600054	Nut 6mm	2
30		B07030000604	Washer 6mm	2
31		B01010601624	Bolt 6x16mm	2
32		B01090601664	Bolt 6x16mm	2

## B22 ELECTRICAL

1	SS49-B22.01	95000BMDT000	Horn	1
2	SS49-B22.02	92000BMBT007	Main Wire Harness	1
3	VN49-B04.05	98801B09F000	Regulator	1
4	SS49-B22.04	94000BMBT000	Starter Relay	1
5	SS49-B22.05	96900BMBT000	Wire Harness	1
6	SS49-B22.06	88101BM0T001	Cover Main Switch	1
7	SS49-B22.07	88100BMBT000	Main Switch Assy	1
8		88400BM0T000	Lock, Fuel Tank	1
9		88501BMBT000	Lock 1	1
10		88502BMBT000	Lock, Side Cover 3 Nut	1
11		88801BMBT000	Lock Seat 1	1
12		88802BMBT000	Lock Seat 2	1
13		88800BMBT000	Lock Seat, Assy	1
14	TNG-BAT-X5	96100BM0T000	Battery	1
15		B07030000605	Washer 6mm	2
16		B07000000605	Washer 6mm	2
17		B04000600055	Nut 6mm	1
18		96202BMA000	Ignition Coil	1
19		96201BMA000	Cover, Ignition Coil	1
20		B07000000505	Washer 5mm	1
21		B07030000505	Washer 5mm	1
22		B02000502025	Screw 5x20mm	1
23		96800BMA000	Fuse 8A,250v	1
24		08802BMBT000	Bolt 6x12mm	2




25		B05074001005	Screw 4x10mm	2
26		96001K00P000	Band 250mm	3
27		96003K00P000	Band 200mm	3
28		96002K00P000	Band 150mm	1
29	SS49-B22.29	96200BMAT000	Ignition Coil Assy	1
30	SS49-B22.30	88000BMBT000	3-Lock Assy	1
31		B01090601265	Bolt 6x12mm	3
32	SS49-B22.32	96500BM0T001	Flasher	1
33	SS49-B22.33	97701BM0T000	CDI	1
34		B01090601065	Bolt 6x10mm	1
38		B05004801305	Screw 4.8x13mm	2



### B23 TOOL KIT

1		02110BM0T000	Tool Bag	1
2		02102BM0T000	Spark Plug Socket	1
3		02101BM0T000	Spark Plug Socket Handle	1
4		02103BM0T000	Screw Driver	1
5		02104BM0T000	Handle	1
6		02114BM0T000	Funnel, Oil Tank	1
7		02115BM0T000	Rear Shock Absorber Adjuster	1



### B24 ENGINE ATTACHMENT

1	SS49-B24.01	08351BM0TC10	Kick Starter, Silver	1
2		B02050602565	Screw 6x25mm	1

