



## B01 STEERING

1	TS250-B01.01	250T-B/056	Handlebar	1
2		GB578-86	Hex Bolt M12X35	1
3	TS250-B01.03	250T-B/104	Throttle cable	1
4		250T-B/098.1	Lower Cable Seat	1
5		250T-B/098.2	Upper Cable Seat	1
5		GB818-85	Pan Head Screw M5X22	2
6	TS250-B01.07	250T-B/098	Cable Seat	1
6	TS250-B01.08	250T-B/118	Grip, Right	1
7	TS250-B01.09	250T-B/113	Headlight Switch	1
8	TS250-B01.10	250T-B/115	Starter Switch	1
9	TS250-B01.11	250T-B/013-14	Mirror Set (Left & Right)	1
11	TS250-B01.12	250T-B/110	Kill switch	1
12	TS250-B01.13	250T-B/111	High/Lo Beam Switch	1
13	TS250-B01.14	250T-B/112	Turn Signal Switch	1
14	TS250-B01.15	250T-B/114	Horn Button	1
15	TS250-B01.16	250T-B/117	Grip, Left	1




## B02 FRONT FORK

1	TS250-B02.01	250T-B/068	Steering Column	1
2	TS250-B02.02	250T-B/076	Front Shock Absorber, LH	1
3	TS250-B02.03	250T-B/077	Front Shock Absorber, RH	1
4		GB5789-86	Flange Bolt M6x12	1
5		GB5789-86	Flange Bolt M6x40	1
6	TS250-B02.06	250T-B/123	Guide	2
7	TS250-B02.07	250T-B/066	Clip	4
8	TS250-B02.08	GB818-85	Screw M6x12	1
9	TS250-B02.09	250T-B/079.1	Lower Bearing Assy	1
10	TS250-B02.10	250T-B/079.2	Upper Bearing Assy	1
11	TS250-B02.11	250T-B/079.3	Locknut	1




### B03 FRONT WHEEL

1	TS250-B03.01	250T-B/140	Front Axle	1
2	TS250-B03.02	250T-B/069	Speedometer Pickup	1
3	TS250-B03.03	250T-B/042.1	Bearing	2
4	TS250-B03.04	250T-B/105	Speedometer Cable	1
5	TS250-B03.05	250T-B/042.2	Spacer	1
6	TS250-B03.06	250T-B/042	Front Wheel Rim	1
7	TS250-B03.07	250T-B/044	Front/Rear Tire 110/90-12	1
8	VN49-B18.29	250T-B/046	Valve Stem	1
9	TS250-B03.09	250T-B/065	Front Brake Disc	1
10	TS250-B03.10	250T-B/067	Brake Disc Bolt, Front	6
11	TS250-B03.11	250T-B/042.3	Seal	1
12	TS250-B03.12	250T-B/141	Collar	1
13	GS150-B03.07	GB6177-86	Locknut M12X1.25	1



### B04 FRONT BRAKE ASSY

1	TS250-B04.01	250T-B/064.2-1	Brake Handle, Right	1
2	TS250-B04.02	250T-B/064.2-2	Return Spring	1
3	TS250-B04.03	250T-B/064.2-3	Connecting Socket	1
4		250T-B/064.2-4	Nut M5	1
5	TS250-B04.05	250T-B/064.2-5	Bolt, Brake Handle	1
6	TS250-B04.06	250T-B/064.2-6	Master Cylinder	1
7	TS250-B04.07	250T-B/064.2-7	Bracket, Master Cylinder	1
8		250T-B/064.2-8	Bolt M6X22	2
9	TS250-B04.09	250T-B/064.2-9	Switch, Front Brake	1
10	TS250-B04.10	250T-B/064.2-10	Brake Hose, Front	1
11	TS250-B04.11	250T-B/064.2-11	Bolt, Oil Inlet	2
12	TS250-B04.12	250T-B/064.2	Disc Brake, Front	1
13	TS250-B04.13	250T-B/064.1	Front Caliper Assy	1
14	TS250-B04.14	250T-B/064.1-19	Front Brake Pad Set	1




### B05 MUFFLER ASSY

1	TS250-B05.01	250T-B/084	Muffler Cushion	1
2	TS250-B05.02	250T-B/050	Muffler Connector	1



3	TS250-B05.03	GB823-86	Cap Nut M8	2
4	TS250-B05.04	250T-B/080	Black Lead Tray	1
5	TS250-B05.05	250T-B/078	Muffler Assy	1
6	TS250-B05.06	GB5787-86	Flange Bolt M8X38	1
7	TS250-B05.07	GB5787-86	Flange Bolt M8X80	1
8		GB5787-86	Flange Bolt M8X25	1
9		GB5787-86	Flange Bolt M8X20	1




### B06 AIR CLEANER

1	TS250-B06.01	250T-B/038.2	Air Box	1
2	TS250-B06.02	250T-B/038.1	Air Cleaner	1
3	TS250-B06.03	250T-B/038.1-1	Filter Element, Air Cleaner	1
4	TS250-B06.04	250T-B/125	Deflector	1
5		250T-B/148	Clamp	2




### B07 FUEL TANK

1	TS250-B07.01	250T-B/127	Fuel Tank	1
2		GB6177-86	Flange Nut M8	2
3		GB5787-86	Flange Bolt M6X16	3
4		250T-B/095	Fuel Pipe A	1
5		250T-B/095	Fuel Pipe B	1




6		250T-B/095	Fuel Pipe C	1
7	TS250-B07.07	250T-B/119	Fuel Filter	1
8		250T-B/097	Vacuum Tube	1
9	TS250-B07.09	250T-B/116	Fuel Pump	1
10		250T-B/093	Retainer/Sealing Ring, Fuel Sensor	1
11	TS250-B07.11	250T-B/092	Fuel Sensor	1
12		250T-B/149	Tank Plug	1
13		250T-B/138	Pipe Clip	8
14		GB5787-86	Flange Bolt M6X20	2




### B08 SEAT ASSY

1		250T-B/040	Seat cushion	1
2		GB5787-86	Bolt flange M6X20	2
3		GB96-35	Big washer 6-140HV	2
4		GB6177-86	Nut flange M6	5
5		250T-B/040.1	seat install board	1
6		250T-B/053	protecting cover, seat lock	1
7		250T-B/052	seat cock(rear)	1
8		250T-B/106	Seat lock acble(long)	1
9		GB5787-86	Bolt flange M6X12	4
10	not a part	250T-B/035	seat lock install frame(front)	4
11		250T-B/051	seat cock(front)	1
12		250T-B/108	Seat lock acble(short)	1




### B09 REAR WHEEL

1	TS250-B03.07	250T-B/045	Front/Rear Tire 110/90-12	1
2	VN49-B18.29	250T-B/046	Valve Stem	1
3	TS250-B09.03	250T-B/043	Rear Wheel Rim	1
4	TS250-B09.04	250T-B/071	Rear Brake Disc	1
5	TS250-B09.05	250T-B/072	Brake Disc Bolt, Rear	6
6	TS250-B09.06	250T-B/073	Connecting Bracket	1




7	TS250-B09.07	GB6187-86	Flange Nut M16x1.5	1
8	TS250-B09.08	250T-B/143	Bushing Set (Long/Short)	1




### B10 REAR BRAKE ASSY

1	TS250-B10.01	250T-B/070.2-1	Brake Handle, Left	1
2	TS250-B10.02	250T-B/070.2-2	Return Spring	1
3	TS250-B10.03	250T-B/070.2-3	Connecting Socket	1
4		250T-B/070.2-4	Nut M5	1
5	TS250-B10.05	250T-B/070.2-5	Bolt, Brake Handle	1
6	TS250-B10.06	250T-B/070.2-6	Master Cylinder	1
7	TS250-B10.07	250T-B/070.2-7	Bracket, Master Cylinder	1
8		250T-B/070.2-8	Bolt M6X22	2
9	TS250-B10.09	250T-B/070.2-9	Switch, Rear Brake	1
10	TS250-B10.10	250T-B/070.2-10	Brake Hose, Rear	1
11	TS250-B10.11	250T-B/070.2-11	Bolt, Oil Inlet	2
12	TS250-B10.12	250T-B/070.2	Rear Brake Master Cylinder	1
13	TS250-B10.13	250T-B/070.1	Rear Caliper Assy	1
14	TS250-B10.14	250T-B/070.1-14	Rear Brake Pad Set	1




### B11 COOLING SYSTEM

1	TS250-B11.01	250T-B/153	Temperature Switch	1
2	TS250-B11.02	250T-B/154	Radiator	1
3	TS250-B11.03	250T-B/155	Fan	1
4		GB5787-86	Flange Bolt M6x12	3
5	TS250-B11.05	250T-B/107	Pipe Spring	2
6	TS250-B11.06	250T-B/094.1	Outlet Hose	1
7	TS250-B11.07	250T-B/094.2	Inlet Hose	1




8	TS250-B11.08	250T-B/094.3	Filler Hose	1
9	TS250-B11.09	250T-B/147.1	Coolant Filler Inlet	1
10	TS250-B11.10	250T-B/147.2	Coolant Filler Cap	1
11	TS250-B11.11	250T-B/094.4	Overflow Hose	1
12	TS250-B11.12	250T-B/094.5	Return Tube	1
13	TS250-B11.13	250T-B/151	Overflow Tank	1
14	TS250-B11.14	250T-B/152	Cap, Overflow Tank	1
15	TS250-B11.15	250T-B/094.6	Drain Tube	1
16	TS250-B11.16	250T-B/150	Hose Clamp	8




### B12 FRAME

1	TS250-B12.01	250T-B/142.1	Hanger Axle 1	1
2	TS250-B12.02	GB6187-86	Flanged Locknut M10x1.25	1
3	TS250-B12.03	250T-B/122	Rubber Hanger, Large	1
4	TS250-B12.04	250T-B/121	Rubber Hanger, Small	1
5		250T-B/048	Main Frame	1
6	TS250-B12.06	250T-B/049	Hanger	1
7	TS250-B12.07	GB6187-86	Flanged Locknut M12x1.25	2
8	TS250-B12.08	250T-B/142.1	Hanger Axle 2	1



### B13 SUPPORT STANDS


1	TS250-B13.01	250T-B/054	Center Stand	1
2		GB6187-86	Nut M6	1
3	TS250-B13.03	250T-B/124	Rubber Cushion	1
4		GB5787-86	Flange Bolt M6x25	1
5		GB5787-86	Flange Bolt M10x25	2
6	TS250-B13.06	250T-B/054.1	Collar, Center Stand	2
7	TS250-B13.07	250T-B/055	Side Stand	1
8	TS250-B13.08	250T-B/083	Spring, Side Stand	1
9	TS250-B13.09	250T-B/055.1	Special Bolt, Side Stand	1
10	TS250-B13.10	250T-B/082	Spring, Center Stand	1






### B14 FRAME BRACKETS

1		250T-B/061	Horn Bracket	1
2		GB5787-86	Flange Bolt M8x40	2
3		GB6187-86	Flange Nut M8	2
4		250T-B/060	Right Foot	1
5		250T-B/059	Left Foot	1
6		GB5787-86	Flange Bolt M6x16	4
7		250T-B/057	Left Foot Bracket	1
8		250T-B/058	Right Foot Bracket	1
9		GB5787-86	Flange Bolt M6x12	4
10		GB5787-86	Flange Bolt M8x16	6
11		250T-B/062	Bracket, Starter Relay	1




### B15 REAR SHOCK ABSORBER

1	TS250-B15.01		Rear Shock Absorber Set	1
2	TS250-B15.02	250T-B/075	Shock Absorber Pair	1
3		250T-B/074	Left Shock Absorber	4
4	TS250-B15.04	250T-B/074..1	Bushing	2
5		GB5787-86	Flange Bolt M8x30	1
6	TS250-B15.06	250T-B/074..2	Bushing	1
7	TS250-B15.07	GB5787-86	Flange Bolt M10x1.25x40	2
8	TS250-B15.08	GB97.1-85	Washer 8x28	1
9		GB6187-86	Flanged Locknut	1




### B16 FRONT COVER AND FENDER

1	TS250-B16.01RED	250T-B/002	Front Cover , Red	1
2		GB845-86	Self Tapping Screw ST4.8x16	8
3		ZBT31084-87	Spring Nut ST4.2	11
4	TS250-B16.04	250T-B/028	Fender Frame	1
5		250T-B/036	Amber Reflector	2
6		GB6177-86	Flange Nut M6	2
7	TS250-B16.07RED	250T-B/011	Front Fender Front, Red	1
8		GB5787-86	Flange Bolt M6x12	4
9	TS250-B16.09	250T-B/123	Rubber Ring	1
10	TS250-B16.10RED	250T-B/027	Front Fender Rear, Red	1
11		GB5787-86	Flange Bolt M6x16	4
	TS250-B16.15	34905-F8-9000	Bulb for Turn Signal (in legshield)	2



### B17 LEG SHIELD AND FLOORBOARD


1	TS250-B17.01	250T-B/015	Leg Shield	1
2		GB845-86	Self Tapping Screw ST4.8x16	14
3	TS250-B17.03	250T-B/021	Floorboard, Center	1
4		ZBT31084-87	Spring Nut ST4.2	2
5		GB5787-86	Flange Bolt M6x12	1
6	-	250T-B/137	Vin Cover	4
7	TS250-B17.07	250T-B/041	Locking Fuel Cover	1






### B18 FLOORBOARD PANELS

1	TS250-B18.01	250T-B/019	Floorboard, Left	1
2		250T-B/024	Floor Mat Set (Left/Right)	1
3	TS250-B18.03	GB9074.14-88	Screw w/Washer M6c20	4
4		GB845-86	Self Tapping Screw ST4.8X16	10
5		ZBT31084-87	Spring Nut ST4.2	20
6	TS250-B18.06	250T-B/020	Floorboard, Right	1
7	TS250-B18.07	250T-B/129	Belly Pan Set (Left/Right)	1
8	TS250-B18.08RED	250T-B/006	Lower Side Panel, Left, Red	1
9	TS250-B18.09RED	250T-B/007	Lower Side Panel, Right, Red	1




### B19 SEAT STORAGE BOX

1	TS250-B19.01	250T-B/016	Outer Shell, Storage Box	1
2		GB9074.14-88	Screw with washer M6x16	2
3		GB845-86	Self Tapping Screw ST4.8x16	20
4		GB5787-86	Flange Bolt M6x12	1
5		ZBT31084-87	Spring Nut ST4.2	15
6	TS250-B19.06	250T-B/033	Cover, Battery Box	1
7	TS250-B19.07	250T-B/022	Front Cover, Storage Box	1
8	TS250-B19.08	250T-B/018	Storage Box	1
9	TS250-B19.09	250T-B/029	Rear Fender	1
10		250T-B/035	Reflector	1
11		GB6170-86	Nut M6	1
12	TS250-B19.12	GB96-35	Washer 6-140HV	1
13	TS250-B19.13	250T-B/023	Inner Cover, Storage Box	1




### B20 REAR BODY PANELS

1	TS250-B20.01RED	250T-B/005	Side Cover, Right, Red	1
2		GB845-86	Self Tapping Screw ST4.8x16	13
3		ZBT31084-87	Spring Nut ST4.2	6
4	TS250-B20.04RED	250T-B/004	Side Cover, Left, Red	1
5	TS250-B20.05RED	250T-B/008	Rear Molding, Left, Red	1




6	TS250-B20.06RED	250T-B/009	Rear Molding, Right, Red	1
7	TS250-B20.07RED	250T-B/010	Rear Molding, Red	1



### B21 REAR RACK AND BACKREST

1	TS250-B21.01	250T-B/012	Outer Cover, Rear Rack	1
2	TS250-B21.02	250T-B/031	Rear Grip, Left	1
3	TS250-B21.03	250T-B/032	Rear Grip, Right	1
4	TS250-B21.04	250T-B/047	Rear Rack	1
5	TS250-B21.05	250T-B/063	Bracket, Tail Light	
6		GB5787-86	Flange Bolt M8x35	8
7		GB5787-86	Flange Bolt M8x40	2
8	TS250-B21.08RED	250T-B/003	Rear End Panel, Red	1
9		GB5787-86	Flange Bolt M6x12	2
10	TS250-B21.10	250T-B/039	Rear Backrest	1
11	TS250-B21.11	250T-B/145	Hole Cover	6
12	TS250-B21.12	250T-B/146	License Plate Bracket	1
13	TS250-B21.13	250T-B/131	Rack Bushing	2




### B22 INSTRUMENT PANEL

1	TS250-B22.01	250T-B/025	Instrument Panel Cover, Rear	1
2		GB845-85	Self Tapping Screw ST4.8x16	8
3	TS250-B22.03	250T-B/026	Instrument Panel Cover, Front	1
4	TS250-B22.04	250T-B/130	Wind Screen	1
5		GB9074.14-88	Screw w/Washer M6x16	5



6		ZBT31084-87	Spring Nut ST4.2	2
7	TS250-B22.07	250T-B/001	Wind Screen Lower Panel, Red	1
8	TS250-B22.08	250T-B/120	Alarm Switch	1
9	TS250-B22.09	250T-B/101	Speedometer Assy	1



### B23 ELECTRICAL

1	TS250-B23.01	250T-B/103	Sub Wire Harness	1
2	TS250-B23.02	250T-B/103.1	Instrument Light A 12V/1.7W	3
3	TS250-B23.03	250T-B/103.2	Instrument Light B 12V/1.7W	3
4		250T-B/126	Wrap	1
5	TNG-BAT-X9	250T-B/099	Battery	1
6	TS250-B23.06	GB9074.14-88	Screw w/Washer M3x22	8
7	TS250-B23.07	250T-B/109	Seat lock	1
8	TS250-B23.08	250T-B/090	Starter Relay	1
9	TS250-B23.09	250T-B/102	Main Wire Harness	1
10	TS250-B23.10	250T-B/139	Resistor	1
11		GB5787-86	Flange Bolt M6x25	1
12		GB6177-86	Flange Nut M6	1
13	TS250-B23.13	250T-B/089	Rectifier/Regulator	1
14		GB5787-86	Flange Bolt M6x16	1
15	TS250-B23.15	250T-B/091	Horn	1
16		GB5787-86	Flange Bolt M6x12	1
17	TS250-B23.17	250T-B/096	CDI	1
18	TS250-B23.18	250T-B/087	High Tension Wire and Coil	1
19	TS250-B23.19	GB818-85	Pan Head Screw M5x20	1
20	TS250-B23.20	250T-B/088	Flasher	1
21	TS250-B23.21	250T-B/085	Battery Cable, Negative	1
22	TS250-B23.22	250T-B/086	Battery Cable, Positive	1

